


Dear Customer:
We are very appreciated that you chose our PB304 as your Walkman bluetooth speaker.Please read this instruction carefully before use to make the product more functional.It has not only gorgeous and fashionable exterior design but also pure and beautiful sound.The whole unit possesses design patent. It has advanced audio engineering,which makes you enjoy excellent acoustics whenever and wherever.

Notes:
Please store and use the unit under normal temperature environment;
Please don't expose the unit to the rain or humid environment;
Please don't throw the unit in order to avoid any damage;
Please don't disassemble and repair the unit by yourself;
Please don't discard or place the unit in the fire due to the built-in lithium battery.

Warm reminding:
1.For the sake of your hearing protection and the unit working life ,please don't listen to the music at high volume for a long time!
2.When there's a trouble with the unit,please immediately shut off the power and pull out the USB plug so as not to damage the loudspeaker and other components.
3.When there's a toot indication showing low power,please charge the lithium battery timely, because low power will affect the sound quality and the data transmission range,or the bluetooth will be easy to disconnect.
4.If the unit isn't used for a long time,please charge at least once in a month.This will be useful to protect the battery and extend its lifespan.
5.The unit has auto power-off function:if it is not connected or not working during 25 minutes, it will be shut down automatically.



Specification:
Model No.: PB304
Bluetooth Version: Bluetooth V3.0+EDR
Data Transmission Range: ≤10M(depend on the surrounding and connected bluetooth device)
Micro USB Charging Voltage: DC 5V-1600MA
Built-in Battery: Lithium Battery 1500MAH
Output Power: 3W×2
Frequency Response: 90Hz-18KHz
Sensibility: 80dB±2dB
SNR: ≥80dB
Unit Net Weight: 0.748KG

Accessories:
1. Bluetooth Speaker 1PCS
2. 3.5MM Audio Cable 1PCS
3. Micro USB Charging Cable 1PCS
4. Instruction/Warranty Card 1SET

Function State Instruction Indicators						
Power On	Bluetooth Search	Connected	AUX	Charging	Fully Charged	Incoming Calls
Blue Light On	Blue Light Twinkling	Blue Light On	Blue Light Twinkling	Red Light On	Dim Red Light	Blue Light Slowly Twinkling

Buttons				
Ⓜ	Operation Mode	Connection Status	AUX	Incoming Calls
	Short Press	Play/Pause	Cutoff Audio Source Input	Speaker Phone
	Continuous Double press	The Last Dialed Number Callback	N/A	N/A
“ _ ”	Short Press	Volume Down	N/A	N/A
	Long Press	The Next One	Volume Down	Volume Down
“ + ”	Short or double Press	Volume Up	N/A	N/A
	Long Press	The Previous One	Volume Up	Volume Up

Power On: Turn on the power switch,there will be a warning tone and blue light twinkling.The volume default is 70%.

Connection: After power on,the unit will enter into searching status and the blue light will twinkle quickly; meanwhile,it will match the bluetooth device automatically,and the device will remind match or not.

Confirmed to match and connected successfully,the blue light will be turned on,and there will be a toot reminder coming out of the unit!(In general,there's no need to put in password;if there's a need,then put in "0000").If the unit can't search any bluetooth device after power on for 5 minutes,it will be auto shutoff. If there's a need for a second connection,the unit has to be powered on again.The unit has reconnection function,that means the bluetooth device will be auto match when the bluetooth is turned on once more if the device has been connected successfully.Warm reminding:if the connection is failed,please reset the unit or maybe it's low power,please charge it.

Music Play: Long Press “-” for next one;Long press “+” for previous one;short or double press “-”+” for volume adjustment;press Ⓜ to play and pause the music;long press Ⓜ for disconnection and searching another bluetooth device.

Speaker Phone: After connected with the mobile phone,when there comes a call,there will be a notification tone coming out of the unit;press Ⓜ to receive the call,press Ⓜ again to hang up.

AUX Audio Source Play: Plug the audio cable into the speaker AUX audio interface and computers or other music player audio socket.Start the music on the player,the unit will switch to AUX mode automatically. short or double press “-”+” for volume adjustment;press Ⓜ to play and pause the music and disconnect.

Warm Reminding: When in AUX state,the Previous,Next,Play and Pause will be controlled by the player.

Smart Auto Quick Charge: Charge with the USB charging cable in the poweroff state,plug the Micro USB port into the speaker USB power socket and the other port into the computer USB socket or USB charger, then it will start charging,and the red light will turn to dim red after fully charged.

Battery Life: Built-in lithium battery with a capacity of 1500MAH.Support continuous playing for over 5 hours.

Compatibility
Wireless: All the devices with Bluetooth V3.0 or more advanced version(regarding the agreement details, please refer to the universal specification),such as iPad,iPhone 11 or other iPhone with iPhone software 3.1, iPod,TOCH,MAC with Bluetooth,and most of other master phones and computers with Bluetooth TM.

Bluetooth V3.0 includes A2DP,AVRCP,HFP,HSP.

Solutions for Common Problems

Phenomena	Solutions
Failed connection after several trials	1.Check the unit is in search or not,or reset it. 2.Close other bluetooth devices causing disturbance.
Low volume or distortion	1.Check the volume of the bluetooth device and adjust to proper level. 2.The battery is low power.Please charge it.
Interruption	1.Check if it's out of the effective transmission range,or if there's any obstacle between the unit and bluetooth device.
Indicator no function	1.The battery is low power.Please charge it. 2.Reset the unit.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits fora Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to thefollowing two conditions :
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

- CAUTION Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

The Rating Label is sticking on the speaker bottom part .

420*148mm,材质： 80G书写纸，黑白单面印刷，风琴折。