



## **Appendix II**

### **Internal Photographs**

## Open View of EUT




## Internal View of EUT-1




## Internal View of EUT-2




## Internal View of EUT-3




Internal View of EUT-4



Internal View of EUT-5




Internal View of EUT-6



Internal View of EUT-7




## Internal View of EUT-8




## Internal View of EUT-9




## Internal View of EUT-10




## Internal View of EUT-11




Internal View of EUT-12




Internal View of EUT-13




Internal View of EUT-14



Internal View of EUT-15



Internal View of EUT-16



Internal View of EUT-17




Adapter-1




Adapter-2




Adapter-3




Adapter-4




## Adapter-5



## Antenna and RF Model location-1




## Antenna and RF Model location-2




## Antenna and RF Model location-3



Antenna and RF Model location-4



Antenna and RF Model location-5



## Antenna and RF Model location-6

