


正面



产品使用说明书


Instructions book

产品图解
Product diagram



遥控手柄 bluetooth /operation stick

分解图示 Decomposition diagram



组合后图示 Assembled

遥控手柄与手机蓝牙配对操作
Bluetooth stick connect mobile phone bluetooth operation

第一步: 短按开关键显示闪烁状态, 遥控手柄自动进入蓝牙配对状态。

第二步: 打开手机蓝牙功能进入搜索状态出现‘BEEOK’, 在手机上点击‘BEEOK’则进行自动配对连接, 连接成功后, 遥控器上开关键蓝色LED灯熄灭, 即表示配对成功。

第三步: 蓝牙连接成功后, 系统将自动识别, 打开手机照相机, 按下遥控手柄中的拍照键即可进行拍照。

温馨提示:

- 1.调焦功能键目前仅适用于三星手机。
- 2.蓝牙遥控器与手机配对连接后, 若在5-10分钟内不操作使用, 遥控器上的指示灯会自动熄灭进入休眠状态, 当要重新使用时只需短按开关键即可。

1st Step
Press the switch button. Button flashing, it will enter in bluetooth pairing state.

2nd Step
Open the mobile phone bluetooth, enter in bluetooth searching state. Find out ‘BEEOK’, then connect it. When the bluetooth stick Switch button light turns off, that means bluetooth is paired successfully.

3rd step
After the bluetooth connected successfully, system will identify automatic, Open the mobile phone camera, press the bluetooth stick ‘Camera’ button to take photo.

Warm Tips:

1. Zoom function button only support for Android phone.
2. Bluetooth stick will be in dormancy state and the shutter light will turn off in 5-10 minutes if no operation. When use it, just need press switch button shortly.

注意事项
Cautions

- 1.本设备支持iOS5.0以上系统, 安卓4.2以上版本。
- 2.因天气原因请不要在下雨或打雷的情况下使用。
- 3.使用此产品时, 请留意将手机与手机夹、遥控手柄与伸缩杆固定好、锁紧, 避免损伤手机。
- 4.使用伸缩杆时, 请注意周围的人和东西, 避免伤到人和损伤东西; 伸缩杆在拉出及收回, 请慢慢将伸缩杆拉出及收回, 避免夹伤手。
- 5.因遥控手柄内部有电池、使用和保管时请注意防潮及防湿。
- 6.因落下及冲击会引起接触不良时, 请及时重新连接再拍照。
- 7.本产品没有防水功能, 请不要让产品沾水。
- 8.遥控手柄在充电时, 产品会发热请勿用布或纸等将其盖住。
- 9.充电状态时LED灯为红色, 充饱后红灯熄灭。
- 10.请不要让产品落下或撞击。
- 11.除指定机器以外, 请不要使用。

产品参数
Specification

蓝牙版本: 采用蓝牙3.0版本
蓝牙要求: 支持iOS5.0以上系统, Android4.2以上版本; 无需安装其他适配软件, 即联即用。

遥控距离: 10米
电池容量: 55mAh
待机时间: 100小时
工作时间: 40小时
总重量: 150克
拉伸长度: 315-960毫米
材质: 塑胶、不锈钢
最大承载: 500克
配线: 蓝牙遥控手柄、带手机固定支架的伸缩拉杆、USB线

背面

保修卡
Warranty Card

感谢您选用我公司手机智能助拍器, 您将会感受到我公司手机智能助拍器给您带来非一般的使用感受。请如实填写以下信息, 以便我们能及时提供周到的服务。

Thank you for choosing our company's wireless mobile phone monopod, which will bring you outstanding using performance. Please fill in the following information correctly so that we can offer you timely and considerate service.

客户留存 Kept by customer	经销商留存 Retained by the dealer
您的姓名: Name	性别: Gender
手机: Mobile phone	手机: Mobile phone
家庭详细地址: Address	家庭详细地址: Address
以下由经销商填写 Below information to be filled by agency	
产品型号: Model	销售日期: Selling date
经销商名称: Agency name	联系电话: Telephone
产发票号码: Invoice NO	

保修卡
Warranty Card

感谢您选用我公司手机智能助拍器, 您将会感受到我公司手机智能助拍器给您带来非一般的使用感受。请如实填写以下信息, 以便我们能及时提供周到的服务。

Thank you for choosing our company's wireless mobile phone monopod, which will bring you outstanding using performance. Please fill in the following information correctly so that we can offer you timely and considerate service.

客户留存 Kept by customer	经销商留存 Retained by the dealer
您的姓名: Name	性别: Gender
手机: Mobile phone	手机: Mobile phone
家庭详细地址: Address	家庭详细地址: Address
以下由经销商填写 Below information to be filled by agency	
产品型号: Model	销售日期: Selling date
经销商名称: Agency name	联系电话: Telephone
产发票号码: Invoice NO	

保修卡
Warranty Card

一、服务条款

- 1.您在购买本产品一年内(含), 产品主机经我公司服务中心检测出由于本产品元器件所引发之故障, 请您携带有效购机凭证和有效保修凭证与故障设备到服务中心享受免费保修服务。
- 2.您购买的本产品所配其他的附件(设备外壳、说明书、包装、软件等(以实物为准)以及其他不属于保修范围的附件、辅助部件)均不在保修范围内。

二、特别提醒

- 1.如果您购买的本产品属于下列任何一种情况, 我公司有权不按照“质保凭证”条款的内容提供免费服务, 您可以选择有偿服务, : 未按产品使用说明书的要求使用、维护、保管而导致的故障或损坏; 擅自涂改三包凭证上的信息与商品实物不相符; 其他非产品设计、技术、制造、质量等问题而导致的故障或损坏; 因不可抗力而导致的故障或损坏的(火灾、地震、水灾、雷电等或其它的自然灾害、环境污染、不适当电压等所造成之故障或损坏)使用过程中感染病毒造成损坏的; 由于储存疏忽或不当, 及保养不当造成之故障或损坏; 本产品的服务政策中所列设备的其他部件出现故障, 或随机操作系统及软件出现故障时, 不作为产品“质保承诺”兑现的依据。
- 2.在购买时请您协助销售商完整填写本手册相关信息, 并确认加盖销售商公章, 同时向销售商索要有效购机凭证。
- 3.购买凭证、保修凭证是获得服务的主要凭证, 请妥善保管并在每次接受服务时务必携带。如您不能出示有效保修凭证和有效购买凭证, 则该故障产品不在免费服务范围内。
- 4.您的保修期自开具有效凭证之日起算。
- 5.产品出现故障的日期以送达我公司服务中心之日为准。

I. Terms of service

1. Any problem resulting from product components, once tested by our service center, can be applied for free maintenance. service center within 1 year. Please bring valid purchase proof and warranty card along with the defective product to the service center.
2. Accessories of the purchased product (equipment case, user manual, packing, software etc (subject to the actual product and other accessories which do not belong to warranty scope) are not included in the warranty scope.

II. Attention please

1. The right not to offer free maintenance service according to the terms on 'warranty card' will be reserved by our company if the product belongs to any of the following:
 - The product serial NO. Has been damaged or erased
 - Defect or damage caused by using, maintaining or keeping other than in accordance with the user manual
 - Product damage caused by virus infection, etc which are not complain with those on the actual product
 - Other damage not resulted from product design or other natural disaster, environmental pollution, improper electrical voltage, etc. damage caused by virus infection, damage caused by improper placing and maintaining
 - Defect of other component listed in the product service terms.
 - Problems of operation system or software, are not valid for the execution of "warranty promise".
 - Please help the selling agency to fill in relative information on the warranty card, and ensure them stamp official seal. At the meantime, please ask for valid purchase proof from them.
 - Purchase proof, warranty card are the main proof for you to acquire maintenance service. Please keep them safe and bring them every time when you apply for service. Free maintenance service will not be applied to defective product if you fail to offer valid warranty card and purchase proof.

Federal Communications Commission (FCC) Interference

Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RF exposure warning

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment must not be collocated or operating in conjunction with any other antenna or transmitter.