

Ashley Mary

BLUETOOTH® SPEAKER:

Thank you for purchasing the Ashley Mary Bluetooth® Speaker. Before using your speaker, please read the instruction manual carefully and keep for future reference.

CONTENTS:


- Ashley Mary Bluetooth® Speaker
- Instruction Manual
- USB Charge Cable

SAFETY/CARE NOTES:

When used for the first time, please ensure that the volume is on a low setting as excessive volume may cause damage to the unit and potentially impair your hearing. Please keep your speaker away from liquids, excessive moisture, rainwater, sand, dust, dirt and heat sources. To clean your speaker, please use a dry dust cloth.

FEATURES:

- 1) ON/OFF Button.
- 2) Bluetooth® Indicator Light
- 3) Charging Indicator Light
- 4) Microphone
- 5) Speaker
- 6) Micro USB charge cable port



BLUETOOTH CONNECTION:

- Press and hold the power ON button for 3 seconds and the blue LED will flash continually. You will hear a voice prompt telling you that the speaker is ready to be connected to your Bluetooth® device.
- Activate your Bluetooth® device and search for 'ASHLEY MARY SPEAKER'. When connected you will hear a voice prompt telling you that you have connected to the speaker, the blue LED will stay on.

HANDS FREE VOICE CALLING:

The speaker is equipped with a microphone that enables hands free voice calling. Your device must be connected to the speaker via Bluetooth® to enable hands free calling. Press the button once on

the speaker to answer the call, press again to cancel the call.

When you answer the call on your device the sound will automatically be transmitted from the speaker. Please note, some devices will require you to change manually. Please note that when using Skype® from your Bluetooth® device you will need to answer and cancel the call manually from your Bluetooth® device.

MUSIC:

When your Bluetooth® device is connected to the speaker, you can begin to play music.

BLUETOOTH® ANTI-THEFT ALARM FEATURE:

Once your phone or other Bluetooth® device is connected, the Anti-Theft feature will activate.

If your speaker and Bluetooth® device is over 32 feet away from each other, the alarm will sound. The Bluetooth® device will reconnect when back in range.

BLUETOOTH® CAMERA SHUTTER FUNCTION:

When you are connected you can take photos by pressing the play button on the Bluetooth® speaker when connected to your camera APP.

This item is compatible with Apple devices running iOS 5 or later and with Android devices running 4.3 or later. If using an Android device, you may need to configure the camera settings for the volume key to act as the camera key. If you are using an older version, you will need a third-party camera APP to allow for camera key configuration. Please note, some non-Android or iPhone devices will not operate this feature.

CHARGING:

When the battery is running low a voice prompt will sound to alert you of this.

To charge the speaker, connect to a PC or USB DC5V power source via the USB cable supplied. When charging, the red light on the front of your speaker will be illuminated and will turn off when the battery is fully charged.

The speaker takes 2 hours to fully charge if not in use while charging. You may use this speaker while charging; however, this will increase the time required to fully charge the battery. Once fully charged the speaker will last up to 2.5 hours.

TROUBLESHOOTING:

1. Speaker will not turn on: Check your speaker is charged by following the charging instructions.
2. Unable to connect to speaker via Bluetooth®: Ensure your speaker is switched ON. Ensure your Bluetooth® device is within range of your speaker (32 feet without obstruction). Check that your device is paired with the ASHLEY MARY SPEAKER.
3. No output on speaker: Ensure that the volume is turned up on your device.

SPECIFICATIONS:

Battery	
Operating voltage	3.7v DC
Capacity	180 mAh
Type	Lithium polymer
Playback duration	Up to 2.5 hours
Charging	
USB Voltage	5v DC
Current	500 mA
Charging time	2 hours (if not in use)
Audio input	
Bluetooth	Version 4.1
Bluetooth range	Up to 32 feet (without obstruction)
Amplifier	
Power	2W
THD	1%
SNR	90dB

WARNING:

Do not place the Bluetooth® Speaker near fire. Do not expose the product to an excessively hot environment. Do not expose the Bluetooth® Speaker to water or high humidity. Do not place the Bluetooth® Speaker on flammable materials while charging. Do not leave the Bluetooth® Speaker charging once it is fully charged. Do not use the Bluetooth® Speaker in temperatures below freezing or over 100°F. Do not drop or shake. Do not disassemble the Bluetooth® Speaker or attempt to repair or modify it any way. The Bluetooth® Speaker is not a toy. It is not intended for use by children without supervision.

If heat, discoloration or warping appears when charging, immediately disconnect the device and discontinue use as this may cause leakage or ignition. If battery leakage does occur, avoid contact with eyes. If liquid does come into contact with eyes or skin, do not rub. Rinse the affected area with clean water and consult a physician immediately.

LIMITED WARRANTY:

design loop warrants the product against defects in material and workmanship under normal use for a period of one year from the original date of purchase. design loop will repair or replace the defective product, at our option, at no additional charge.

This warranty is applicable to the original purchaser only and is applicable only when presented with proof of purchase.

LIMITATIONS:

This limited warranty does not cover normal wear and tear of the products. This warranty does not apply to damage resulting from: improper or unreasonable use or maintenance, abuse, negligence, failure to follow instructions contained in any written materials that accompany the product, deterioration by reason of excess moisture, corrosive atmosphere, lightning, power surges, connections to improper voltage supply, unauthorized alteration, or other external causes such as extremes in temperature or humidity, modifications, scratches or discoloration, accidents, misuse, or acts of God.

To make a warranty claim, email design loop at support@designloopco.com. Be sure to include a copy of the sales receipt to demonstrate proof of purchase.

design loop shall not be liable, in any event, for any incidental or consequential damages resulting from use or misuse of this product. Except to the extent prohibited by law, any implied warranty of merchantability or fitness for a particular purpose on this product is limited in duration to the warranty period. Some states do not allow the exclusion or limitation or incidental or consequential damages so that the above limitations may not apply to you. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



- The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks is used under licence.

Made in China.

FCC ID No. :2AFVJCO9200

