



Generic User Guide for MIUI 14

Contents

Chapter 1 Get started	01
About the user guide.....	01
Phone overview.....	01
Insert a SIM card.....	01
Power on the phone.....	02
Finish the setup wizard.....	03
Connect to Wi-Fi.....	03
Add accounts.....	03
Copy your data.....	04
Turn the screen on or off.....	04
Chapter 2 Basic features	04
Gestures and shortcuts.....	04
Home screen.....	07
Notifications icons and status icons.....	08
Control center.....	10
Recents windows.....	12
Widgets.....	12
Lock and unlock the screen.....	13
Adjust the volume.....	14
App Downloads.....	15
Apps and App folders.....	16
Screenshots and Screen recording.....	16
Transfer files.....	19
Charging.....	20
Chapter 3 Personalize your phone	21
Wallpapers and themes.....	21
Sound & vibration.....	22
Display.....	24

Always-on display & Lock screen	26
Home screen	28
Notifications & Control center	31
Date and time	34
Languages and regions.....	36
Chapter 4 Battery and maintenance	36
View battery capacity	36
Enable Battery saver	37
Enable Ultra battery saver	37
Fix the battery usage issues	37
View power consumption in detail	38
View the battery temperature	38
Enable Reverse wireless charging	38
Chapter 5 Networks and connection.....	39
SIM cards & mobile networks	39
Use an eSIM card	41
Wi-Fi.....	43
Chapter 6 Connection and sharing	45
Bluetooth.....	45
Portable hotspot	46
Connection & sharing	47
Chapter 7 Phone and Messages.....	50
Phone	50
Messages	55
Chapter 8 Camera.....	59
Camera overview	59
Open Camera	60
Take photos.....	61
Switch between camera modes	61

Basic features.....	62
Useful features	63
Take a selfie.....	68
Take videos.....	69
Take Documents mode photos	69
Pro mode	70
Take photos in Portrait mode.....	72
Take photos in Night mode	74
Take photos in ultra-high definition mode	74
Take videos in Short video mode	74
Take photos in Panorama mode.....	75
Take videos in VLOG mode	76
Take videos in Slow motion mode	76
Take videos in Time-lapse mode	76
Take videos in Movie effects mode	77
Take photos in Long exposure mode.....	77
Take photos in Supermoon mode.....	78
Take videos in Dual video mode.....	78
Clone mode	79
Camera settings.....	80
Chapter 9 Gallery.....	85
Gallery overview	85
Photos.....	86
Albums.....	90
Edit a video with Video editor	92
Create a collage	92
Create a clip.....	93
Edit a picture with Cutout	93
Edit a picture with Art.....	94

Edit a video with Video effects.....	94
Free up space	95
Sort and set the album view format	95
Gallery Settings	95
Chapter 10 Apps	98
Calculator	98
Clock.....	100
Compass	102
Downloads.....	103
File Manager.....	103
Google.....	105
Mi Browser.....	108
Mi Remote	109
Mi Store.....	110
Mi Video.....	111
Music	113
Notes.....	114
Recorder	116
Scanner	117
Security.....	117
Services & Feedback.....	126
ShareMe.....	126
Themes	127
Weather.....	127
Xiaomi Community	128
Chapter 11 Security and safety	129
Passwords and security	129
Security status.....	132
Safety & emergency.....	132

Privacy.....	135
Apps.....	138
Location.....	142
Chapter 12 Accessibility.....	144
General.....	144
Vision.....	145
Hearing	147
Physical	148
Digital Wellbeing & parental controls.....	149
Chapter 13 Special features	150
Learn to use floating windows	151
Enable Sidebar	151
Open an App in Sidebar.....	152
Open an App in floating window.....	152
Manage floating window shortcuts.....	153
Toolbox	153
Set up front camera assistant	154
Turn on Second space.....	155
Measure heart rate.....	155
Chapter 14 Reboot, update, reset, and restore	156
Power off the phone	156
Reboot the phone	156
Update MIUI version.....	156
Update system Apps.....	156
Manage System apps updater	156
Back up and restore	157
Factory reset.....	157
Chapter 15 About device and accounts	157
About the phone	157

Memory extension.....	157
Xiaomi Account	158
Google.....	158
Accounts & sync	158
Services & feedback	158
Disclaimer	159


Chapter 1 Get started

About the user guide

Thanks for choosing Xiaomi phone, please read the user guide carefully before you start. This is the phone generic user guide for the MIUI 14 version. If you are not sure which software version your device is running, you can go to **Settings > About phone** to view the MIUI version information.

For more MIUI features, see global.miui.com for more information.

Phone overview



1. Front camera	2. SIM card slot	3. USB port
4. Fingerprint sensor	5. Power button/ Power button with Fingerprint sensor	6. Volume buttons
7. Flash	8. Rear cameras	

Note

The illustration is for reference only. The fingerprint sensor may locate on the **Power button** or the bottom of the screen.

Insert a SIM card


1. Withdraw the SIM card slot with the ejection tool.

2. Put the SIM card on the slot.
3. Insert the slot back into the phone.

Note


- If you insert two SIM cards, you can set one as the primary mobile data SIM and the other as the primary calling SIM, or set call forwarding between the two SIM cards. See [Set a default call SIM](#) and [Set a default data SIM](#) for more information.
- On different models, the SIM card slot may locate on the side or the bottom of the phone and the slot appearance may vary.
- Some models may support to insert an SD card on the SIM card slot.

For example:



Power on the phone

1. Press and hold the **Power button** until the phone vibrates.



2. Finish the setup wizard.

Note

The first time you power on the phone, a setup wizard helps you personalize your phone, connect to a mobile network or Wi-Fi network, choose to copy Apps and data,




sign in with a Google account or Xiaomi Account, set screen lock, set up Google Assistant, and other basic settings.

Finish the setup wizard

If you do not finish all basic settings in the setup wizard when you power on the phone at the first time, a notification shows on the notification panel after you start the phone.

You can swipe down the notification panel to see the notification of **Android Setup**. You can tap the notification to follow the onscreen instructions to finish the setup wizard.


Connect to Wi-Fi

1. Go to  **Settings** >  **Wi-Fi**.
2. Tap  to enable **Wi-Fi**.
3. Select an available network to connect.

Note

You need to enter a password for an encrypted Wi-Fi network.



Tip

You can swipe down the status bar at the upper-right corner of the phone, then tap  **Wi-Fi** on the Control center to connect the same Wi-Fi next time.

Add accounts

Sign in to your Google Account

Google Account enables you to access Google Cloud Storage and Apps installed from your account, and make full use of the Android features.

1. Go to  **Settings** >  **Accounts & sync**.
2. Tap **Add account**.
3. Choose **Google**.
4. Sign in with your Google Account.

Note

If you do not have an account, you can tap **Create account** to create one. See [Google](#) for more information.

Sign in to your Xiaomi Account

Xiaomi Account enables you to access exclusive Mi content and make full use of Mi Apps.

1. Go to  **Settings** >  **Xiaomi Account**.
2. Sign in with your Xiaomi Account.

Note

Xiaomi Account will be created automatically when you use a phone number for the first time. You can also create a Xiaomi Account with an email address.

Copy your data

When you power on your phone for the first time in setup wizard, you can follow the onscreen instructions to copy your data with cables or use other methods.

Turn the screen on or off

You can quickly press the **Power button** to turn the screen on or off.

The phone turns off the screen automatically to save power, secure your privacy, and goes to sleep when you are not using it. The phone can be locked or unlocked depending on your screen lock settings.

Chapter 2 Basic features

Gestures and shortcuts


You can learn gestures and shortcuts to interact with the phone.


Note

The feature may vary by device.

Basic gestures


You can use the simple gestures to control your phone and Apps.



Gesture	Definition	Examples for gesture effects
	Tap	<ul style="list-style-type: none">• Open or choose an item.• Enter texts with keyboard on the phone screen.

Gesture	Definition	Examples for gesture effects
	Touch and hold	<ul style="list-style-type: none"> • Move an App icon on the Home screen. • Activate a list to choose multiple items.
	Swipe	<ul style="list-style-type: none"> • Browse a list quickly.
	Scroll	<ul style="list-style-type: none"> • Drag a list up or down to see more information.
	Zoom in	<ul style="list-style-type: none"> • View photos with more details. • Browse websites clearly.
	Zoom out	<ul style="list-style-type: none"> • Check maps in full view.

Button shortcuts

You can take actions with physical buttons to use basic functions or activate other features.

Gesture	Description
	<p>Power off and reboot</p> <p>Press and hold the Power button until the Power off and Reboot menu appears.</p>



Gesture	Description
	<p>Increase the volume</p> <p>Press the Volume up button.</p>
	<p>Decrease the volume</p> <p>Press the Volume down button.</p>
	<p>Take a screenshot</p> <p>Simultaneously press the Volume down button and the Power button.</p>
	<p>Launch Google Assistant *</p> <p>Press and hold the Power button until the Google assistant appears.</p>

Note

* **Launch Google Assistant** may not be available to your models.

Take a screenshot



You can use the gestures to take a screenshot and a partial screenshot.

Gesture	Description
	<p>Take a screenshot</p> <p>Slide 3 fingers down.</p>
	<p>Take a partial screenshot</p> <p>Press and hold with 3 fingers.</p>




Note

Before you can use the gestures, you need to enable the shortcuts. See [Enable Take a screenshot shortcut](#) and [Enable Partial screenshot shortcut](#) for more information.

Home screen

		
1. Status bar	2. System navigation buttons	3. Full screen indicator


System navigation buttons





	<ul style="list-style-type: none">• Tap to return to the previous step.
	<ul style="list-style-type: none">• Tap to return to the Home screen.• Press and hold to use Google Assistant.
	<ul style="list-style-type: none">• Tap to view recently-opened Apps in Recents.

Note

See [Set system navigation buttons](#) for more information.

Full screen gestures

Gesture	Description
	Go to Home screen Swipe up from the bottom of the screen.

Gesture	Description
	<p>Open Recents</p> <p>Swipe up from the bottom of the screen and pause.</p>
	<p>Go back</p> <p>Swipe left or right from the edge of the screen.</p>
	<p>Trigger app's action</p> <p>Swipe left or right from the edge of the screen in top area.</p>
	<p>Switch between apps</p> <p>Swipe left or right from the full screen indicator or bottom of the screen.</p>







Note



















You can use the above gestures only when you choose full screen gestures mode. You can see [Set full screen gestures](#) for more information.

Notifications icons and status icons

Notifications icons and status icons inform you of the newest events, such as news or messages from Apps and the statuses of your phone, such as the network strength or battery condition.

Notification icons and status icons

	5G network connected		Full signal strength
	SIM card not found		VoLTE enabled
	Airplane mode enabled		Wi-Fi network connected

	Portable hotspot enabled		Calling
	Missed call		Unread SMS
	Do not disturb		Silent mode
	Vibrate in silent mode		Alarm
	Headset		Headset with a microphone connected
	Microphone in use indicator		Camera in use indicator
	Bluetooth enabled		Location services
	Battery saver		Low battery
	Charging		Mi Turbo Charge enabled

Note

- The network status icon may vary depending on your region and network service provider.
- Because functions vary among different models, some notification icons and status icons may not be available to your models.

View the notifications

1. Swipe down from the upper-left of the phone to open the notification panel.
2. Tap a notification to view in details.

Clear the notifications


1. Swipe down from the upper-left of the phone to open the notification panel.
2. Swipe right on a notification reminder to clear the notification.

Tip

You can tap  at the bottom of the notification panel to clear all notifications.









Control center






















You can quickly access the feature shortcuts on the Control center.



1. View notification icons and status icons	2. Go to Settings	3. Add or delete toggles
4. Tap to enable or disable the feature/ Touch and hold to access the feature settings	5. Swipe left or right to reveal more shortcut toggles	

Toggles on the Control center

	Bluetooth		Aeroplane mode
	Auto brightness		Mute
	Screenshot		Flashlight
	Lock orientation		Lock screen

	Screen Recorder		Scanner
	Reading mode		Dark mode
	DND		Battery saver
	Ultra battery saver		Cast
	Mi Share		Floating windows
	Vibrate		Hotspot
	Nearby Share		NFC
	Dolby Atmos		Location
	Focus mode		Bedtime mode
	Performance mode		Mi Remote
	Reverse wireless charging		

Note


The toggles may not be available to some models.

Open the Control center


When you use **New version** of the Control center, pull down the status bar on the right to open the Control center. When you use the **Old version** of the Control center, pull down status bar to open the Control center. See [Choose Control center style](#) for more information.

Recents windows


Recents windows enable you to view recently-used Apps and switch between Apps.




Open recently-opened Apps in Recents

1. Open **Recents** windows.
 - Swipe up from the bottom of the screen when in full screen mode.
 - Tap  when use system navigation buttons.
2. Tap an App window.

Remove recently-opened Apps in Recents

1. Open **Recents** windows.
 - Swipe up from the bottom of the screen when in full screen mode.
 - Tap  when use system navigation buttons.
2. Swipe an App window left or right.



Note

You can tap  to clear all recently-opened Apps.

Widgets

Widgets enables you to quickly access the functions of Apps such as Cleaner function, Clock information, or Weather information.

Add a widget to Home screen

1. Enter the screen editing mode.
 - Pinch on the Home screen.
 - Touch and hold an empty space on the Home screen.
2. Tap  **Widgets** to view all widgets.
3. Choose a widget and tap the widget to add it to the Home screen.
4. Tap  at the upper-left corner of the phone or zoom in the page.

Tip

If there is not enough space, you can drag the widget to a different Home screen page.

Move a widget on Home screen

1. Touch and hold a widget until the pop-up window shows.
2. Move the widget to other places on the Home screen.

Remove a widget from Home screen

1. Touch and hold a widget until the pop-up window shows.
2. Tap **Remove**.

Lock and unlock the screen



You can lock and unlock the screen without password. In the case, you can turn on and off the screen easily. You can also add a screen lock and other lock types to secure your phone.



Lock the screen with the Power button

Press the **Power button**.

Lock the screen with Widgets

When you are not convenient to press the Power button, tap the lock icon on the Home screen to quickly lock the screen.

1. Enter the screen editing mode.
 - Pinch on the Home screen.
 - Touch and hold an empty space on the Home screen.
2. Tap  **Widgets** to view all widgets.
3. Tap  **Lock** from Quick functions.

4. Tap  at the upper-left corner of the phone or zoom in the page.
5. Tap  **Lock** to lock the screen.

Unlock the screen with a pattern, PIN, or password

If you do not know or want a pattern, PIN, or password, you can see [Set up Screen lock](#) for more information.

1. Press the **Power button** to wake up the phone.
2. Swipe up from the bottom of the screen.
3. Draw the pattern, or enter the PIN or password to unlock the screen.

Unlock the screen with fingerprint

You can tap and hold the fingerprint sensor on the bottom of the screen or on the side of the phone depending on your models.



Note

- Set screen lock before you add the fingerprint. If you do not have fingerprint data, see [Set up a fingerprint lock](#) for more information.
- Only the finger you registered with fingerprint data can unlock the screen.
- The places of fingerprint sensors may vary in different models.

Unlock the screen with face data

When you are not convenient with fingers, you can use face unlock to unlock your phone with face identification.

Add a screen lock password before you add the face data. See [Set up a face lock](#) for more information.

1. Press the Power button to wake up the phone.
2. Look at the screen until the lock icon changes from  to .
3. Swipe up from the bottom of the screen.

Note

You keep the screen stay on when you are looking at the screen.

Adjust the volume

Press the **Volume up button** or **Volume down button** to adjust the volume.


Tip

You can also swipe down the status bar to adjust the volume bar on the Control center.

App Downloads

Download Apps from Google Play Store

Google Play Store App is pre-installed on the Home screen. You can download Apps on the phone.

1. Open  **Play Store** App.
2. Choose an App that you want to download.
3. Tap **Install** to download and install the App.

Note

You need to sign in with your Google Account. See [Sign in to your Google Account](#) for more information.

The App icon automatically shows on the Home screen when the it is downloaded.

Download Apps from other resources




When your phone allows to download Apps from other resources, you can follow the instructions of the resources. If your phone does not allow other resources to download Apps, see [Allow to install unknown Apps](#) for more information.

Caution

Download Apps from unknown or unreliable resources may damage your phone.

Allow to install unknown Apps

The feature allows the phone to download and install Apps from some Apps.

1. Go to  **Settings** >  **Privacy protection** > **Special permissions**.
2. Tap **Install unknown apps** to view all Apps.
3. Choose the App that you want to download Apps from.
4. Tap  to enable **Allow from this resource**.

Caution

Your phone and personal data are more vulnerable to attack by unknown Apps.

Apps and App folders

Downloaded Apps and pre-installed Apps are shown on the Home screen. You can manage Apps and add them to the personalized App folders.

Open an App from the Home screen

Tap an App icon on the Home screen.

Move an App on the Home screen

1. Touch and hold an App icon until the pop-up window shows.
2. Move the App to other places on the Home screen.

Remove or uninstall an App from the Home screen

1. Touch and hold an App icon until the pop-up window shows.
2. Choose **Remove** or **Uninstall** in the pop-up window.

Create App folders on the Home screen

1. Touch and hold an App icon until the pop-up window shows, then drag the App icon to cover another App icon on the Home screen.


The system automatically shows an App folder for the two Apps.

2. Release the App icon into the App folder.

Move Apps to an App folder

1. Touch and hold an App icon until the pop-up window shows, then drag the App icon to an App folder.
2. Release the App icon.

Rename an App folder


1. Tap an App folder to open the folder.
2. Tap the folder name and enter the new text.
3. Tap the screen or  to confirm the new name.

Screenshots and Screen recording

Take a screenshot in three ways





You can take a screenshot with the following three ways:

- Press the **Volume down button** and the **Power button** simultaneously to take a screenshot. See [Enable Take a screenshot shortcut](#) for more information.

- Slide three fingers down to take a screenshot. See [Enable Take a screenshot shortcut](#) for more information.
- Swipe down from the status bar to open the Control center and tap  **Screenshot** to take a screenshot.

Enable Take a screenshot shortcut

When you enable the feature, you can slide 3 fingers down on the screen or press the **Volume down button** and **Power button** simultaneously to take a screenshot.


1. Go to  **Settings** >  **Additional settings** > **Gesture shortcuts** > **Take a screenshot**.
2. Choose to enable take a screenshot shortcut.
 - Tap  to enable **Slide 3 fingers down**.
 - Tap  to enable **Volume down + Power**.

Take a partial screenshot

You can adjust the coverage and choose a shape when you take a partial screenshot on the screen.

Before you can use the feature, you need to enable the shortcut. See [Enable Partial screenshot shortcut](#) for more information.




1. Press and hold with three fingers on the screen.
2. Choose a shape at the upper-right corner of the phone.
3. Move with one finger to draw the coverage.



4. Tap **Save**.


Enable Partial screenshot shortcut

When you enable the feature, you can press and hold with 3 fingers on the screen to take a partial screenshot.

1. Go to  **Settings** >  **Additional settings** > **Gesture shortcuts** > **Partial screenshot**
2. Tap  to enable **Press and hold with 3 fingers**.

Take a scrolling screenshot

When you want to take a screenshot that contains more content, you can take a scrolling screenshot to save the content in one long screenshot.




1. Take a screenshot. See [Take a screenshot in three ways](#) for more information.
2. Tap **Scroll** on the screenshot at the upper-right corner.
3. Scroll up to determine where to end the scrolling screenshot or wait for the page goes down automatically.
4. Tap **DONE**.
5. Tap  to save the scrolling screenshot.

Note

If you want to view and save the scrolling screenshot, you need to give the **Gallery Editor** permissions to certain folders.

Record the screen

You can use the feature to record a meeting or your game performance.

1. Swipe down the status bar to open the Control center.
2. Tap  **Screen Recorder**.
3. Tap  to start recording.
4. Tap  to stop recording.

Tip

You can enable  **DND** on the Control center to prevent unexpected notifications.

Set up Screen Recorder

1. Go to  **Settings** >  **Additional settings** > **Screen Recorder**.


2. Choose to set up **Screen Recorder**.


- Tap **Resolution** to select video resolution.
- Tap **Video quality** to select video quality. Higher quality means bigger file size.
- Tap **Orientation** to select orientation of recorded videos.
- Tap **Sound source** to select system sounds, microphone, or mute.
- Tap to enable **Fixed frame rate** to enhance playback on social media platforms.
- Tap **Frame rate** to select frame rates. Higher frame rates reduce motion blur.
- Tap to enable **Lock screen to end**. End recording and save video when the screen is locked.
- Tap to enable **Show touch gestures**. Visualize gestures with a white dot.
- Tap to enable **Show button taps**. Visualize navigation button taps.

Transfer files

Transfer files with the ShareMe App

You can use the **ShareMe** App to transfer files without an internet connection.

Before the phones transfer files, you need to install  **ShareMe** on both phone A and phone B. See [App Downloads](#) for more information.

1. Open  **ShareMe** on both phones separately.
2. Tap **Receive** on phone B to receive files.

Phone B displays a QR code until it establishes a connection with phone A.

3. Tap **Send** on phone A to select file items to send.
4. Tap **SEND** on phone A to connect with phone B.
5. Choose to transfer files.
 - Use phone A to scan the QR code on phone B to connect.
 - Wait for the phone A to search for phone B, then tap the phone B name to connect.

Phone A automatically transfers the selected files to phone B after the connection is established.

Note

You can tap **Share more files** to share more files between phone A and phone B.

Transfer files with a computer

1. Connect both your phone A and phone B to a computer with an available cable separately.
2. Choose to use USB for **File Transfer/Android Auto** in the pop-up windows on both phones.
3. Select the files of phone A, and then copy and paste or drag and drop the files to folders of phone B on the computer.

Note

When you copy files from phone A to phone B, make sure that the folder names are the same on both phones.

Charging

You can charge the phone with a power adapter and USB cable. Some models also support wireless charging.

Charge the phone

When the battery is running low, you need to charge the phone.

1. Connect the USB cable to the phone.
2. Plug the cable into the adapter.
3. Connect the adapter to a power outlet.
4. Disconnect the charger when the phone is fully charged.

Caution

Make sure that the charger and the USB cable are available. To avoid severe damage and explosions, do not use unauthorized devices to charge the phone.

Wireless charging

You can charge your phone with a wireless charger.

To ensure the safety of charging, please click <https://www.mi.com/global/> to purchase a wireless charger and USB cable.

1. Plug the power adapter of the wireless charger into a power outlet and the USB cable into the wireless charger.
2. Place your phone on the center of the wireless charger with the phone screen facing up.

 **Note**

- Wireless charging may not be available to some phone models. And the support functionality may vary depending on your device.
- Charging speed may vary depending on device usage, charging conditions and other factors.

 **Tip**

Some phone models may also support reverse wireless charging. You can go to [Enable Reverse wireless charging](#) to check whether your device supports the feature.

After the wireless charger connects to your phone, the phone displays the charging status.




Chapter 3 Personalize your phone

Wallpapers and themes

Wallpaper and **Themes** enable you to personalize your phone. You can use them to change the backgrounds, font style, and other styles.

Change the wallpaper





You can change the background of your Home screen and Lock screen.

1. Open **Wallpapers** settings.
 - Open  **Themes** , then tap **Wallpapers**.
 - Go to  **Settings** >  **Wallpaper**.
2. Choose a new wallpaper such as a live image.
3. Tap **Apply**.
4. Choose **Set as Lock screen** , **Set as Home screen** , or **Set both**.
 - Tap **Set as Lock screen** to apply the wallpaper to the Lock screen.
 - Tap **Set as Home screen** to apply the wallpaper to the Home screen.

- Tap **Set both** to apply the wallpaper both to the Lock screen and Home screen.

Change the theme

You can change the wallpaper and clock on the Home screen and Lock screen, set the notification shade, Phone, Messaging and other display, and change the icons on the Home screen.

1. Open  **Themes** settings.
 - Open  **Themes**.
 - Go to  **Settings** >  **Themes**.
2. Tap **Themes** to choose a theme.
3. Tap the selected theme to view details.
4. Download the theme.
 - Tap **FREE** to download a free theme.
 - Tap **PREMIUM** to download themes that need premium.
5. Tap **APPLY**.



Note

You can also choose to apply the theme to the Lock screen, Home screen, System, or icons.

Sound & vibration



Adjust volume

You can adjust the volume of media, ringtone, and alarm when you are in quiet environment.

1. Go to  **Settings** >  **Sound & vibration**.
2. Drag the sliders to adjust the **Media** , **Ringtone** , **Alarm** volume separately.

Change the ringtones of Notifications, Ringtone, and Alarm

You can customize your ringtones of Notifications, Ringtone, and Alarm sound. You can set the preset sounds or add the sound from local files or online ringtones.

1. Go to  **Settings** >  **Sound & vibration**.
2. Tap **Notifications** , **Ringtone** , or **Alarm** to enter the **Ringtones** page.




3. Tap a ringtone to hear a preview and select it.

Tip

You can also tap **Choose local ringtone** to set ringtones from local files.




Adjust media sound in multiple Apps

You can adjust sound for individual Apps while multiple Apps play audio simultaneously.


1. Go to  **Settings** >  **Sound & vibration** > **Sound assistant**.
2. Tap  to enable **Adjust media sound in multiple apps**.

Enable Silent mode

The feature allows the phone to silence calls and notifications.




1. Go to  **Settings** >  **Sound & vibration**.
2. Tap  to enable **Silent mode**.

Tip

You can also swipe down from the upper-right corner of the phone to enable  **Mute** in Control center.




Enable Do not disturb

With the mode enabled, there are no reminders for incoming calls and notifications.

1. Go to  **Settings** >  **Sound & vibration**.
2. Tap **Do not disturb**, then tap  to enable **Do not disturb**.

Enable Haptic feedback

You can receive tactile response to gestures and system controls.

1. Go to  **Settings** >  **Sound & vibration**.
2. Tap  to enable Haptic feedback.



Note

You can drag the slider below to adjust the haptic feedback level.

Display




Select Light mode or Dark mode

Light mode adjusts the phone to fit in strong-light environments. Dark Mode applies a dark color scheme to the phone to fit in low-light environments.

1. Go to  **Settings** >  **Display**.
2. Select **Light mode** or **Dark mode** to apply to the system.




Schedule Dark mode

You can schedule Dark mode to turn on at night.

1. Go to  **Settings** >  **Display** > **Schedule Dark mode**.
2. Tap  to enable **Schedule Dark mode**.
3. Choose **Sunset to sunrise** or **Custom**.
 - Tap **Sunset to sunrise**. Dark mode applies to your phone at sunset and is turned off at sunrise.
 - Tap **Custom**. You can turn Dark mode on and off at scheduled time.

Enable Automatic brightness


The phone automatically adjusts the brightness when in different light conditions.

1. Go to  **Settings** >  **Display** > **Brightness level**.
2. Tap  to enable **Automatic brightness**.

Note

Screen brightness is optimized according to ambient light. You can still make minor adjustments manually.

Tip

You can also swipe down from the upper-right corner of the phone to enable  **Auto brightness** on the Control center.

Adjust screen brightness level manually


You can adjust the brightness level to make the phone dimmer or brighter.

1. Go to  **Settings** >  **Display** > **Brightness level**.

2. Drag the slider of **Screen brightness** to adjust the screen brightness manually.



Tip

You can also swipe down from the upper-right corner of the phone to drag the slider in the brightness level bar on the Control center.






Choose a color scheme

You can adjust the color of the screen.

1. Go to  **Settings** >  **Display** > **Color scheme**.
2. Select a color scheme from **Vivid** , **Saturated** , **Original color** , or **Advanced settings** for more color scheme options.

Enable Adaptive colors

Adaptive colors adjust colors to ambient light.



1. Go to  **Settings** >  **Display** > **Color scheme**.
2. Tap  to enable **Adaptive colors**.

Note

You can adjust the color temperature in **COLOR TEMPERATURE**.

Choose a refresh rate

You can change the refresh rate to get a high-performance gaming experience.



1. Go to  **Settings** >  **Display** > **Refresh rate**.
2. Choose **Default** or **Custom**.
 - Tap **Default** to adjust fresh rate dynamically based on scenarios to balance performance with power consumption.
 - Tap **Custom** to select a refresh rate.

Note

Higher refresh rate makes viewing experience smoother but consumes more power.



Change the font

You can change the font and style on your phone.

1. Go to  **Settings** >  **Display** > **Font**.
2. Choose a font in the **Fonts** page.
3. Download and apply the font.




Change the text size

You can change the text size to fit your eyes.


1. Go to  **Settings** >  **Display** > **Text size**.
2. Drag the slider from **xxs** to **XXL** to change the text size.

Enable Auto-rotate screen

The phone automatically rotates the screen between portrait and landscape position when you rotate the phone.

1. Go to  **Settings** >  **Display**.
2. Tap  to enable **Auto-rotate screen**.




Tip

If you want to lock the screen orientation, you can disable the **Auto-rotate screen** or swipe down from the upper-right corner of the phone to enable  **Lock orientation** on the Control center.

Always-on display & Lock screen

Enable Always-on display



Always-on display enables items, such as signature, analog, kaleidoscope, digital, or background to be shown when the screen is locked.

1. Go to  **Settings** >  **Always-on display & Lock screen** > **Always-on display**.
2. Tap  to enable **Always-on display**.


Set the time for Display items

You can set when to display Always-on display items.

You need to enable Always-on display first. See [Enable Always-on display](#) for more information.



1. Go to  **Settings** >  **Always-on display & Lock screen** > **Always-on display** > **Display items**.
2. Choose **For 10 seconds after tapping**, **Always**, or **Scheduled**.

Tip

You can tap  to enable **Turn off when Battery saver is on** to reduce power consumption.



Customize always-on display

You can customize the themes and colors for displayed items or apply the **Signature**, **Analog**, **Kaleidoscope**, **Digital**, or **Select background** display to the always-on display.

1. Go to  **Settings** >  **Always-on display & Lock screen** > **Always-on display**.
2. Tap the corresponding items such as **Signature**, **Analog**, or **Kaleidoscope** to customize the themes, colors, and other settings for displayed items.
3. Tap **Apply** to apply the customized displayed items.

Set screen sleep time




Set sleep time to lock the screen automatically.

1. Go to  **Settings** >  **Always-on display & Lock screen** > **Sleep**.
2. Choose an inactivity interval.

The screen locks if you do not wake up the phone in the interval.

Raise to wake

When you raise the phone, the screen wakes up.

1. Go to  **Settings** >  **Always-on display & Lock screen**.
2. Tap  to enable **Raise to wake**.

Double tap to wake or turn off screen when device is locked

You can double tap to turn the screen off only when pre-installed themes are applied.

1. Go to  **Settings** >  **Always-on display & Lock screen**.

2. Tap to enable **Double tap to wake or turn off screen when device is locked**.

Set Lock screen clock format

1. Go to **Settings > Always-on display & Lock screen > Lock screen clock format**.
2. Choose a Lock screen clock layout.

Note

- You cannot change the format when **Dual clock** is on.
- You cannot change the Lock screen layout for the third party themes.

Display charging animation after device is unlocked


Charging animation keeps displaying after your phone is unlocked except for video playback and other similar full screen scenes.

1. Go to **Settings > Always-on display & Lock screen**.
2. Tap to enable **Display charging animation after device is unlocked**.

Home screen

Change the size of App folder

You can personalize the Home screen with different sizes of App folders.






1. Touch and hold an App folder on the Home screen until the pop-up window shows.
2. Tap **Edit folder** to view the available sizes.
3. Choose **Regular** or **Enlarged**.
4. Tap ✓.

Don't show text below App icons

Do not show text below the App icons on the Home screen.


1. Go to Home screen settings.

- Go to  **Settings** >  **Home screen**.
- Pinch on the Home screen or touch and hold an empty space on the Home screen to enter the screen editing mode. Then tap  to set Home screen layout.

2. Tap  to enable **Don't show text**.

Set App display on Home screen

You can choose not to display Apps or display the used Apps in the App drawer or display bigger UI elements.



1. Go to  **Settings** >  **Home screen**.

2. Tap **Home screen** to choose App display on Home screen.



- Tap **Classic** to not to display Apps.
- Tap **With App drawer** to display the used Apps in the drawer when you swipe up on Home screen.
- Tap **Lite mode** to apply bigger UI elements, more accessible calling, and enhanced security.

Note

To turn off **Lite mode**, you go to  **Settings** and tap the place under the search bar.



Set animation speed

You can select the responsive speed of animation.

1. Go to  **Settings** >  **Home screen**.
2. Tap **Animation speed** to choose **Relaxed** , **Balanced** , or **Fast**.



Set system navigation buttons

You can interact with your phone with system navigation buttons.



1. Go to  **Settings** >  **Home screen**.
2. Tap **System navigation** to select system navigation methods.
3. Choose **Buttons** to use system navigation buttons. See [System navigation buttons](#) for more information.

Set full screen gestures

You can interact with your phone with full screen gestures to quickly navigate, multitask, and access features.



1. Go to  **Settings** >  **Home screen**.
2. Tap **System navigation** to select system navigation methods.
3. Choose **Gestures** to use full screen gestures. See [Full screen gestures](#) for more information.

Note

- You can tap  to enable **Hide full screen indicator** when you use full screen gestures.
- You can tap  to enable **Gesture confirmation**.



Adjust the icon size

You can change the size of icons based on your needs.

1. Go to  **Settings** >  **Home screen** > **Icon size**.
2. Drag the slider to adjust the icon size.

Set Home screen layout

You can choose to show the App icon numbers on one Home screen page.

1. Go to  **Settings** >  **Home screen**.
2. Tap **Home screen layout** to select 4x6 or 5x6 Home screen layout.


Enable Global icon animations



The feature allows the phone to render animations on third party App icons.

1. Go to  **Settings** >  **Home screen**.
2. Tap  to enable **Global icon animations**.

Arrange items in Recents




You can set the Recents display layout.



1. Go to  **Settings** >  **Home screen**.
2. Tap **Arrange items in Recents** to select **Vertically** or **Horizontally**.

Show memory status


After you enable the feature, when you open recently-opened Apps in **Recents**, you can check the memory status at the upper-right corner of the phone.



1. Go to  **Settings** >  **Home screen**.
2. Tap  to enable **Show memory status**.

Notifications & Control center

Enable Lock screen notifications

Allow the App notifications to show on the Lock screen.




1. Go to  **Settings** >  **Notifications & Control center**.
2. Tap **Lock screen** in **NOTIFICATIONS**.
3. Tap beside an App to enable Lock screen notifications.



 **Tip**

You can tap **Format** to choose **Show notification and content** or **Don't show Lock screen notifications**.

Enable Floating notifications



Allow the App notifications to show on the floating notification banners.



1. Go to  **Settings** >  **Notifications & Control center**.
2. Tap **Floating notifications** in **NOTIFICATIONS**.
3. Tap beside an App to enable Floating notifications.


Hide floating notifications

You can swipe up on a floating notification to temporarily hide upcoming ones.

1. Go to  **Settings** >  **Notifications & Control center**.
2. Tap **Floating notifications** in **NOTIFICATIONS**.
3. Tap beside an App to enable Floating notifications.
4. Tap **Hide temporarily** to set hide time for floating notifications.

Enable App notification badges

Allow the App notification numbers to show on the badges. A notification badge is a red circle with a number in it. The number shows how many notifications you receive.



1. Go to **Settings** > **Notifications & Control center**.
2. Tap **Badges** in **NOTIFICATIONS**.
3. Tap beside an App to enable the notification badges.

Choose Control center style




You can choose to use the old version or new version Control center style.





1. Go to **Settings** > **Notifications & Control center** > **Control center style**.
2. Choose a Control center style.
 - Choose to tap **Old version**. You can pull down Status bar to view toggles and notifications
 - Choose to tap **New version**. You can pull down status bar on the left to view notifications and you can pull down Status bar on the right to open Control center.

Items shown on the Lock screen after swiping down

You can swipe down the notification panel on the Lock screen. If you use the new version of Control center, you can also swipe down the Control center on the right part of the Lock screen and set the Smart home.




1. Go to  **Settings** >  **Notifications & Control center** > **Items shown on the Lock screen after swiping down**.
2. Tap  to enable **Notification shade**.

Note



If you use the new version of Control center, you can tap  to enable **Control center** and tap  to enable **Smart home**.


Show notification icons

Show notification icons on the Status bar.

1. Go to  **Settings** >  **Notifications & Control center** > **Status bar**.
2. Tap  to enable **Show notification icons**.

Choose Battery indicator




1. Go to  **Settings** >  **Notifications & Control center** > **Status bar** > **Battery indicator**.
2. Choose one battery indicator style to apply.



Date and time

Change the date and time

The date and time are set automatically over the network based on your location. You can adjust the date and time manually.

1. Go to  **Settings** >  **Additional settings** > **Date & time**.
2. Tap  to disable **Set time automatically**.
3. Tap **Date** or **Time** to change the date or time.




4. Tap **OK**.

Note

On some models, the UI names for the feature may vary. The UI name can be **Set time automatically** or **Use network-provided time** depending on your device.




Set time automatically

The phone adjusts time automatically with the network.

1. Go to  **Settings** >  **Additional settings** > **Date & time**.
2. Tap  to enable **Set time automatically** or **Use network-provided time** based on your models.

Set time zone automatically

Use the time provided by the carrier network.




1. Go to  **Settings** >  **Additional settings** > **Date & time**.
2. Tap  to enable **Set time zone automatically** or **Use network-provided time zone** based on your models.

Note

If you disable the feature, you can select time zone according to your region.

Use location to set time zone



The automatic time zone is off and you can use your location to set time zone.

1. Go to  **Settings** >  **Additional settings** > **Date & time**.
2. Tap  to enable **Use location to set time zone**.

Note




The feature may not be available to some models.

Choose time format

1. Go to  **Settings** >  **Additional settings** > **Date & time** > **Time format**.
2. Choose **12-hour 1:00 PM** , **24-hour 13:00** , or **Auto (based on system language)**.

Enable Dual clock

The phone shows Dual clock when current time is different from that on the second clock.

1. Go to  **Settings** >  **Additional settings** > **Date & time**.
2. Tap  to enable **Dual clock**.



 **Note**

- You can tap **Second clock** to choose the region or time zone of the second clock.
- Dual clock is displayed on the Lock screen, Home screen, and turned off screen.

Languages and regions

You can change the languages and regions when you are in travel or move.

Set the language

1. Go to  **Settings** >  **Additional settings** > **Languages & input** > **Languages**.
2. Choose and set the language from language list.

Set the region

1. Go to  **Settings** >  **Additional settings** > **Region**.
2. Choose and set the region from region list.

Chapter 4 Battery and maintenance

The phone allows you to check the battery health and manage the usage and maintenance of the battery. You can go to battery settings with two methods:

- Go to  **Settings** >  **Battery**.
- Go to  **Security** >  **Battery**.

 **Note**

The battery features may not be available to some models.

View battery capacity

The feature enables you to check the remaining use time and battery capacity.

1. Go to battery settings. See [Go to battery settings](#) for more information.
2. Open **Battery saver** page.
3. View the battery capacity.

Tip

When your phone is charged, you can view the remaining fully charging time and charged battery capacity.

Enable Battery saver


Use Battery saver mode to save power. It can reduce background activity of Apps, stop sync, and minimize system animations.

1. Go to battery settings. See [Go to battery settings](#) for more information.
2. Open **Battery saver** page.
3. Tap **Save battery** on the slider.

Note


You can also choose **Balanced** or **Performance** mode. **Balanced** mode is recommended for normal use. **Performance** mode increases phone performance, but consumes more power.

Tip


You can also swipe down from the upper-right corner of the phone to enable  **Battery saver** on the Control center.

Enable Ultra battery saver

Use Ultra battery saver to save power when the phone is in low battery. It restricts most power consuming features. Only calls, messages, and network connectivity are not affected.

1. Go to battery settings. See [Go to battery settings](#) for more information.
2. Open **Battery saver** page.
3. Tap  to enable **Ultra battery saver**.

Tip

You can also swipe down from the upper-right corner of the phone to enable  **Ultra battery saver** on the Control center.

Fix the battery usage issues

When you enter battery settings, the phone scans the battery usage issues automatically. You can choose to check and fix the battery usage issues.

1. Go to battery settings. See [Go to battery settings](#) for more information.
2. Open **Battery saver** page.
3. Tap **Fix 1 battery usage issue**.

The phone starts fixing the issues.

Note

You may have no or more battery usage issues to fix or optimize in real situations. The suggestions may be on battery usage issues or battery optimizations.

View power consumption in detail

You can check the battery usage tendency and the consuming power percentage of the Apps.

1. Go to battery settings. See [Go to battery settings](#) for more information.
2. Open **Battery saver** page.
3. Tap the line chart and view the power consumption in detail below.


View the battery temperature

You can check the battery temperature on current time and how many time you have charged today.

1. Go to battery settings. See [Go to battery settings](#) for more information.
2. Tap **Battery** or swipe left to enter **Battery** page.
3. View the temperature and charged times.

Enable Reverse wireless charging

You can charge other devices that support the wireless charging when you are in urgent circumstances.

1. Go to battery settings. See [Go to battery settings](#) for more information.
2. Tap **Battery** or swipe left to enter **Battery** page.
3. Tap **Reverse wireless charging**.
4. Tap  to enable **Reverse wireless charging**.


Tip

You can drag the slider of **Charging limit** to set the battery capacity. When the battery reaches the charging limit, the phone stops reverse wireless charging.

Note

The feature may not be available to your models.

You can now place other phones or wearable devices with Qi wireless charging functionality on the back center of your phone.



Chapter 5 Networks and connection


SIM cards & mobile networks

Connect to mobile data

The phone needs a SIM card to connect to the mobile network. You can surf the internet with the available SIM cards.




1. Go to  **Settings** >  **SIM cards & mobile networks**.
2. Tap  to enable **Mobile data**.

Tip

You can swipe down the Status bar and tap  **Mobile data** to enable mobile data on the **Control center**.

Stop using a SIM card

You cannot receive calls or use the mobile network with the SIM card.

1. Go to  **Settings** >  **SIM cards & mobile networks**.
2. Tap a phone number to set SIM card.
3. Tap  to stop **Turn on**.


Note

Only when the phone is inserted with two SIM cards, you can disable one SIM card.

Set a default data SIM

Select a default SIM card for mobile data usage.

1. Go to  **Settings** >  **SIM cards & mobile networks**.
2. Tap the number of a SIM card in **Data SIM**.





Set a default call SIM

Select a default SIM card for calling.



1. Go to  **Settings** >  **SIM cards & mobile networks**.
2. Tap the number of a SIM card in **Default for calls**.



Edit SIM card name or SIM card number

1. Go to  **Settings** >  **SIM cards & mobile networks**.
2. Tap a phone number to set SIM card.
3. Tap **Edit SIM card name** or **Edit SIM card number** to change the name or the number.
4. Tap **OK**.

Manage advanced settings

1. Go to  **Settings** >  **SIM cards & mobile networks** > **Advanced settings**.
2. Manage advanced settings.
 - **Use mobile data during VoLTE calls on the secondary SIM:** During VoLTE calls, the phone connects to a mobile data network with the secondary SIM. But you can set the feature when you insert two SIM cards.
 - **Data roaming:** When roaming, you can connect to data services.

Use an eSIM card




eSIM card is a virtual SIM card that occupies no space on the SIM card slot. The function of an eSIM card is similar to a physical SIM card. You can also make calls, send messages, and use mobile data.

Note

- eSIM card may not be available on some phone models.
- eSIM card is only available in some countries and regions.
- eSIM card may vary depending on your carrier.

Apply for an eSIM card

You need to contact your carrier to apply for an eSIM card.

A customer service representative may ask you for the embedded-SIM ID (EID) information when you apply for an eSIM card. You can go to  **Settings** >  **SIM cards & mobile networks** to enable **Use eSIM**, then go to **Manage eSIM** >  > **View device EID** to view the information.

Note

You can apply for multiple eSIM cards, but some phone models only support one eSIM card in use at a time.

Add an eSIM card from Setup Wizard

1. Start **Setup Wizard** when you open the phone for the first time.

After you set up the region that supports eSIM cards in the Setup Wizard, the phone checks SIM cards and eSIM cards automatically.

2. Tap **Activate eSIM** after the phone detects SIM cards.
3. Connect to a Wi-Fi network to check eSIM cards.
4. Tap **Add mobile plan** to choose to add a mobile plan.

- Scan the QR code provided by your carrier.
- Scan the image from **Gallery**. When you are not convenient with your camera, you can save the QR code provided by the carrier as an image. And then tap **Gallery** to choose the image for scan.
- Tap **Add manually instead** below the scanner to use activation code provided by your carrier.

5. Follow the onscreen instructions to add and activate an eSIM card.

Note

If two SIM cards are detected, the eSIM card activation process in Setup Wizard will be skipped. You can set up later in **Settings**. See [Add an eSIM card from Settings](#) for more information.

Add an eSIM card from Settings

1. Go to **Settings** > **SIM cards & mobile networks**.
2. Tap to enable **Use eSIM** and tap **OK**.
3. Tap **Manage eSIM**.
4. Tap **Add mobile plan** to choose to add a mobile plan. See [Choose to add a mobile plan](#) for more information.
5. Follow the onscreen instructions to add and activate an eSIM card.

Note

- You can tap **Discover mobile plans** to find mobile plans.
- eSIM card and SIM 2 cannot be used at the same time. If you insert dual SIM cards or SIM 2 on your phone, eSIM card cannot be activated. To use eSIM card, you need to disable SIM 2 and switch to eSIM card.

Enable Use eSIM

Enable the feature if you want to use the eSIM again. If you want to use SIM 2, you can disable **Use eSIM**.

1. Go to **Settings** > **SIM cards & mobile networks**.
2. Tap to enable **Use eSIM** and tap **OK**.

Disable, name, or delete an eSIM card

1. Go to **Settings** > **SIM cards & mobile networks**.
2. Tap to enable **Use eSIM** and tap **OK**.
3. Tap **Manage eSIM**.
4. Choose to disable, name, or delete an eSIM card.
 - **Disable mobile plan:** If you want to use other eSIM cards, you can disable the current eSIM card.





- **Change nickname:** You can change a new name for the eSIM card.
- **Delete mobile plan:** If you delete the eSIM card, you will permanently delete XIAOMI PROFILE from the phone. The eSIM card will not be restored and displayed in the eSIM list.

 **Note**

- **Delete an eSIM card** does not cancel any mobile data plans you have purchased from a carrier.
- Disable an eSIM card before you delete it.

Reset eSIM cards



If you reset eSIM cards, all of your mobile plans will be permanently removed from the device.

1. Go to  **Settings** >  **SIM cards & mobile networks**.
2. Tap  to enable **Use eSIM** and tap **OK**.
3. Go to **Manage eSIM** >  > **Reset eSIM**.
4. Tap **Reset**.

 **Note**

But resetting eSIM cards does not cancel any data plans you have purchased from a carrier.

Wi-Fi




You can go to  **Settings** >  **Wi-Fi** to connect to a Wi-Fi network. See [Connect to Wi-Fi](#) for more information.

 **Note**

Available networks show up when you enable **Wi-Fi**.

Disconnect a Wi-Fi network

If you want to switch to a new network, you can disconnect a connected Wi-Fi network.





1. Go to  **Settings** >  **Wi-Fi**.
2. Tap  to view the connected Wi-Fi network details.
3. Tap **Forget network**.

4. Tap **OK**.

Your device stops connecting to the network automatically. You may need to enter the password when you connect to the network again.




Connect to a hidden Wi-Fi network

Hidden networks do not broadcast their names. If you want to connect to it, you need to enter the information manually. You can ask the network administrator for the name and password before you begin.

1. Go to  **Settings** >  **Wi-Fi**.
2. Tap  to enable **Wi-Fi**.
3. Tap **Add network** at the bottom of the Wi-Fi network list.
4. Enter the information about the Wi-Fi network.
 - **Network name:** Type the name of the network.
 - **Security:** Select a security option from the list, and enter the password if required.
 - **Privacy:** Select a media access control address (MAC address).
 - **Hidden network:** Select whether the network is hidden.
5. Tap .

Manage network acceleration



You can use the features to optimize connection and accelerate network.

1. Go to  **Settings** >  **Wi-Fi** > **Network acceleration**.
2. Choose to manage network acceleration.
 - Tap **Dual band Wi-Fi speed boost** to boost Wi-Fi speed by connecting to auxiliary networks.
 - Tap  to enable **Use mobile data to boost speed**. The feature allows the device to use mobile data to boost connection speed. Use the feature may generate additional carrier fees.

Note

The features may not be available to some models. And the feature paths on different models may vary.

Manage advanced settings

1. Go to  **Settings** >  **Wi-Fi** > **Additional settings**.
2. Manage advanced settings.
 - **Manage saved networks:** Delete the saved networks.
 - **Install certificates:** Install Wi-Fi certificates from local files.
 - **Wi-Fi Direct:** Wi-Fi Direct enables the phone to connect other Wi-Fi Direct devices at anywhere and anytime, even when there is no access to a Wi-Fi network nearby.

Chapter 6 Connection and sharing




Bluetooth

You can connect your phone with earphones, speakers, and other devices with Bluetooth functionality. You can also use Bluetooth to share data between your phone and other devices.

Pair a Bluetooth device

You can connect to compatible Bluetooth devices. For example, you can connect phones, wireless Bluetooth earphones, and wearable devices.

The following steps take the connection between Xiaomi phones as an example.


1. Go to  **Settings** >  **Bluetooth**.
2. Tap  to enable **Bluetooth** on both devices.

Available devices show up when you enable **Bluetooth**.
3. Tap the name of phone B in phone A.
4. Tap **Pair** in the pop up windows of the two devices.




Note

- In the pop up windows, you can also choose to block the Bluetooth device if you do not want to connect to the device.
- The two devices need to enable **Bluetooth** and stay in an effective distance. The phone searches for devices automatically, then you can see the names of available devices.


Tip

You can also swipe down from the upper-right corner of the phone to enable  **Bluetooth** on the Control center.

Unpair a Bluetooth Device




1. Go to  **Settings** >  **Bluetooth**.
2. Tap  to enable **Bluetooth**.

The saved Bluetooth names show up below the **Bluetooth version**.



3. Tap to  view the paired Bluetooth device details.
4. Tap **Unpair**.

Rename a device

When you enable Bluetooth, other nearby devices can see the name.

1. Go to  **Settings** >  **Bluetooth** > **Device name**.
2. Enter the device name.
3. Tap .

Manage advanced settings

1. Go to  **Settings** >  **Bluetooth** > **Additional settings**.
2. Manage advanced settings.
 - **Pair compatible devices:** You can quickly connect to earphones, speakers, and other compatible devices.
 - **Bluetooth blacklist:** View the blocked Bluetooth devices.
 - **Show Bluetooth devices without names:** The names of the Bluetooth devices are not displayed and only the MAC addresses are displayed.


Portable hotspot

Enable Portable hotspot

Turn on the Portable hotspot and your phone can provide an internet access to other devices.




1. Go to  **Settings** >  **Connection & sharing** > **Portable hotspot**.
2. Tap  to enable **Portable hotspot**.

Tip

- You can tap **Share QR code** to share Wi-Fi network.
- You can swipe down from the upper-right corner of the phone to enable  **Hotspot** on the Control center.




Turn off hotspot automatically

The feature helps save mobile data.

1. Go to  **Settings** >  **Connection & sharing** > **Portable hotspot**.
2. Tap  to enable **Turn off hotspot automatically**.

Change the name and password of portable hotspot




You can change the portable hotspot name and password to secure your privacy or data usage.

1. Go to  **Settings** >  **Connection & sharing** > **Portable hotspot**.
2. Tap **Set up portable hotspot** to change the portable hotspot name or password.
3. Tap .

Connection & sharing

Enable Mi Share


Mi Share allows you to send items wirelessly to other nearby devices.

1. Go to  **Settings** >  **Connection & sharing** > **Mi Share**.
2. Tap  to enable **Mi Share**.

Note




If you share items with other phones, make sure that both of the phones turn on **Mi Share**. You can check the list of supported devices on the official website of any selected brand.

Tip

You can also swipe down from the upper-right corner of the phone to enable  **Mi Share** on the Control center.

Turn on Mi Share automatically

Mi Share is turned back on automatically when Bluetooth or Wi-Fi is turned back on.




1. Go to  **Settings** >  **Connection & sharing** > **Mi Share**.
2. Tap  to enable **Turn on Mi Share automatically**.

Enable Cast




You can enable **Cast** to project the items from your phone screen on a bigger external monitor.

Note

You need to turn off **Portable hotspot** before you enable **Cast**.

1. Go to  **Settings** >  **Connection & sharing** > **Cast**.
2. Tap  to enable **Cast**.
3. Select an available device to start casting.

Tip




- You can go to  **Settings** >  **Connection & sharing** > **Cast** > **Help** to learn casting information.
- You can also swipe down from the upper-right corner of the phone, then tap  to enable **Cast** on the Control center.

Add VPN

A Virtual Private Network (VPN) enables you to send and receive data across shared or public networks. A VPN encrypts the connection between the device and the internet and it can increase the functionality, security, and management of the private network.




Note

You need to set a screen lock to save your VPN settings. See [Set up Screen lock](#) for more information.

1. Go to  **Settings** >  **Connection & sharing** > **VPN**.
2. Tap **Add VPN** at the bottom of the screen.
3. Enter the corresponding information such as **Name** , **Type** , **Server address** , **IPSec identifier** , **IPSec CA certificate** , **IPSec server certificate** , **Username** , and **Password** of the VPN.
4. Tap  to save the VPN.

Enable VPN




You need to set a screen lock to save your **VPN** settings. See [Set up Screen lock](#) for more information.

1. Go to  **Settings** >  **Connection & sharing** > **VPN**.
2. Tap  to enable **VPN**.
3. Choose a VPN to connect.

Note

If you connect a **VPN** successfully, you can see that the **VPN** icon shows at the upper-right corner of the phone.


Enable Airplane mode

1. Go to  **Settings** >  **Connection & sharing**.
2. Tap  to enable **Aeroplane mode**.

Note




On some models, the UI names for the feature can be **Aeroplane mode** or **Airplane mode**.

Tip

You can also swipe down from the upper-right corner of the phone to enable  **Aeroplane mode** on the **Control center**.

Enable NFC


Near Field Communication (**NFC**) is a short-range wireless connectivity technology. It supports data exchange or mobile payment when the phone touches other compatible devices or brought within a few centimeters of each other. You can place your device near a contactless terminal to use Mi Pay, transport cards, key cards, and other NFC features.

1. Go to  **Settings** >  **Connection & sharing**.
2. Tap  to enable **NFC**.

Note

- NFC may not be available to your models.
- The feature may vary depending on your carrier.




Tip

You can also swipe down from the upper-right corner of the phone to enable  **NFC** on the **Control center**.

Make payment with NFC

You can use NFC payment App to make payment by touching your device to a compatible credit card reader.

You need to install a payment App on your device, add a credit card, and enable the payment service first.

1. Go to  **Settings** >  **Connection & sharing**.
2. Tap  to enable **NFC**.
3. Tap **Secure element position** to select **HCE Wallet**.
4. Go to **Contactless payments** > **Payment default** to select a default payment App where the payment service is enabled.


Note

HCE Wallet: The **HCE**, namely **Host Card Emulation**, is the technology used to emulate a credit or debit card on the phone. Only mobile payment with the **HCE** option works on Xiaomi phones.

Chapter 7 Phone and Messages




Phone

Phone App helps you connect with family and friends. You can make calls and save the contacts.




Make a Call



Make a call with Dialpad

1. Tap  **Phone**.
2. Tap  to open the **Dialpad**.
3. Enter the phone number.
4. Tap  to make a call.



Make a call from Favorites

1. Go to  **Phone** > **Favorites**.
2. Select a favorite contact to make a call.

Make a call from Recents

1. Go to  **Phone** > **Recents**.
2. Choose a contact and tap  to make a call.


Make a call from Contacts list

1. Go to  **Phone** > **Contacts**.
2. Choose a contact.
3. Tap the contact to view details.
4. Tap  or the phone number to make a call.


Make video calls

You can make video calls from **Dialpad** , or **Recents** and **Contacts** tabs.


- On **Dialpad** , after you enter the phone number, you can tap **Video call** to make a video call.



- On **Recents** tab, you can tap the phone number of a recent contact, then tap **Video call** to make a video call.



- On **Contacts** tab, Choose a contact and tap **Video call** to make a video call.



Note

- You need to sign in to your Google account to use the feature.
- Not all devices support video calling. The receiver has the option to accept the video call or answer the call as a regular voice call.

Answer a call

Swipe up  to answer a call.


Silence a call

Press the **Volume up button** or **Volume down button** when the phone rings.

Decline a call


Swipe down  until  shows to decline a call.

Manage the call while on calling




Mute	Mute the call
Keypad	Enter numbers during a call
Speaker	Open the speaker to make voice loud
Add call	Add calls to the contact list
Hold	Put the current call on hold


Add a contact to Favorites

1. Go to  **Phone** > **Favorites**.
2. Tap **Add a favorite** and choose a contact to **Favorites**.

View recent calls

1. Go to  **Phone** > **Recents**.
2. Swipe up to view more recent calls.



Create a contact

1. Go to  **Phone** > **Contacts**.
2. Tap **Create new contact**.
3. Choose to save the contact to the device, Google account, or SIM cards.




4. Enter the information such as the name, the organization, and the phone number of a contact.
5. Tap **Save**.

View call history

You can view all incoming calls, outgoing calls, and missed calls.


1. Tap  **Phone**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Call history**.


Manage Phone call settings

1. Tap  **Phone**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Settings** to view all phone settings.
4. Manage Phone call settings.
 - **Caller ID & spam:** You can set the Caller ID and spam ID to identify business calls and prevent suspected spam calls.
 - **Accessibility:** Accessibility includes TTY mode feature. TTY mode is an abbreviation that refers to all types of teletypewriters. TTY mode helps people who are hearing impaired or have difficulty in speaking.
 - **Assisted dialing:** Assisted dialing predicts and adds a country code when you make a call abroad.
 - **Blocked numbers:** You do not receive calls or texts from blocked numbers.
 - **Calling accounts:** You can manage the calling accounts, call forwarding, call waiting, and incoming call settings.
 - **Display options:** You can set the display of contacts and phone themes.
 - **Nearby places :** When you search from  **Phone**, the feature needs your location to find nearby places that match your query, even if they are not in your contacts.
 - **Quick responses:** You can set to show buttons for ending call and sending SMS.

- **Sounds and vibration:** You can change the ringtone for calls and adjust the volume.
- **Voicemail:** You can set the notifications and number of voicemail.
- **Caller ID announcement:** The caller's name and number are read out loudly for the incoming calls.
- **Flip To Silence:** You can place your phone face down on a flat surface to silence the incoming call.

Messages


You can use  **Messages** to send and receive texts, photos, videos, and audio messages. You can also share GIFs, stickers, locations, contacts, and files with others.



1. Add attachment	2. Touch and hold to record voice message	3. Add emojis
-------------------	---	---------------

Send a message

You can send a text message to a contact to start a conversation.

1. Open  **Messages**.
2. Tap **Start chat** to start a new conversation.
3. Choose a contact to send a message.



Note

When you insert two SIM cards, you can choose one SIM card to send the message.




Send MMS messages to a group

Multimedia Messaging Service (MMS) enables you to send a message with multimedia content to a group of contacts. The multimedia includes pictures, audio, phone contacts, and videos.



1. Open  **Messages**.
2. Tap **Start chat** to start a new conversation.
3. Tap **Create group** and add one or more contacts to the new MMS group.
4. Tap **Next** at the upper-right corner of the phone.
5. Enter a group name, then tap **Next** to create the group.
6. Tap the text field to text an MMS message or tap the attachment icons to add multimedia content.
7. Tap .

View a message

1. Open  **Messages**.
2. Select a message.
3. Tap the message to view your conversation.

Reply to a message



When you receive a message from others, you can text a message to reply to. The messages are shown in one conversation.

1. Open  **Messages**.
2. Tap a message that you want to reply in the messages list.
3. Tap the text field to text a message.
4. Tap  to send the message.

Pin a conversation



You can pin a conversation to the top of the messages list. The feature helps contact the person conveniently.

You can pin up to 5 messages.

1. Open  **Messages**.
2. Touch and hold a conversation.
3. Tap .

Archive a conversation

You can archive conversations to the archived folder.



1. Open  **Messages**.
2. Touch and hold a conversation.
3. Tap .

Tip

You can also swipe a conversation left or right to archive the conversation.




Add contact from a message

When you receive a message from a person you know, you can add the sender to your contact list.

1. Open  **Messages**.
2. Touch and hold a conversation.
3. Tap  at the upper-right corner of the phone.
4. Tap **Add contact** and add name or other information.



Mute notifications from a message sender

You do not receive notifications from the message sender on the notification panel.

1. Open  **Messages**.
2. Touch and hold a conversation.
3. Tap  at the upper-right corner of the phone.
4. Tap **Mute notifications**.
5. Tap  to disable **Show notifications**.

Block a spam or conversation



You can block unwanted and junk messages and filter messages from unknown senders.

1. Open  **Messages**.
2. Touch and hold a conversation.
3. Tap  at the upper-right corner of the phone.
4. Tap **Block**.
5. Tap **OK**.

Note



The spam or conversation is moved to **Spam & blocked**.

Pair a device



1. Open  **Messages**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Device pairing**.
4. Tap **QR code scanner**.
5. Scan the QR code shown on messages.google.com/web.

Choose a theme

You can adjust the appearance in different environment. For example, Dark theme is suitable for night.


1. Open  **Messages**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Choose theme**.
4. Select **Light** , **Dark** , or **System default** theme.
5. Tap **OK**.

View an archived conversation

1. Open  **Messages**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Archived**.
4. Tap a conversation to view details.

View a spam or blocked conversation



1. Open  **Messages**.

2. Tap  at the upper-right corner of the phone.
3. Tap **Spam & blocked**.
4. Tap a spam or blocked conversation to view details.

 **Note**

You can tap **Unblock** to unblock the conversation.


Manage Messages settings

1. Open  **Messages**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Settings** to view all message settings.
4. Manage Messages settings.
 - **Notifications:** You can choose to show notification indicators or allow sound when you receive messages.
 - **Hear outgoing message sounds :** When you send an SMS or MMS message through the **Messages** App, a signal sounds serves as a confirmation.
 - **Automatic previews:** The feature works with your message data while keeping your messages private.
 - **Spam protection:** The feature can prevent spam messages to protect your data.

Chapter 8 Camera

Camera overview

You can get a full view of the Camera layout.



1. Flash	2. HDR	3. Leica photographic styles
4. Viewfinder	5. Zoom levels	6. Gallery
7. Shutter button	8. Switch button	9. Camera modes
10. Beautify and Filters	11. AI camera	12. Google Lens
13. More		

Note

Some features may not be available to your models. The Camera layout and the place of the icons may vary depending on your models.

Open Camera

You can open **Camera** with the following methods:



- Tap **Camera** on the **Home screen**.
- Touch and hold and swipe left to open the **Camera** when the screen is locked.

Tip

You will not be able to see your **Gallery** items if you launch **Camera** on the **Lock screen** without verifying your password.

Take photos

The default camera mode is **Photo**, you can swipe left or swipe right to choose other modes to shoot.

1. Open  **Camera**.
2. Adjust the basic camera features based on your needs. See [Basic features](#) for more information.
3. Tap  to take a photo.

Switch between camera modes

Photo mode is the first camera mode when you open **Camera**. You can swipe left or right on the camera screen to select the following camera modes:

- **Clone**: Apply clone effects to your photos or videos. See [Clone mode](#) for more information.
- **Documents**: Take a picture for a document. See [Take Documents mode photos](#) for more information.
- **Dual video**: Take a video with the front and rear cameras at the same time. See [Take videos in Dual video mode](#) for more information.
- **Long exposure**: Take long exposure photos. See [Take photos in Long exposure mode](#) for more information.
- **Movie effects**: Take a video in Movie effects mode and apply more magic camera effects. See [Take videos in Movie effects mode](#) for more information.
- **Night**: Take photos or videos in low-light environment. See [Take photos in Night mode](#) for more information.
- **Panorama**: Take a panoramic landscape or other scenes. See [Take photos in Panorama mode](#) for more information.
- **Portrait** : Apply **Cinematic** , **Beautify** , or **Filters** effects to your photos. See [Take photos in Portrait mode](#) for more information.
- **Pro**: Take professional photos and videos. See [Pro mode](#) for more information.
- **Short video**: Shoot videos up to 10 seconds long and apply filters effects. See [Take videos in Short video mode](#) for more information.

- **Slow motion:** Take a video with a slow-motion effect. See [Take videos in Slow motion mode](#) for more information.
- **Supermoon:** Take a photo for the moon. See [Take photos in Supermoon mode](#) for more information.
- **Time-lapse:** Take videos and condense the videos with a higher speed. See [Take videos in Time-lapse mode](#) for more information.
- **Video:** Shoot a video. See [Take videos](#) for more information.
- **VLOG:** Use diverse vlog scenes. See [Take videos in VLOG mode](#) for more information.


Note

- Camera modes may not be available to some models.
- Camera features may vary in different models.

Basic features



You can use the basic features to adjust the brightness and exposure of the photo or zoom in or out to customize your shot.

Set the focus


1. Open  **Camera**.
2. Tap the screen to show the focus ring and exposure setting.
3. Tap the area that you want to focus on.

Adjust the exposure

When you take a photo in a low-light or an overexposed environment, adjust the exposure to adjust the brightness of your photo.

1. Open  **Camera**.
2. Tap the screen to show the focus ring and exposure setting.
3. Drag  up or down beside the focus ring to adjust the exposure.

Zoom in or out







1. Open  **Camera**.
2. Pinch the screen to zoom in or out on the viewfinder.

Tip


On some models, you can also toggle the zoom levels such as 0.6X, 1X, and 2X to zoom in or zoom out. For a more precise zoom, pinch the screen to 2X zoom level and then you can drag the slider left or right to zoom in or out.

Turn on the flash

When you take a photo in a low-light environment, turn on the flash to make your photos clearer.

1. Open  **Camera**.
2. Tap .
3. Choose flash types.
 - Tap  to enable automatic flash.
 - Tap  to enable flash after you tap .
 - Tap  to make flash always on.

Scan QR codes

1. Open  **Camera**.
2. Point the camera at the QR code, then tap the notification that appears.

Note

If you want to enable **Scan QR codes**, see [Enable Smart suggestions](#) for more information.

Useful features

You can use the useful features such as the **Gridlines** and **Tilt-shift** to improve your shot or **Timer** and **Voice shutter** to help take group photos.

Note

Some features may not be available to your models.

Apply Leica photographic styles

You can apply **Leica Authentic Look** or **Leica Vibrant Look** photographic styles to generate the marked Leica style photos. **Leica Authentic Look** preserves the true contrast between light and dark and accurate white balance of the image to avoid distortion of light and color. **Leica Vibrant Look** makes moderate



brightening and saturation adjustments to present bright and sharp shadows, and applies vibrant colors to make the photo or videos more suitable for vivid scenes.

1. Open  **Camera**.
2. Tap  to choose **Leica Vibrant Look** or **Leica Authentic Look** style.

Note




The feature may not be available to some models.

Adjust the aspect ratio

1. Open  **Camera**.
2. Tap  at the upper-right corner.
3. Choose an aspect ratio such as **1:1** , **3:4** , **9:16** , or **Full**.




Set a timer

You can set a countdown to give yourself time to take a photo.

1. Open  **Camera**.
2. Tap  at the upper-right corner.
3. Choose **3S** , **5S** , or **10S**.
4. Tap  to start the timer.




Add a movie frame

The movie frame changes the aspect ratio of your photo to a movie aspect ratio, and adds a movie effect to your photo.

1. Open  **Camera**.
2. Tap  at the upper-right corner.
3. Tap  **Movie frame**.

Enable Voice shutter




Voice shutter enables you to control the shutter with voice to take photos.

1. Open  **Camera**.
2. Tap  at the upper-right corner.
3. Tap  **Voice shutter**.

You can now say "Cheese!" to take a photo.

Show gridlines

You can use gridlines to straighten or compose your photo.




1. Open  **Camera**.
2. Tap  at the upper-right corner.
3. Tap  **Gridlines** to show gridlines.

Tip

You can tap  to choose different gridline types.

Enable Macro

Macro enables you to take photos or videos of an object in a close distance.




1. Open  **Camera**.
2. Tap  at the upper-right corner.
3. Tap  **Macro** to enable **Macro**.

Note



Some models may also support **Super macro** features. The feature may vary depending on your device.

Enable Tilt-shift

You can use **Tilt-shift** to make certain area clear and other places blurred in your photo.

1. Open  **Camera**.
2. Tap  at the upper-right corner.
3. Tap  **Tilt-shift** to enable **Tilt-shift**.

Note




- You can tap  for circle tilt-shift or  for linear tilt-shift.
- You can move the tilt-shift area to the place that you want to blur or be clear.

Enable Timed burst

You can use **Timed burst** to take a series of photos within the interval you set.



You can use **Timed burst** in **Pro** and **Photo** modes.

1. Open  **Camera**.

2. Tap  at the upper-right corner.
3. Tap  **Timed burst** to enable **Timed burst**.
4. Tap  to show the sliders for **Number of photos** and **Interval**.
5. Set the numbers and the interval.

Disable automatic HDR

High dynamic range (HDR) supports you to take photos in high-contrast situations. HDR brings more highlight and shadow details to the photos.


1. Open  **Camera**.
2. Tap **HDR**.
3. Tap .

Tip

The camera enables automatic HDR by default. You can also tap **HDR** to make HDR always on.


Enable AI camera

AI camera identifies subjects and scenes intelligently and optimizes the camera settings accordingly. It can identify a variety of scenes, such as blue sky, snowy weather, sunrise and sunset, greenery, and document.

1. Open  **Camera**.
2. Tap **AI** to enable AI camera.

When you are taking a photo, AI camera shows the identified icons.



For example, the camera identifies the object as green plant, then it applies suitable effects.



Add a movie filter

A movie filter creates a cinematic feel to your video.



You can apply **Movie filters** in **Pro** mode when you take a video.

1. Open  **Camera**.
2. Select **Video** mode.
3. Tap .
4. Choose a movie filter.



Enable Steady video

You can use **Steady video** to improve the smoothness of a video.

You can use **Steady video** in **Video** mode.

1. Open  **Camera**.
2. Select **Video** mode.
3. Tap .



Note

Some videos supports both  **Steady video** and  **Steady video PRO**. The feature may vary depending on your device.

Add Beautify and Filters effects

Beautify helps beautify the body part that you want to. **Filters** helps apply a filter effect.



You can add **Beautify** and **Filters** effects in **Photo** and **Portrait** modes and add **Beautify** and **Bokeh** effects when you take a video.

1. Open  **Camera**.
2. Tap  to choose to add **Beautify** and **Filters** effects.
 - Tap **Beautify** and drag the slider to adjust beautify effect.
 - Tap **Filters** and choose a filter effect.

Note

Some models may support Leica filters.

Adjust video resolution and frame rate




1. Open  **Camera**.
2. Select **Video** mode.
3. Tap  at the upper-right corner.
4. Choose a video resolution and frame rate.

Note


You can adjust video resolution and frame rate in both **Pro** and **Video** modes when you take a video.

Take a selfie

Use the front camera to take a selfie in **Photo** or **Portrait** mode or to take a video. The following steps take **Photo** mode as an example.




1. Open  **Camera**.
2. Tap  to switch to the front camera.
3. Tap  to take a selfie.

Tip

You can tap  to apply **Beautify** and **Filters** effects. See [Add Beautify and Filters effects](#) for more information.

Take videos

Take videos to capture the beautiful scenes and important moments.

1. Open  **Camera**.
2. Select **Video** mode.
3. Tap  to start shooting.
4. Tap  to stop shooting.


Tip

When taking a video, you can tap  to pause your shooting and tap  to continue.



You can also tap  to take a photo while shooting.

Take Documents mode photos

You can take a picture for a document such as paper, PowerPoint, and black-board in Documents mode. It can modify lens distortion and adjust perspective and support you to take a straight photo. Documents mode also enables you to add watermarks to protect your documents from unauthorized copying.



When you tap **Documents** for the first time, the option is not present. You can tap **Documents** again after downloading.

1. Open  **Camera**.
2. Select **Documents** mode.
3. Point camera at the subject and wait for the camera to identify the document area in the yellow frame.
4. Tap  to take a photo.

Tip

- You can tap  to edit the text of the protective watermark.




- You can go to  **Gallery** to view and adjust the document area.

Pro mode

You can adjust the white balance, focus, shutter speed, ISO sensitivity, exposure verification, lenses, and other features to take professional photos and videos.

Pro features




Pro features enables you to adjust different parameters to achieve the effects that you want. You can take creative photos and videos of your own style. The following are **Pro features** and their functions:

- Tap **WB** to select the white balance effects. When you shoot in different environments, you can apply the corresponding WB effects such as incandescent, daylight, and cloudy.
- Tap **F** and drag the slider to adjust the focus. When your camera is close to a subject, you can drag the slider to the left side. When your camera is far away from a subject, drag the slider to the right side.
- Tap **S** and drag the slider to adjust the shutter speed. When you shoot a stationary scene or portrait, you can lower the shutter speed. When you shoot a moving object, increase the shutter speed.
- Tap **ISO** and drag the slider to adjust ISO sensitivity. When you shoot in a low-light condition, you can increase the ISO value. When you shoot in a bright condition, decrease the ISO value.
- Tap **EV** and drag the slider to adjust exposure verification. When you shoot in a low-light condition, you can increase the EV value. When you shoot in a bright condition, you can lower the EV value.
- Tap **LENS** to select lenses. You can tap  for ultra-wide photos,  for wide photos, or  for telephotos.

Note

Some lens may not be available to your models.


- Tap  to select **Metering modes**.

	Measure light on the center area of the frame.
	Measure light in the whole frame.
	Measure light in one spot in the frame.

💡 Tip

- You can go to **Camera > Pro > Settings** to enable **Exposure verification**. The feature highlights underexposed areas in blue and overexposed areas in red and helps you to adjust exposure accordingly.
- You can go to **Camera > Pro > Settings** to enable **Focus peaking**. The feature places a red highlight on the in-focus area and helps you to adjust focus accordingly.





Take photos in Pro mode



1. Open **Camera**.
2. Select **Pro** mode.
3. Adjust the Pro features such as **WB** , **F** , **S** , **ISO** , **EV** , **LENS** , and **Metering modes**. See [Pro features](#) for more information.
4. Tap **○** to take a photo.

Take videos in Pro mode



1. Open  **Camera**.
2. Select **Pro** mode.
3. Tap  to switch to shoot a video.
4. Adjust the Pro features. See [Pro features](#) for more information.
5. Tap  to start shooting.
6. Tap  to stop shooting.


Note

When taking a video, you can tap  to pause your shooting and tap  to continue.

You can also tap  to take a photo while shooting a video.

Take photos in Portrait mode

You can use **Portrait** mode to apply **Cinematic**, **Beautify** and **Filters** effects. You can enable this feature to add a blurred background to your photos.





1. Open **Camera**.
2. Select **Portrait** mode.
3. Choose to add effects.
 - Tap to enable **Full body mode**. The feature uses suitable lenses when you take a full body photo. The feature may not be available to some models.
 - Tap to enable **Smart HD portrait**. The feature may not be available to some models.
 - Tap to apply a cinematic effect. The feature may not be available to some models.
 - Tap to apply a **Pro lenses** style. The feature provides 35mm to 90mm lenses styles to fit your photographic needs. The feature may not be available to some models.
 - Tap and drag the slider to adjust the aperture. A lower aperture value creates a more blurred background behind the portrait.
 - Tap to beautify the portrait and add filters.
4. Tap to take a photo.

Tip

You can tap  to take photos with the front camera.

Take photos in Night mode

Night mode captures more details and brightens your photos in low-light conditions.

1. Open  **Camera**.
2. Select **Night**.
3. Tap .




Note

Some models support to take videos in **Night** mode.

Take photos in ultra-high definition mode

The ultra-high definition mode supports ultra-high image resolution and helps in post-processing.

The following takes **50MP** mode as an example.

1. Open  **Camera**.
2. Select **More**.
3. Tap the icon for the ultra-high definition like  or **50MP**.
4. Tap  to take a photo.

Note








The ultra-high definition mode supports to take photos in **50MP** , **64MP** , **108MP**, or other Ultra HD modes. The feature and parameters may vary depending on your models.

Take videos in Short video mode

You can apply different effects to take a short video for 1 to 15 seconds.





When you tap **Short video** for the first time, the option is not present. You can tap **Short video** again after downloading.

1. Open  **Camera**.
2. Select **More**.




3. Tap  **Short video**.
4. Choose to set up your shooting.
 - Tap  to add background music.
 - Tap  to apply the speed effect.
 - Tap  and choose to apply **Beautify** effect, **Filters** effect, or **Kaleidoscope** effect.
5. Tap  to start shooting.
6. Tap  to stop shooting.
7. Tap  to save your shooting.

Take photos in Panorama mode

You can take a wide landscape photo or you can take a photo for large groups in Panorama mode.

1. Open  **Camera**.
2. Select **More**.
3. Tap  **Panorama**.
4. Point the camera at the starting scene of the Panorama photo.
5. Tap  to start your Panorama photo.
6. Keep the camera align with the arrow and move according to the arrow direction when you are shooting.
7. Tap  to finish the Panorama photo.





Note

- You can tap  to change the starting scene from horizontal level to vertical level. You can tap  to change the start direction from left to right or from bottom to top.
- If you finish the Panorama photo all the way along the reference line, it ends automatically. You can go to  **Gallery** to view and edit the photo.

Take videos in VLOG mode

VLOG mode provides diverse vlog scenes. With the preset parameters, background music, and clip styles, you can take a charming vlog easily.

When you tap **VLOG** for the first time, the option is not present. You can tap **VLOG** again after downloading.

1. Open  **Camera**.
2. Select **More**.
3. Tap  **VLOG**.
4. Choose a VLOG mode.
5. Tap  to apply the mode.
6. Tap  to start shooting video clips.

After you shoot all video clips, tap  to preview the shooting.





7. Tap  to save your shooting.

Tip

You can tap a clip to preview the clip. If you want to reshoot the clip, tap the clip again and then tap **Reshoot**.

Take videos in Slow motion mode






You can record a slow motion video in **Slow motion** mode.

1. Open  **Camera**.
2. Select **More**.
3. Tap  **Slow motion**.
4. Tap  to start shooting.
5. Tap  to stop shooting.

Take videos in Time-lapse mode

Time-lapse mode takes a video for several minutes or even hours, and then condenses the videos with a higher speed. You can capture the beauty of change such as drifting clouds, sunrise and sunset, and blossoming flowers.

1. Open  **Camera**.

2. Select **More**.
3. Tap  **Time-lapse**.
4. Choose to set up your shooting.
 - Tap  to choose **Speed** and **Duration**.
 - Zoom in or zoom out the photo.
 - Tap  to adjust parameters. See [Pro features](#) for more information.
5. Tap  to start shooting.
6. Tap  to stop shooting.







 **Tip**

You can use a tripod to keep your camera steady when you are shooting.

Take videos in Movie effects mode

You can take a video in Movie effects mode and apply more magic camera effects.





When you tap **Movie effects** for the first time, the option is not present. You can tap **Movie effects** again after downloading.

1. Open  **Camera**.
2. Select **More**.
3. Tap  **Movie effects**.
4. Choose a movie effect, then tap  to apply the effect.
5. Follow the instructions of each effect.
6. Tap  to start shooting.
7. Tap  to stop shooting.
8. Tap  to save the shooting.

Take photos in Long exposure mode

Long exposure mode keeps the shutter open for a period of time. When you shoot a waterfall, a crowded street, or moving light, long exposure can capture the trail of the objects.

When you tap **Long exposure** for the first time, the option is not present. You can tap **Long exposure** again after downloading.

1. Open  **Camera**.
2. Select **More**.
3. Tap  **Long exposure**.
4. Choose a corresponding scene.
5. Tap  to start to shoot.
6. Tap  to stop to shoot.





Tip

You can use a tripod to keep your phone steady when you are shooting to get a clear photo.

Take photos in Supermoon mode

The feature allows you to take a splendid photo for moon.


When you tap **Supermoon** for the first time, the option is not present. You can tap **Supermoon** again after downloading.

1. Open  **Camera**.
2. Select **More**.
3. Tap  **Supermoon**.
4. Tap  and drag the slider to adjust the zoom level from 5X to 60X.
5. Tap  to take a photo.

Note






The zoom levels may vary in different models.

Tip

You can tap  to add the silhouette of an airplane tree branches and other designs or text to your photo.

Take videos in Dual video mode

Dual video mode splits the scene on the viewfinder into two views. You can view and record a scene with the rear and front camera simultaneously.

1. Open  **Camera**.
2. Select **More**.
3. Tap  **Dual video**.
4. Tap  to adjust the places of front and rear views on the viewfinder.
5. Tap  to start shooting.
6. Tap  to stop shooting.

Tip






You can tap  to enlarge a view and narrow the other view.

Clone mode

Clone mode supports to take photos or videos of the same person at some intervals in one photo or video. You can take many creative photos and videos.

When you tap **Clone** for the first time, the option is not present. You can tap **Clone** again after downloading.



Take photos in Clone mode





1. Open  **Camera**.
2. Select **More**.
3. Tap  **Clone**.
4. Tap **Photo** and then tap .
5. Point the camera to the subject and wait for the camera to identify your subject.
6. Tap  to take a photo.
7. Tap  to save the photo.

Note

You can create up to 4 clones at a time.

Take videos in Clone mode

1. Open  **Camera**.
2. Select **More**.
3. Tap  **Clone**.

4. Tap **Video** or **Freeze frame**, and then tap .
5. Point the camera to the subject and wait for the camera to identify your subject.
6. Tap  to start shooting.
7. Tap  to stop the shooting.
8. Tap  to save the shooting.

 **Note**





You can create up to 2 clones at a time.

Camera settings

You can go to  > **Camera** >  >  **Settings** to open **Camera settings**.

Add a watermark

You can protect your photos with watermarks or add other information such as time, location, or temperature to the photo.


1. Open **Camera settings**.
2. Tap **Watermark**.
3. Choose to add watermark types.
 - Tap  to enable **Add time stamp on photos**.
 - Tap  to enable **Device watermark**.
 - Tap **Custom watermark** to add your watermark. Before you add the custom watermark, You need to tap  to enable **Device watermark** first.
 - Tap  to enable **Leica watermark**.

 **Note**

The feature may not be available to some models.

Enable Motion tracking focus



The feature keeps moving people or pets in focus automatically. You can also double tap any subject in the viewfinder to track.

1. Open **Camera settings**.
2. Tap  to enable **Motion tracking focus**.

Note


The feature may not be available to some models.

Enable Smart suggestions

1. Open **Camera settings**.
2. Tap **Smart suggestions**.
3. Choose smart suggestions. The features are usually enabled by default.
 - Tap  to enable **Document scanner**. The feature displays a shortcut whenever the AI camera detects a document or presentation slide.
 - Tap  to enable **Scan QR codes**. The feature only enables the rear camera to scan QR codes in **Photo** mode.

Enable Notify about orientation

The camera notifies about orientation when the phone is parallel to the ground.

1. Open **Camera settings**.
2. Tap  to enable **Notify about orientation**.

Enable Correct distortion in ultra wide shots


Note

Correct distortion in ultra wide shots is enabled by default.

1. Open **Camera settings**.
2. Tap  to enable **Correct distortion in ultra wide shots**.

Enable Motion capture

Track motion is to minimize blur on the photos of children, pets, and other active subjects.


1. Open **Camera settings**.
2. Tap  to enable **Motion capture**.

Note

The feature may not be available to some models.


Enable Auto night mode

Auto night mode can detect low light conditions and improve image quality automatically.

1. Open **Camera settings**.
2. Tap  to enable **Auto night mode**. The feature is usually enabled by default.


Enable Remove moles

Remove moles when you use the skin smoothing effects.

1. Open **Camera settings**.
2. Tap  to enable **Remove moles**.


Enable Close focus

Remove blurring when focusing on flat surfaces very close up.

1. Open **Camera settings**.
2. Tap  to enable **Close focus**.

Enable HEIF format

High efficiency image file format saves storage space.

1. Open **Camera settings**.
2. Tap  to enable **HEIF format**.

Note

You cannot take live photos and remove watermarks in HEIF mode.

Set picture quality

1. Open **Camera settings**.
2. Tap **Picture quality** to choose **High** , **Standard** , or **Low**.


Set up volume buttons function

You can customize the volume buttons shortcuts.

1. Open **Camera settings**.
2. Tap **Volume buttons function** to choose **Shutter** , **Timer (2s)** , **Zoom** , or **Volume**.

Enable Additional shutter

After you enable the feature, you can drag the shutter button up to create an additional shutter.

1. Open **Camera settings**.
2. Tap  to enable **Additional shutter**.

Tap to take a photo


You can tap the viewfinder to take a photo.

1. Open **Camera settings**.
2. Tap to enable **Tap to take a photo**.

Customize the camera

You can change the camera layout, color, and sound.

1. Open **Camera settings**.
2. Tap **Customize** to choose customized types.
 - Tap **Feature Layout** to rearrange the icons on both camera start screen and **More** features screen.
 - Tap **Camera modes** to select "**More**" tab or "**More**" panel.



Save location info

The location information is saved when you take a photo. You can go to **Gallery** to view location info in the photo detailed information.

1. Open **Camera settings**.
2. Tap to enable **Save location info**.


Enable the shutter sound

The camera makes a sound when you tap the shutter.

1. Open **Camera settings**.
2. Tap to enable **Shutter sound**. The feature is usually enabled by default.




Enable Pocket mode

The system locks touch gestures when you place the phone in a pocket.

1. Open **Camera settings**.
2. Tap  to enable **Pocket mode**.

Preserve settings

Preserve settings can preserve the previously used mode rather than automatically reset to default preferences.

1. Open **Camera settings**.
2. Tap **Preserve settings** to choose to enable or disable the previous settings.
 - Tap  to enable **Camera mode** . **Camera mode** preserves the previously used mode along with the front or rear camera selection.
 - Tap  to enable **Beautify** . **Beautify** preserves Beautify preferences selected during the previous session. The feature is enabled by default.
 - Tap  to enable **AI camera** . **AI camera** preserves AI camera status set during the previous session. The feature is enabled by default.

Set Anti banding

When you take a photo or video of a electronic screen, you can set the anti banding to reduce disturbances of the photo.

1. Open **Camera settings**.
2. Tap **Anti banding** to choose **Off** , **50Hz** , **60Hz** , or **Auto**.

Autostart





Autostart makes camera more responsive by allowing it to autostart. You can tap **Autostart** to manage autostart permissions in App info.

Restore default settings



1. Open **Camera settings**.
2. Tap **Restore default settings**.
3. Tap **OK**.

More settings






Set camera settings when you take a selfie

1. Open  **Camera**.
2. Tap  to switch to the front camera.
3. Go to  >  **Settings** to open **Camera settings**.






4. Choose to set camera settings.

- Tap  to enable **Mirror front camera**.
- Tap  to enable **Adjust makeup effects for men**.

Set camera settings in Video mode


1. Open  **Camera**.
2. Select **Video** mode.
3. Go to  >  **Settings** to open **Camera settings**.
4. Choose to set camera.
 - Tap **Video encoder** to select high compatibility or high performance video encoder.
 - Tap  to enable **Allow tagging videos** . You can tap **Tag** while shooting a video to go back to tagged moment during playback.
 - Tap  to enable **Live in-ear monitor**. The system monitors recorded sound with wired earphones when they are connected.


Set camera settings in Pro mode

1. Open  **Camera**.
2. Select **Pro** mode.
3. Tap  to switch to shoot a video.
4. Go to  >  **Settings** to open **Camera settings**.
5. Tap  to enable **Histogram** . **Histogram** allows the camera to show real-time exposure feedback when you are shooting. See [Set camera settings in Video mode](#) for more information when taking a video.

Chapter 9 Gallery

Gallery overview


Open  **Gallery** to view all the visual media stored on your phone. You can view, edit, and manage pictures and videos.



Photos






You can view photos and videos organized by days, months, or years.











View pictures

1. Go to  **Gallery > Photos**.
2. Tap a picture to view details.
3. Swipe left or right to view other pictures.


Edit pictures

You can crop the photo to different aspect ratio, add filters, doodle, text, or frame, and make adjustment to beautify your photo.

1. Go to  **Gallery > Photos**.
2. Choose a picture.
3. Tap  to edit the picture.
4. Choose **Basic** or **AI** to apply different effects.
 - Tap  **Auto** to apply auto effects to your picture.
 - Tap  **Crop** to crop the picture into a different size.
 - Tap  **Filter** to add color effects.




- Tap  **Adjust** to adjust the exposure, brightness, contrast, saturation, vibrance, warmth, tint, highlights, fade, grain, sharpness, and vignette of the picture.
 - Tap  **Doodle** to make doodles or add different shapes.
 - Tap  **Text** to add markup or text.
 - Tap  **Mosaic** to apply mosaics to the picture.
 - Tap  **Art framing** to add a frame to the picture. Only images taken by Xiaomi products co-engineered with Leica are supported.
 - Tap  **Erase** to remove visual clutter.
 - Tap  **Sky** to add a sky background.
 - Tap  **Sticker** to make your selfies cooler with lots of funny stickers.
 - Tap  **Frame** to add a frame to the picture and change the aspect ratio.
5. Tap  to save your modifications.
 6. Tap **Save**.

Tip

You can touch and hold  to see the original picture and release to see the adjusted picture.

Manage pictures

You can add the photos to albums, set the photo as wallpaper, and view or edit the detailed information of the photo.


1. Go to  **Gallery** > **Photos**.
2. Choose a picture.
3. Tap  to manage the picture.
 - Tap **Add to album** to move the picture to an album.
 - Tap **Recognize text** to identify texts. You can now copy and revise the text, share the text file, or save the file to  **Notes** App.

Note

The feature currently can support languages such as Bahasa Indonesia, Spanish, Italian, French, German, Portuguese, Chinese, and English.




- Tap **Adjust** to make the picture a document.
- Tap **Protective watermark** to add watermarks to the picture.
- Tap **Set as wallpaper** to set the picture as wallpaper.
- Tap **Start slideshow** to showcase the picture in a slideshow.
- Tap **Rename** to change the picture name.
- Tap **Google Lens** to identify the photo. The feature may not be available to some models.
- Tap **Details** to view and edit information about the picture.

Play videos

1. Go to  **Gallery > Photos**.
2. Choose a video to play.
3. Swipe left or right to play other videos.

Edit videos

You can cut the video to adjust the duration, add background music, filters, or text effects, and make other adjustments to your videos.



1. Go to  **Gallery > Photos**.
2. Choose a video.
3. Tap  to edit the video.
 - Tap  to adjust the video speed.
 - Tap **Editor** to cut the video into segments.
 - Tap **Filters** to add visual effects.
 - Tap **Enhance** to adjust the exposure, brightness, contrast, saturation, vibrance, warmth, tint, highlights, fade, grain, sharpness, and vignette of the video.
 - Tap **Captions** to add text.
 - Tap **Soundtrack** to add background music.

- Tap **Aspect ratio** to change the aspect ratio.
- Tap **Pro** to switch to the **Video editor** to adjust the video. See [Edit a video with Video editor](#) for more information.

4. Tap **Save**.



Manage videos

You can add the videos to albums, set the videos as wallpaper, compress the videos, and view or edit the detailed information of the videos.

1. Go to  **Gallery > Photos**.
2. Choose a video.
3. Tap  to manage the video.
 - Tap **Add to album** to add the video to a private or other album.
 - Tap **Set video wallpaper** to set the video as wallpaper.
 - Tap **Compress video** to compress the video.
 - Tap **Rename** to change the video name.
 - Tap **Details** to view and edit information about the video.



Share photos and videos

You can share the photos and videos to your family, friends, and other media platforms.


1. Go to  **Gallery > Photos**.
2. Choose a picture or video.
3. Tap .
4. Choose a platform to share your selection.

Mark a photo or video as favorite



When you take a lot of photos, you can use the feature to mark your favorite photos or videos. All your favorite items are stored in **Select best photo** album and you can view and edit them.

1. Go to  **Gallery > Photos**.
2. Choose a picture or video.
3. Tap .

Note

You can go to  **Gallery** > **Settings** to view the favorite photos and videos in **Select best photo** album.

Delete photos and videos

1. Go to  **Gallery** > **Photos**.
2. Choose a picture or video.
3. Tap .
4. Tap **Delete** in the pop up window.

Tip



You can also touch and hold an item to select multiple photos or videos to delete.

Albums

Your photos are organized automatically by categories, such as Favorites, Camera, Screenshots and screen recordings, and Videos. You can view the organized albums or create new albums.

Create an album



You can create albums and add photos to the albums to categorize your photos and videos.

1. Go to  **Gallery** > **Albums**.
2. Tap  at the lower-right corner of the phone.
3. Enter the album name.
4. Follow the instruction to add photos or videos to the album.

Tip

You can also choose not to add photos or videos to the album.

Rename an album

1. Go to  **Gallery** > **Albums**.
2. Press and hold the album that you want to rename.
3. Tap  **Rename**.
4. Enter the new album name.



5. Tap **OK**.

Note

You cannot rename the default album name such as **All photos** , **Favorites** , **Videos** , and **Screenshots and screen recordings**.

Hide albums



You can hide albums to protect your privacy. The hidden albums do not show on your **Settings** tab.

1. Go to  **Gallery > Albums**.
2. Press and hold the album that you want to hide.
3. Tap  **Hide**.
4. Tap **OK** in the pop up window.

Note



If you want to view the hidden albums, you can see [View hidden albums](#) for more information.

Delete albums

1. Go to  **Gallery > Albums**.
2. Press and hold the album that you want to delete.
3. Tap  **Delete**.
4. Tap **OK** in the pop up window.

Manage albums




You can move the albums to other albums, make photos or videos in albums shown in **Share without location info by default** album, and set the album cover.

1. Go to  **Gallery > Albums**.
2. Press and hold an album to choose the album.
3. Tap  **More** to manage the album.
 - Tap **Show in Photos** to make pictures shown on the **Share without location info by default** album.
 - Tap **Move to other albums** to move the album to other albums.

- Tap **Change album cover** to select a new picture as an album cover.



Edit a video with Video editor

Video editor enables you to trim your videos, make contrast or brightness adjustments, change the playback speed, and apply other features and effects.

1. Open  **Gallery**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Video editor**.
4. Select one or more videos.
5. Tap  to import the videos.
6. Use video editing tools to edit the video.
 - Tap **Templates** to select a template.
 - Tap **Editor** to add transitions or new videos and cut the video into segments.
 - Tap **Filters** to add a filter effect to the video.
 - Tap **Enhance** to adjust the exposure, brightness, contrast, saturation, vibrance, warmth, tint, highlights, fade, grain, sharpness, and vignette of the video.
 - Tap **Captions** to add texts or credits.
 - Tap **Soundtrack** to adjust the volume levels and add background music or sound to the video.
 - Tap **Aspect ratio** to adjust the aspect ratio of the video.
7. Tap **Save**.


Create a collage



You can combine multiple photos into a single image and apply an interesting layout.

1. Open  **Gallery**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Collage**.
4. Select 1 to 6 photos.

5. Tap ✓ to import the photos.
6. Choose a collage style.
 - Tap **Poster** to select a poster style collage.
 - Tap **Layout** to select a layout. Then you can tap **Margins** to add margins and tap **Aspect ratio** to change the aspect ratio of the whole collage.
 - Tap **Film roll** to select a film roll style collage.
7. Tap **Save**.

Create a clip

You can share photos from  **Gallery** by creating a slideshow of your pictures with video effects and music.



1. Open  **Gallery**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Clip**.
4. Select 3 to 20 photos and tap ✓ to import the photos.
5. Use editing tools to edit the clip.
 - Tap **Templates** to select a template.
 - Tap **Audio** to add background music or sound to the clip.
 - Tap **Edit** to add more photos or delete some photos.
6. Tap **Save**.

Note

You can choose to create a video for **10s** or **Longer video** at the upper-middle of the phone.

Edit a picture with Cutout



Cutout can automatically cut out subjects from a picture and change the background behind the subjects.

1. Open  **Gallery**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Cutout**.

4. Select 1 photo.
5. Wait for the system to identify the subjects in the photo.
6. Select a background to change the background behind the subjects.
7. Tap **Save**.

Edit a picture with Art

You can add an Art style to your photo.

1. Open  **Gallery**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Art**.
4. Choose an art style.
 - Tap **Low poly** to add a futuristic geometric background.
 - Tap **Etching** to add an atmosphere of old master prints.
 - Tap **Sketch** to turn backgrounds into sketches.
 - Tap **Watercolor** to add watercolor style backgrounds.
 - Tap **RGB** to add a cyberpunk retro effect.
 - Tap **Blinds** to add a misplaced vertical segments effect.
 - Tap **Foggy window** to add hazy blurs.
 - Tap **Tech** to add a futuristic feel.
5. Select 1 photo.
6. Wait for the system to apply the art style.

Note

You can also choose an art style to change the current style.


7. Tap **Save**.

Edit a video with Video effects

Use Video effects to apply interesting effects on portrait videos.



The feature may not be available to some models.

1. Open  **Gallery**.

2. Tap  at the upper-right corner of the phone.
3. Tap **Video effects**.
4. Tap **Start** and select 1 video.
5. Tap **Next** to import the video.
6. Press and hold the video effects to apply different effects to the video.
7. Tap **Save**.

Free up space

Free up space clears photos in your Gallery to free up storage space.



1. Open  **Gallery**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Free up space**.

The system starts scanning the **Gallery** automatically.

4. Tap **View** or **View details**.
5. Select the photos that you want to delete.
6. Tap **Delete selected photos**.
7. Tap **Delete** in the pop up window.

Sort and set the album view format

You can sort albums by name, created time, or last updated time.




1. Open  **Gallery**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Sort and view**.
4. Choose to sort and set the album view format.
 - Tap **Sort** to sort the albums in **Custom** , **Name** , **Created** , or **Last updated**.
 - Tap **List view** to view albums in list format.

Gallery Settings



Enable Select best photo

MIUI analyzes similar photos and marks the best photos for you.

Select best photo is enabled by default. You can also disable the feature to remove marks from photos.

1. Open  **Gallery**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Settings**.
4. Tap  to enable **Select best photo**.

View hidden albums



1. Open  **Gallery**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Settings**.
4. Tap **View hidden albums**.

Tip

If you want to hide albums, you can see [Hide albums](#) for more information.




Set the time for each slide

When you slide show the photos, you can set the interval for each slide.

1. Open  **Gallery**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Settings**.
4. Tap **Show each slide for** to enter interval.
5. Tap **OK**.




Loop all slides

When you browse photos in slide show, you can loop all slides.

1. Open  **Gallery**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Settings**.
4. Tap  to enable **Loop all slides**.

Enable Recognise text on images

The feature allows the system to recognise text on images, and you can select or take other actions with the text.





1. Open  **Gallery**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Settings**.
4. Tap  to enable **Recognise text on images**.

Note

To recognise the text on images, see [Manage pictures](#) for more information.



Set secure sharing


Secure sharing enables you to share photos and videos without the privacy information such as location, phone model, or metadata.

1. Open  **Gallery**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Settings**.
4. Tap **Secure sharing**.
5. Choose to set secure sharing.
 - Tap  to enable **Share without location info by default** to remove location info from shared photos. **Share without location info by default** is enabled by default.
 - Tap  to enable **Share without metadata by default** to remove device model, metadata, and other information. **Share without metadata by default** is enabled by default.

Convert HEIF before sending

The system converts HEIF images to JPEG before sending.

1. Open  **Gallery**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Settings**.


4. Tap  to enable **Convert HEIF before sending**. The feature is usually enabled by default.

Chapter 10 Apps



Note


When you use Apps, certain permissions such as the access to location info and camera need to be allowed. You can give limited permissions to the Apps and withdraw the consent at any time.


Calculator


You can use  **Calculator** to perform basic arithmetic calculations with the standard calculator. You can also use the scientific calculator for trigonometric functions, angular radians, roots, and financial and currency measurement.


Use Calculator


1. Open  **Calculator**.
2. Choose proper calculators.
 - Tap  to use the basic calculator for basic arithmetic calculations.




- Tap  to switch to the scientific calculator for trigonometric functions, angular radians, and roots.




- Tap  to use the Converter calculator to convert currencies and multiple units of measurement.




- Tap  to use the Mortgage calculator to help you plan finances with adjustable repayment methods and interest rates.



Copy, delete, or clear numbers


1. Open  **Calculator**.
2. Tap the numbers to calculate.
3. Choose to copy, delete, or clear numbers.




- Touch and hold the calculation result in the display, then tap **Copy**. You can now paste the result elsewhere.
- Tap  to delete the last digit if you make a mistake when you enter a number.
- Tap **C** to delete the last entry or tap **AC** to delete all entries.

Clock

Add an alarm

You can set alarms for any time of day and have them repeat on one or more days of the week.



1. Open  **Clock**.
2. Tap  on the start page to add an alarm.
3. Adjust the alarm time.
4. Set the ringtone, repeat frequency, and other items.
5. Tap .



The  shows beside the alarm time.

Tip

If you want to change the preset alarm time, tap the alarm to change the time.




Turn off the alarm

You can turn off the alarm once on the day you set or turn off the repeating alarm.

1. Open  **Clock**.
2. Tap  beside the alarm time.
3. Select to turn off the alarm once or turn off the repeating alarm.





Add custom clock

You can add clocks in different countries and regions to compare the time.




1. Open  **Clock**.
2. Tap .
3. Tap .
4. Search for country or city.
5. Tap the location to add a custom clock to the start page.

Use stopwatch

You can use the stopwatch to measure the duration of an activity such as a match or an event.



1. Open  **Clock**.
2. Tap .
3. Tap  to start.
4. Tap  to pause the stopwatch.


Note

You can tap  to mark different time segments, tap  to continue, or tap  to reset the stopwatch.




Set a timer

You can use the timer to count down from a specified time. You can set times with duration from one second to 99 hours 59 minutes and 59 seconds.


1. Open  **Clock**.
2. Tap .

3. Set the time period.
4. Tap  to start timing.

Note


The timer stops automatically when the timing ends. You can also tap  to pause the timer, tap  to continue, or tap  to reset the timer.

Tip


You can tap  to add an ambient noise. You can also choose to silence the alarm at the end of an ambient noise timer.

Compass

You can use **Compass** to show your direction, location, and elevation.



Use compass


1. Open  **Compass**.
2. Place your phone on a horizontal or vertical surface to see the compass face.

Tip

You can see the real-time view provided by your camera when you hold the phone vertically.

Use a level

You can use the level to measure whether a surface is horizontal or vertical.

1. Open  **Compass**.
2. Swipe left from the start page to use your phone as a level.
3. Place your device on a horizontal or vertical surface to see the level face.



Note

When the color of the circles turns green, it shows that the phone is horizontal or vertical to the surface.

Downloads

You can use **Downloads** to manage your downloaded Apps and other files.





Add a new download job

1. Open  **Downloads**.
2. Tap  at the lower-right corner.
3. Enter an HTTP or HTTPS link in the box.
4. Tap **Download**.


Tip

You can swipe left from the start page to view the completed download jobs.


Delete a downloaded job

1. Open  **Downloads**.
2. Swipe left or tap  to open the download page on the start page.
3. Choose to delete a downloaded job.
 - Touch and hold the item, then tap .
 - Tap the item, then tap .


File Manager

 **File Manager** is an easy and powerful file explorer. It helps you easily manage storage on your device, network-attached storage, and cloud storages. You can also find how many files and apps you have on your device at a glance immediately after opening the App.



Document view

You can tap  to view documents. They are sorted into various categories, such as images, videos, docs, music, APKs, Bluetooth & downloads, and archives. You can tap the corresponding category to locate a document.



Storage statistics

You can tap  to check what files occupy the internal storage of your device at a glance and see all the items in the root folders.



Share files

1. Open  **File Manager**.
2. Choose a file, then tap the file.
3. Tap  **Send** to share the file to different platforms.

Move files to other folder



1. Open  **File Manager**.
2. Choose a file, then tap the file.
3. Tap  **Move** to move the file to other folders.

Delete files

1. Open  **File Manager**.
2. Choose a file, then tap the file.
3. Tap  **Delete** to delete the file.



Manage files

You can make the files private, add the files to **Favorites** folder, copy, rename, and make other adjustments.

1. Open  **File Manager**.
2. Choose a file, then tap the file.
3. Tap  **More** to manage the file.
 - Tap **Copy** to copy the file to other folders.
 - Tap **Make private** to make the file private.
 - Tap **Add to favorites** to add the file to **Favorites** folder in **Add to favorites** of **Internal storage**.

- Tap **Rename** to rename the file.
- Tap **Open in another app** to open the file with other Apps.
- Tap **Details** to view the detailed information of the file.



Clear up space

1. Open  **File Manager**.
2. Tap  at the upper left corner of the phone.
3. Tap **Deep clean**.

The system automatically scans for trash files from **Cache files** , **Obsolete files** , **Packages** , **Residuals** , and **Memory**.

4. Choose the files that you want to clear.
5. Tap **Clear now**.

View the private files




1. Open  **File Manager**.
2. Tap  at the upper left corner of the phone.
3. Tap **Private files**
4. Enter the privacy protection password.

Note


If you enter the private files for the first time, you need to sign into your Mi account or Google account and set a privacy protection password.

Enable Dark mode


You can enable **Dark mode** to make your screen suitable to read in low-light environment.

1. Open  **File Manager**.
2. Tap  at the upper left corner of the phone.
3. Tap  to enable **Dark mode**.

Google


Google service supports many Apps. To learn how to use the Apps, see <https://support.google.com> for more information. To download more Apps, you can go to  **Play Store** App or the Google official website.

Assistant


You can use  **Assistant** to get stuff done faster. Instead of performing tasks manually by tapping your finger on the screen a gazillion times, you can get the job done by using voice commands. Assistant is smart and well-integrated with Android.

See assistant.google.com for more information.


Calendar

You can use  **Calendar** to view schedule information, set reminders, and add tasks or events.

Contacts


You can use  **Contacts** to keep all your contact information in one place and reach several people at once. You can organize, review, and merge your contacts, create personal mailing lists, and quickly send messages to groups of people you contact the most, without entering their addresses individually.

Drive

With  **Drive**, you can open, view, rename, and share files saved to your Drive cloud account.



See support.google.com/drive for more information.

Duo


You can easily make one-to-one video calls with  **Duo**.

See support.google.com/duo for more information.

Files


 **Files** is a file management App that takes less storage on your phone. With  **Files**, you can view files into categories, free up storage and get cloud backup, and share files with others nearby that have the same App.

Gmail

 **Gmail** enables you to send and receive an email with Google's web-based email service.


See support.google.com/mail for more information.

Google

With  **Google**, you can find online content that interests you, and turn on your personalized feed to receive customized content.

See support.google.com/websearch for more information.

Google One

With  **Google One**, you can automatically back up your phone and manage the Google cloud storage.


- You can use the Google account to automatically back up photos, contacts, messages, and other important things. If you break, lose or upgrade your phone, you can restore everything to your new Android device.

Note


Every Google account has 15 GB of free space.

- You can manage your Google account storage across Drive, Gmail, and Photos.

Home

With  **Home**, you can control and manage lights, cameras, TVs, and more compatible devices all from one place.

Maps


You can use  **Maps** to get directions and other location-based information.

Attention

You must enable location services to use  **Maps**.


See support.google.com/maps for more information.

News

 **News** is a personalized news aggregator that organizes and highlights what's happening in the world so you can discover more about the stories that matter to you.


See support.google.com/news/publisher-center for more information.

Photos

You can store and back up your photos and videos automatically to your Google Account with  **Photos**.


See support.google.com/photos for more information.

Play Store

You can find new apps, movies and TV shows, music, books, magazines, and games in  **Play Store**.

See support.google.com/play for more information.

Podcasts

With  **Podcasts**, you can play the latest episodes from your favorite shows, explore podcast recommendations, and manage your listening activities.

See support.google.com/googleplay/podcasts for more information.

YouTube


You can use  **YouTube** to watch and upload videos right from your device.

See support.google.com/youtube for more information.



YT Music

You can stream and browse playlists, albums, and artists from  **YT Music**.

Mi Browser



 **Mi Browser** is a fast and secure full-featured web browser for mobile devices. You can use **Mi Browser** to surf the web, browse news, search for things, watch videos, shop online, and play online games. You can also use **Mi Browser** to download images and videos from social media, use file management tools, and set private folders.

Search or open web address

1. Open  **Mi Browser**.
2. Tap  **Home** to open the Home page.
3. Type on the search bar to search or open web address.



Manage files

You can send, hide, delete, and view the detailed information.

1. Open  **Mi Browser**.
2. Tap  **Files** to view all files.
3. Tap and hold a file that you want to manage.
4. Choose **Send** , **Hide** , **Delete** , or **More**.




Open online games

You can play online game without loading a game App.



1. Open  **Mi Browser**.
2. Tap  **Games** to open the Games page.
3. Tap a game to play.

View Bookmarks and History


You can view your stored bookmarks and browse history.

1. Go to  > **Mi Browser** >  **Profile**.
2. Tap  to view bookmarks and history.

Enable Incognito mode, Dark mode, or Desktop mode

1. Go to  > **Mi Browser** >  **Profile**.
2. Choose to enable **Incognito mode** , **Dark mode** , or **Desktop mode**.
 - **Incognito mode:** Incognito mode allows you to browse the web safely and privately without leaving any search or browsing history.
 - **Dark mode:** The dark color scheme can boost visual experience in low-light environment.
 - **Desktop mode:** Desktop mode enables you to browse web pages similar to the look on computer desktop.


Mi Remote

 **Mi Remote** is a universal remote control App that works with your phone's IR Blaster (Infrared Blaster) port. Mi Remote supports Samsung, LG, Sony, Panasonic, Sharp, Haier, Videocon, Micromax, Onida, and other brands. You can control the available appliances including TVs, set-top boxes, DVD players, smart boxes, air conditioners, projectors, cameras, and other devices in your home.

Use Mi Remote to control remote devices

You can use Mi Remote App on your phone to control remote devices when you are not convenient with a Remoter.


The following takes **Set-top box** as an example.

1. Open  **Mi Remote**.
2. Tap **Add remote** to view available device types such as TV, fan, or smart box.
3. Select **Set-top box** to choose a service provider.
4. Tap **Power** and follow the onscreen instructions to connect the remote devices.

Note



Mi Remote does not supports some devices. You can check the features based on real situations.

Mi Store

You can check the latest marketing sales, view the information about Xiaomi products, buy the latest Xiaomi products, and ask for support in  **Mi Store**.

Find products

You can browse and search for your interested products.



1. Open  **Mi Store**.
2. Tap  **Mi Store** to discover Xiaomi products.

Note

You can also tap  to search the name of the products.

You can view products that are categorized as **Smartphone** , **Smart Home** , and **Lifestyle**. You can also view the discount products on the page.

Buy a product

1. Open  **Mi Store**.
2. Tap  **Mi Store** to discover Xiaomi products.



Note

You can also tap  to search the name of the products.

3. Tap the product to see the price and other information.
4. Tap **BUY NOW** and choose your preferences.
5. Sign in to your Mi Account and complete your address and other information.
6. Tap **Pay now** and verify your password.



Get service support

You can get service support when you have questions about your orders.


1. Open  **Mi Store**.
2. Tap  **Support** to go to the **Xiaomi Service Center** page.
3. Choose to start a live chat or make a call to contact the service.

Manage your orders




You can check the order status and change or cancel an existing purchase order.

1. Open  **Mi Store**.
2. Tap  **Account** to check your order information.
You can see the **Unpaid** , **Shipping** , **Reviews** , and **Returns** order information.
3. Tap the order categories to manage your orders.

Mi Video

 **Mi Video** is a powerful local video player. With **Mi Video**, you can play, download, stream, and manage your videos in one place. You can easily zoom in and out on the played videos.




Play videos

1. Open  **Mi Video**.
2. Tap  **Local** to view local files.
3. Tap  to open video page.

You can view your local videos in **Videos** , **Folders** , and **Playlist** categories.









4. Tap a video to play.








Play musics

1. Open  **Mi Video**.
2. Tap  **Local** to view local files.
3. Tap  to open the music page.
4. Tap a music to play.






Useful features in side panels

When you play a video, you can use useful features to add more effects to your video.

Icons	Function	Icons	Function
	Lock the screen.		Take a screenshot.
	Loop the video.		Stretch the video.
	View the video in notification shade.		Rotate the screen.
	More features		Share the video.






	Cast the video.		Select audio track.
	Adjust subtitles.		Mute the video.
	Browse the playlist.		Activate back-ground playback.
1.0x	Adjust play speed.		AB loop


Gesture shortcuts in Mi video

Gesture	Function
	Double tap to rewind by 5 seconds.
	Double tap to pause or resume.
	Double tap to fast forward by 5 seconds.
	Swipe up or down at the left part of the screen to adjust the brightness.
	Swipe up or down at the right part of the screen to adjust the volume.


Manage videos

You can share, rename, delete, and hide the videos.


1. Open  **Mi Video**.
2. Choose a video, then touch and hold the video.
3. Manage videos.
 - Tap  **Share** to share the video to different platforms.
 - Tap  **Rename** to rename the video.
 - Tap  **Properties** to view the detailed information of the video.
 - Tap  **Hide** to make the video private.

- Tap  **Delete** to delete the video.

Music



You can use  **Music** to stream and browse playlists, albums, and artists. You can also play music saved on your phone.

Play your music

1. Open  **Music**.
2. Browse songs in **Songs** , **Artists** , **Albums** , or **Folders** page.
3. Choose a music to play.





Sign in to your Xiaomi Account

You can sign in to your Xiaomi account to sync your music information and preference.

1. Open  **Music**.
2. Tap  to open the account settings.
3. Tap **Sign in** to sign in to your Xiaomi Account.




Set up Music

You can set sleep timer, filter files, and do more other settings.

1. Open  **Music**.
2. Tap  to open the account settings.
3. Go to **Settings** > **Advanced settings** to find service and settings.
 - Tap  to enable **Sleep timer** to stop player after a certain time.
 - Tap **Headphones & audio effects** to enable **Dolby Atmos** and adjust graphic equalizer.
 - Tap  to enable **By size** or **By length** and drag the slider to adjust to filter audio files.

Enable Dark mode





Dark mode create a comfort visual effect in low-light environment.

1. Open  **Music**.
2. Tap  to open the account settings.
3. Tap  to enable **Dark mode**.

Notes

You can take notes with text, images, audio, and mind maps.






Create a note

1. Open  **Notes**.
2. Tap  in  page to create a note.
3. Enter the text.
4. Tap  to save the note.

Tip

- You can add audio, images, sketches, checklists, and other items in a note.
- You can also apply a heading style, bold or italic font, a bulleted or numbered list, and more items to change the formatings.



Make a voice note

1. Open  **Notes**.
2. Tap  to add a note.
3. Tap  and speak to your phone.
4. Tap  to stop the recording.
5. Enter the title of the voice note.
6. Tap  to save the voice note.

Tip


You can press and hold  to create a voice note.

Delete a note

1. Open  **Notes**.
2. Touch and hold a note in .
3. Tap **Delete**.

Manage notes





You can hide, pin, delete, move note, and create a folder to categorize notes.

1. Open  **Notes**.
2. Touch and hold a note to choose one or multiple notes.




3. Choose to manage the notes.

- Tap **Hide** to hide the note.
- Tap **Pin** to pin the note.
- Tap **Delete** to delete the note.
- Tap **Move to** to move the note to a new folder.
- Tap **Create a folder** to add notes to a folder when you choose multiple notes.



Restore deleted notes

1. Open  **Notes**.
2. Tap  on the start page.
3. Tap  to view all folders.
4. Tap  to view all deleted notes.
5. Tap the note you want to restore, then tap **OK**.


Create a new folder

1. Open  **Notes**.
2. Tap  on the start page.
3. Tap  to view all folders.
4. Tap **New folder**.
5. Enter the folder name.
6. Tap **OK**.

Search notes

1. Open  **Notes**.
2. Tap the search bar in  page to enter keywords of the note.
3. Choose to locate the note.




View hidden notes

1. Open  **Notes**.
2. Swipe down from the upper part of the screen and then release.
3. Enter the privacy protection password.


4. Tap a hidden note to view details.

Create a subtask checklist

You can use Notes as a reminder to remind you of the daily routines and tasks.

1. Open  **Notes**.
2. Swipe left or tap  on the top of the start page.
3. Tap  to create checklist of subtasks.
4. Enter the subtask text.
5. Tap **Done**.




Note

- You can set a reminder and a repeat interval of each subtask checklist.
- If you want to add more subtasks, tap .




Recorder

You can use **Recorder** to record an event, a meeting, personal notes, or classroom lectures, creative ideas, and more.


Record audio

1. Open  **Recorder**.
2. Tap  to start.
3. Tap  to stop recording.
4. Tap **OK** to save the recording.

Tip

- The recording name is generated by default. You can edit the name to a new one.
- You can tap  to mark specific segments, tap  to pause the recording, and tap  to continue the recording.







View recordings

1. Open  **Recorder**.
2. Tap the recording that you want to view.


Tip

You can also share, mark, or make the recording play fast.

Set up Recorder

1. Open  **Recorder**.
2. Tap  at the upper-right corner of the phone.
3. Choose to manage Recorder settings.
 - Tap  to enable **Earpiece mode** to play audio using the earpiece speaker.
 - Tap  to enable **Lock screen notifications** to show a blue indicator on the Lock screen while recording.
 - Tap  to enable **Mute ringer when recording**.
 - Tap  to enable **Name recording manually**.
 - Tap **Recording format** to select **AAC** , **MP3** , or **WAV**.
 - Tap **Delete synced recordings** to delete synced recordings.
 - Tap **Recently deleted items** to manage deleted items. Deleted items can be stored in the trash for up to 30 days.
 - Tap **Clear data** to delete cached items, app data, and customized settings.

Scanner

You can open  **Scanner** and place the QR code inside the frame to scan different types of QR codes and bar codes.


Caution

You do not use Scanner to take photos of the objects that contain your personal information.


Tip

You can turn on the flash in the dark environment.


Security

You can use  **Security** to clean up phone storage, manage Apps and permissions, filter and block spam calls and messages, and protect your phone from hidden viruses or malicious Apps.



App lock

 **App lock** helps protect your privacy. See [App lock](#) for more information.

Battery and performance

Use  **Battery & performance** to test the power consumption and optimize battery-related items. See [Chapter 4 Battery and maintenance](#) for more information.

Blocklist





 **Blocklist** automatically filters all types of spam, phishing, and marketing calls and messages.  **Blocklist** displays the history of your filtered SMS messages and incoming calls.

Note

Highlighted phone numbers indicate unread messages or calls. Phone numbers go from red to black after you read corresponding messages or call history.



Enable Blocklist

You can add phone numbers to the blocklist.

1. Go to  **Security** >  **Blocklist**.
2. Tap  at the upper-right corner of the phone.
3. Tap  to enable **Blocklist**.

Manage blocked incoming calls

You can view the blocked incoming call history or unblock a blocked incoming call.

1. Go to  **Security** >  **Blocklist**.
2. Choose a blocked call.
3. Tap the phone number to view call history.
4. Manage blocked incoming calls.
 - Tap a call in the call history to dial or send a message.
 - Tap **Unblock** to unblock the number.




Tip

You can touch and hold a phone number to delete multiple items.

Manage blocklist








Use phone numbers, prefixes, and locations to establish blocking condition.

You need to enable **Blocklist** first.


1. Go to  **Security** >  **Blocklist**.
2. Tap  at the upper-right corner of the phone.
3. Manage blocklist.
 - Tap **Blocked numbers** to block calls and messages from specific numbers.
 - Tap **Exceptions** to allow calls and messages from specific numbers.

Call blocklist settings


You can choose to block calls from different groups of people and contacts.

1. Go to  **Security** >  **Blocklist**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Call blocklist** choose to block calls.
 - Tap  to enable **Block calls from strangers**.
 - Tap  to enable **Block forwarded calls**.
 - Tap  to enable **Block calls from contacts**.
 - Tap  to enable **Block calls from hidden numbers**.

Boost speed

Use  **Boost speed** to help your phone work faster. The feature clears cache and memory of the running third-party Apps, running system Apps, and locked running Apps.

Cleaner

Use  **Cleaner** to delete useless items that stored on the phone and make the phone work fast and productively.

Clear trash





Cleaner scans trash of cache files, obsolete files, installation packages, residuals, and memory cache. You can clear up the items.

1. Open  **Security**.
2. Tap  **Cleaner** to launch an automatic scan for trash.


3. Choose the items that you want to clear.
4. Tap the button below to clean up the selected items.

Set the reminder


You can receive an alert notification to use **Cleaner** when trashes reaches the limit.


1. Go to  **Security** >  **Cleaner**.
2. Tap  at the upper-right corner of the phone.
3. Tap  to enable **Remind to clean**.
4. Set trash size limit and schedule alerts frequency.

Data usage







Use  **Data usage** to manage your data plan. It keeps track of data usage and helps restrict mobile data, background data, or Wi-Fi usage of Apps.

Deep clean

Use  **Deep clean** to delete redundant or unnecessary items to free up your phone storage.

- **Delete the redundant photos:** detect duplicate photos and poor-quality images in your  **Gallery**.
- **Uninstall rarely-used Apps:** delete the rarely used Apps to free up space.
- **Delete App data:** clear unimportant data for each App.
- **Delete the big files:** delete the unimportant big files.
- **Delete the unnecessary videos:** delete the unnecessary videos.

Deep clean settings

1. Go to  **Security** >  **Deep clean**.
2. Tap  at the upper-right corner of the phone.
3. Choose to manage **Deep clean** settings.
 - Tap  to enable **Remind to clean**, and then to set trash size limit and schedule.
 - Tap  to enable **Scan app memory**.
 - Tap  to enable **Show Home screen shortcut**.


Dual apps

 **Dual apps** allows you to clone an existing app on your device and use it independently with a different account. See [Dual apps](#) for more information.



Facebook cleaner

Use  **Facebook cleaner** to clean images, videos, GIFs, or Cache files.





Game Turbo

 **Game Turbo** boosts the connection stability for games by limiting the bandwidth of background downloads and reducing network delay. This feature clears memory reserved for the background processes to give more space for the game and prevents you from notification disturbances.









Open games with Game Turbo

1. Go to  **Security** >  **Game Turbo**.
2. Swipe up or down in the left part of the screen to select a game.
3. Tap **Start playing** to launch the game with **Game Turbo**.

Add games to Game Turbo







1. Go to  **Security** >  **Game Turbo**.
2. Tap  to view games.
3. Tap  beside the games to add the games to **Game Turbo**.

Manage Booster General settings

1. Go to  **Security** >  **Game Turbo** > .
2. Tap **General Settings**.
3. Choose to manage Booster General settings.
 - Tap  to enable **Game Turbo** to improve gaming experience.
 - Tap  to enable **In-game shortcuts**. You can swipe from the top side edge of the screen to view games.
 - Tap  to enable **Content recommendations** to receive gaming-related content recommendations.
 - Tap  to enable **Remove added games from Home screen**.
 - Tap **Uninstall games** to choose to uninstall games at once.
 - Tap  to enable **Home screen shortcut**.





- Tap **Add game** to add games to **Game Turbo**.

Set up Performance mode

1. Go to  **Security** >  **Game Turbo** > .
2. Tap **Performance mode** to set up Performance mode.
 - Tap **Performance mode** to choose to enable **Wi-Fi optimization** or **Optimized touch controls**. **Wi-Fi optimization** reduces Wi-Fi network delay. **Optimized touch controls** increases touch response and sensitivity.
 - Tap  to enable **Performance optimization** to avoid overheating and hardware-related issues.
 - Tap **Memory exceptions** to add Apps to exceptions and prevent them from being optimized.
 - Tap  to enable **Mi WiFi speed boost** to increase connection speed by 10% to 20% when the phone is connected to Mi/Redmi routers.
 - Tap  to enable **Lower screen brightness automatically**.



Set up Game DND

The feature restricts selected system features, buttons, and full screen gestures when you play games.

1. Go to  **Security** >  **Game Turbo** > .
2. Tap **Game DND** to set up Game DND.
 - Tap **Enhanced experience** to choose to enable **Turn off auto brightness**, **Turn off Reading mode**, **Restrict screenshot gestures**, or **Don't open Notification shade**.
 - Tap  to enable **Restrict buttons and gestures**.

Manage GPU settings

GPU settings help select or customize the performance between the **Picture quality**, the **Highest frame rate**, and the **Gaming performance** when you play a game.



1. Go to  **Security** > .
2. Tap **Default** at the bottom of the phone.
3. Tap **GPU settings** to choose GPU modes such as **Default**, **Save power**, **Balance**, **High quality**, or **Custom**.

Note

Custom enables you to customize **Frame rate** , **Resolution** , **Anti-aliasing Anisotropic filtering** , **Texture filtering quality** , and **Optimized graphics**.



Set up Touch Controls

Touch Controls helps select or customize the performance between the **Classic mode (Default)** , **Pro mode** , **Aiming accuracy** , and **Tap stability**.

1. Go to  **Security** >  **Game Turbo**.
2. Tap **Default** at the bottom of the phone.
3. Tap **Additional settings** to choose **TOUCH CONTROLS** modes.
 - Tap **Classic mode (Default)**.
 - Tap **Pro mode** . **Pro mode** is designed for professional players.
 - Tap **Customize** to personalize the **Swipe response** , **Sensitivity to continuous taps** , **Aiming accuracy** , and **Tap stability**.



Set up Touch-resistant area

The feature reduces touch sensitivity near the edges to avoid triggering touch controls.



1. Go to  **Security** >  **Game Turbo**.
2. Tap **Default** at the bottom of the phone.
3. Tap **Additional settings** to choose **Touch-resistant area**.

Set up Enhanced visuals

The feature helps increase contrast and enhance details for games.

1. Go to  **Security** >  **Game Turbo**.
2. Tap **Default** at the bottom of the phone.
3. Tap **Additional settings** to choose **Enhanced visuals** performances.



Restore default settings

1. Go to  **Security** >  **Game Turbo**.
2. Tap **Default** at the bottom of the phone.
3. Tap **Additional settings** to choose **Restore default settings**.
4. Tap **Restore**.

5. Tap **OK**.

Hide apps

Use **Hide apps** enables you to hide App icons so they no longer appear on your Home screen.

1. Go to  **Security** >  **Hide apps**.
2. Tap beside an App to hide the App icon.

Open hidden Apps

1. Spread two fingers apart on the Home screen.




A folder with hidden Apps shows.

2. Tap a hidden App.



Note

If you enabled App lock, you need to enter the password when you open the hidden folder.


Manage Hide apps

1. Go to  **Security** >  **Hide apps**.
2. Tap  at the upper-right corner of the phone.
3. Manage **Hide apps**.
 - Tap to enable **Hide notifications** to not show the notifications from hidden Apps.
 - Tap to enable **App lock** to protect private files.



Manage Apps

You can go to  **Security** >  **Manage apps** to update and uninstall Apps or manage the permissions. See [Manage apps](#), [Dual apps](#), and [Permissions](#) for more information.

Privacy


Use  **Privacy** to manage Apps that request sensitive permissions, monitor how Apps use sensitive permissions, and manage other privacy-related permissions. See [Privacy protection](#) for more information.

Second space

You can go to  **Security** >  **Second space** to create a second space to separate and secure your data.



To turn on Second space, see [Turn on Second space](#) for more information.

Security scan

Use  **Security scan** to scan your phone for dangerous Apps and viruses. The feature timely solves the issues related to Wi-Fi, payment environment, privacy, and viruses.





Use Security scan

Use Security scan to scan the system and get suggestions on clearing trash and checking the new features.


1. Go to  **Security** >  **Security scan**.
2. Tap the suggestions to clear up space or view the new features.

Scan before installing

Apps checked for viruses and malware before installing.

1. Go to  **Security** >  **Security scan**.
2. Tap  at the upper-right corner of the phone.
3. Tap  to enable **Scan before installing**.

Solve problems


Use  **Solve problems** to scan and solve performance, network, settings, battery, and other issues of the phone.

Note

If you find some problems, you can tap **Submit** to report issues or suggestions in **Services & feedback**.

Test network

Find and solve network-related issues

Use  **Test network** to run a network test when you encounter problems with network. You can follow the onscreen instructions to resolve the current network problems after you see the test results.

Close connected Apps




All Apps currently connected to the internet are shown in the test results. You can tap an App to force to stop it.

Services & Feedback

You can report the issues you encounter to our developers. Your suggestions on how to improve MIUI are welcomed. We always do our best to fix the issues you report in the upcoming updates.

Open Services & Feedback

You can access **Services & feedback** with one of the two following methods:

- Tap  **Services & feedback** in **Tools**.
- Tap  **Services & feedback** in  **Settings**.


Submit feedback

1. Open **Services & feedback**.
2. Tap **Submit feedback**.
3. Choose **Issues** or **Suggestions** to describe issues.
 - Tap **Issues** and describe the issues.
 - Tap **Suggestions** and share how you would like to improve MIUI.
4. Select the item of your feedback.
5. Select the how often the issue occurs and the exact time that the issue happened lately.
6. Tap **Send**.


Note

You can choose to add an image or video, enter your phone number or email, or add logs when you submit a feedback.

ShareMe

You can use  **ShareMe** to back up or transfer files between Android devices or between your mobile devices. See [Transfer files with the ShareMe App](#) for more information.


Themes

 **Themes** can give your phone a new look. Themes is the official personalization platform of MIUI with thousands of high-quality themes. Besides the familiar themes, wallpapers, ringtones, and fonts, you will be able to find lots of other personalization options for your Lock screen and Home screen.

Weather




You can use **Weather** to check the weather in your current location and other locations. You can view the upcoming hourly and 5-day forecast and see the air pollution and other information.

View weather info




You can open  **Weather** to view the current and the 5-day forecast weather information of your location. You can also check the 24-hour forecast, wind speed and direction, real feel, UV index, and pressure on the start page.

Add a city to your weather list



You can add and view the weather information of different cities in your weather list.

1. Open  **Weather**.
2. Tap  at the upper-left corner of the start page.
3. Search for city.
4. Tap  to add the city to the start page.

Delete a city from your weather list

1. Open  **Weather**.
2. Tap  at the upper-left corner of the start page.
The weather list shows.
3. Touch and hold a city.
4. Tap  **Delete**.

Share weather info



1. Open  **Weather**.
2. Tap  at the upper-right corner of the start page.
3. Tap **Share**.

The system automatically creates a picture with the weather information.


4. Choose a platform to share the picture.

Manage Weather settings

You can set your preferred weather units display, the update time for weather information, and change the sound effects when the weather changes.



1. Open  **Weather**.
2. Tap  at the upper-right corner of the start page.
3. Tap **Settings** to view all settings.
4. Manage Weather settings.
 - **Units:** allows you to set preferred temperature units, wind speed units, or atmospheric pressure units.
 - **Update at night automatically:** allows the App to update weather info between 23:00 and 7:00.
 - **Sound effects:** allows the weather changes with sound effects.

Xiaomi Community

 **Xiaomi Community** is an official forum for Xiaomi users. It helps and provides the latest news about Xiaomi Products and MIUI updates. You can chat with Xiaomi fans in Xiaomi Community.

View the latest news

You can view the latest the news and comments about Xiaomi and MIUI from the official accounts or users in the community.

1. Open  **Xiaomi Community**.
2. Tap  **HOME** to view the latest news.
3. Tap the news that you are interested in to see more details.


Tip

You can also make comments below the news.

Make a post

You can post anything that you want to say and share your ideas with other users of the same interest in the community.

1. Open  **Xiaomi Community**.



2. Tap  to choose to post a post, thread, video, poll, or Q&A.
3. Enter the text that you want to share.
4. Tap **Submit**.

Tip

You can also select a forum, add a topic, add photos, videos, and other media files to your post. Other users with the same interest may find your post easily.

Join a forum

You can join the forum that you are interested in and view the latest news and information of the forum.



1. Open  **Xiaomi Community**.
2. Tap  **FORUM** to view your forums.
3. Tap **All forums** to see all forums.
4. Choose the forum that you want to join in, then tap **Join** beside the forum.

Chapter 11 Security and safety



Passwords and security

You can set password to protect your phone. When you turn the phone on or wake it, you need to enter the password to unlock the phone.

Set up Screen lock

1. Go to  **Settings** >  **Passwords & security** > **Screen lock**.
2. Choose a screen lock type.
 - Tap **Pattern** to draw a simple pattern with your finger to lock the phone. See [Set a pattern lock](#) for more information.
 - Tap **Pin** to enter 4 to 16 numbers to lock the phone. See [Set up a PIN lock](#) for more information.
 - Tap **Password** to enter 4 or more letters or numbers to lock the phone. See [Set up a face lock](#) for more information.

Set a pattern lock



1. Go to  **Settings** >  **Passwords & security** > **Screen lock**.
2. Tap **Pattern**.

3. Draw an unlock pattern and then tap **Next**.
4. Draw the unlock pattern again and then tap **Confirm**.

 **Note**

If you do not want to set other lock methods, tap **Cancel**.



Set up a PIN lock

1. Go to  **Settings** >  **Passwords & security** > **Screen lock**.
2. Tap **Pin**.
3. Enter 4 to 16 digits.
4. Tap **Continue** and then tap **OK** to confirm your password.

 **Note**

If you do not want to set other lock methods, tap **Cancel**.

Set up a password lock



1. Go to  **Settings** >  **Passwords & security** > **Screen lock**.
2. Tap **Password**.
3. Enter 4 or more digits or letters.
4. Tap **Continue** and then tap **OK** to confirm your password.

 **Note**

If you do not want to set other lock methods, tap **Cancel**.

Set up a fingerprint lock

You have to set up **Screen lock** first before you set up **Fingerprint unlock**. You can see [Set up Screen lock](#) for more information.

1. Go to  **Settings** >  **Passwords & security** > **Fingerprint unlock**.
2. Verify your identification with a screen unlock.
3. Add your fingerprint on the fingerprint scanner.
4. Tap **Done**.

 **Note**



The place of fingerprint sensor may vary in different models. The fingerprint sensors may locate on the sides of the phone or in the bottom of the screen.

Tip

Make sure both your finger and the screen are clean.

Set up a face lock




You need to set up **Pattern** first before you set up **Face unlock**. You can see [Set up Screen lock](#) for more information.

1. Go to  **Settings** >  **Passwords & security** > **Face unlock**.
2. Verify your identification with a screen unlock.
3. Tap **Start** to add your face data.
4. Tap **Done**.

Unlock with Bluetooth device

You can unlock the phone with bluetooth devices such as some wearable devices made by Xiaomi.

You need to set screen lock before you set up **Unlock with Bluetooth device**. You can see [Set up Screen lock](#) for more information.

1. Go to  **Settings** >  **Passwords & security** > **Unlock with Bluetooth device**.
2. Tap  to enable **Unlock device**.
3. Verify your identification with a screen unlock.
4. Tap **Allow** to turn on Bluetooth in the pop-up window.
5. Tap an available device to connect.

Use Privacy protection password


Privacy protection password is used for the Apps that might contain sensitive information.

1. Go to  **Settings** >  **Passwords & security** > **Privacy protection password**.
2. Tap  to enable **Use Privacy protection password**.

Find my device

You can enable **Use Find My Device** to find, lock, or reset the phone if it is lost.

1. Go to  **Settings** >  **Passwords & security** > **Privacy**.
2. Tap **Find My Device**.

3. Tap  to enable **Use Find My Device** . **Use Find My Device** is usually enabled by default.
4. Tap **Find My Device app** or **Find My Device web** to find the phone.

Note

Find My Device app does not work until you add a Google account.

Security status

You can go to  **Settings** >  **Security status** to view the information about **Find device** , **Security update** , and **Google Play Protect**.

Note



Google Play Protect regularly checks your Apps and phone for harmful behavior. You are notified of any security risks found.

Safety & emergency

In case of emergency, you can use your phone quickly and easily to call for help and alert your emergency contacts.

Add medical information

Add you identification, name, address, blood, allergies and other medical information to help the first respondent know your information quickly.



1. Go to  **Settings** >  **Safety & emergency** > **Medical information**.
2. Tap **Name** , **Blood type** , **Allergies** , **Medications** , **Address** , **Medical notes** , or **Organ donor** to add your medical information.

Note


You can also go to  **Settings** >  **Safety & emergency** > **OPEN EMERGENCY INFORMATION** to add medical information.

Add an emergency contact

You can add emergency contacts to help the first responders to contact to your family and friends.

1. Go to  **Settings** >  **Safety & emergency** > **Emergency contacts**.
2. Tap **Add contact**.
3. Choose a contact or create a new contact.
4. Tap the contact to add it to the emergency contact list.




Tip

You can tap  to search for a contact.

Use Emergency SOS

After you enable the feature, you can press the Power button 5 times or more rapidly to play a loud sound when Emergency SOS is starting.




If you set up the Emergency SOS for the first time, an on-screen guide helps you set up the Emergency SOS. The settings include whether to play countdown alarm, how to set up your emergency actions and share your information in emergency, and so on.

1. Go to  **Settings** >  **Safety & emergency** > **Emergency SOS**.
2. Tap  to enable **Use Emergency SOS**. **Use Emergency SOS** is usually enabled by default.

Play alarm sound




After you enable the feature, the phone plays a loud sound when Emergency SOS starts.

You need to enable **Use Emergency SOS** first.

1. Go to  **Settings** >  **Safety & emergency** > **Emergency SOS**.
2. Tap  to enable **Play alarm sound**.


Manage emergency actions


You need to enable **Use Emergency SOS** first.

1. Go to  **Settings** >  **Safety & emergency** > **Emergency SOS**.
2. Manage emergency actions.
 - Tap  to enable **Call emergency services**. You can add an emergency call.

Note




If you enter a non-emergency number, your phone must be unlocked to use Emergency SOS and your call may not be answered.

- Tap  to enable **Share info with emergency contacts**. In an emergency, your real-time location and other information are automatically shared.

- Tap  to enable **Record emergency video**. The feature can record, back up, and share an emergency video.




Enable Crisis alerts

The feature notifies you about natural disasters and public emergencies that affect your area.

1. Go to  **Settings** >  **Safety & emergency** > **Crisis alerts**.
2. Tap  to enable **Crisis alerts**.




Send Emergency Location

When you call or text an emergency number, your phone can automatically send the location to emergency response partners.

1. Go to  **Settings** >  **Safety & emergency** > **Emergency Location Service**.
2. Tap  to enable **Use Emergency Location Service**. **Use Emergency Location Service** is usually enabled by default.


Enable Earthquake alerts

When the phone detects an earthquake nearby, you get an alert with the initial estimated magnitude and distance from your location.

1. Go to  **Settings** >  **Safety & emergency** > **Crisis alerts**.
2. Tap  to enable **Earthquake alerts**.




Silence notifications while driving





The feature turns on **Do Not Disturb** to limit interruptions such as calls and text messages when you are driving.

1. Go to  **Settings** >  **Safety & emergency**.
2. Tap  to enable **Silence notifications while driving**.

Enable wireless emergency alerts

You can receive alerts that threaten your life and property, bulletins about child abduction, and test information from the safety alert system.




1. Go to  **Settings** >  **Safety & emergency** > **Wireless emergency alerts**.
2. Tap  to enable **Allow alerts**. **Allow alerts** is usually enabled by default.
3. Choose to enable alerts types.

- Tap  to enable **Extreme threats**. The feature alerts extreme threats to life and property.
- Tap  to enable **Severe threats**. The feature alerts severe threats to life and property.
- Tap  to enable **AMBER alerts**. The feature alerts child abduction emergency bulletins.
- Tap  to enable **Test alerts**. The feature allows to receive carrier tests and monthly tests from the safety alert system.

Note

You can tap **Emergency alert history** to view previous alerts.



Set alert preferences

1. Go to  **Settings** >  **Safety & emergency** > **Wireless emergency alerts**.
2. Choose to set alert preferences.
 - Tap  to enable **Vibration** when in alert. **Vibration** is usually enabled by default.
 - Tap **Alert reminder** to select an alert reminder frequency.

Privacy

View Privacy dashboard



You can view the time line of when Apps used a permission in the past 24 hours.

1. Go to  **Settings** >  **Privacy**.
2. Tap **Privacy dashboard** to view which permissions recently are used.
3. Tap a permission to view the time line.

Note




The feature may not be available to some models.

Manage permissions

1. Go to  **Settings** >  **Privacy**.
2. Tap **Permission manager** to control App access to your data.
3. Tap a permission to view which Apps can access the permission.
4. Tap an App to change the App permission.



Show passwords

Show passwords displays characters briefly as you type.

1. Go to  **Settings** >  **Privacy**.
2. Tap  to enable **Show passwords**.

Use Autofill with Google



Autofill with Google saves and fills with passwords, credit cards, or addresses when needed.

1. Go to  **Settings** >  **Privacy** > **Autofill service from Google**.
2. Tap  to enable **Use Autofill with Google**.



Enable Google location history

You can check where you go with the device.

You need to add one Google account or use myaccount.google.com to manage some settings without an account.



1. Go to  **Settings** >  **Privacy**.
2. Tap **Google location history** to view **Activity controls** page.
3. Tap **Turn on**.

Activity controls

The data saved in your account helps give you more personalized experiences across all Google services. You can choose which settings save data in your Google Account. You can go to  **Settings** >  **Privacy** > **Activity controls** to manage **Web & App activity** , **Location History** , **YouTube History** , and **Ad personalization**.

Reset advertising ID

Generate a new advertising ID that Apps can use from now on.




1. Go to  **Settings** >  **Privacy** > **Ads**.
2. Tap **Reset advertising ID**.
3. Tap **CONFIRM**.

Note



You can also tap **Delete advertising ID** to see ads that are not based on your interests.

Enable Usage & diagnostics

The feature shares data to help improve Android device experience.

1. Go to  **Settings** >  **Privacy**.
2. Tap **Usage & diagnostics** to view information about Usage & diagnostics.
3. Tap  to enable **Usage & diagnostics**.

Privacy protection

You can go to  **Settings** >  **Privacy protection** to manage Apps that request sensitive permissions, monitor how Apps use sensitive permissions, and manage other privacy-related permissions.

Manage all permissions

You can manage Apps that request sensitive permissions. See [Manage permissions](#) for more information.

Special permissions

You can monitor how Apps use sensitive permissions:



- **All files access:** Allow an App to read, modify, and delete all files on the device or any connected storage volumes.
- **Device admin apps:** Allow the admin App to erase all data, change the screen lock, lock the screen, or disable some screen lock features.
- **Display over other apps:** Allow an App to display on the top of other Apps you are using.
- **Do Not Disturb access:** Allow an App to enable Do Not Disturb.
- **Media management apps:** Allow an App to modify or delete media files created with other Apps without asking you.
- **Modify system settings:** Allow an App to modify system settings.
- **Device & app notifications:** Allow an App to access notifications.
- **Picture-in-picture:** Allow an App to create a picture-in-picture window while the App is open or after you leave it. For example, to continue watching a video.
- **Premium SMS access:** Allow an App to access Premium SMS.
- **Unrestricted data:** Allow an App to use data unrestrictedly.

- **Install unknown apps:** Allow an App to install unknown Apps. But the feature may make your phone more vulnerable to attack by unknown Apps.
- **Alarms & reminders:** Allow an App to set alarms and schedule time-sensitive actions. The feature lets the App run in the background, which may use more battery.
- **Usage access:** Allow an App to track what other Apps and how often you are using, and your carrier, language settings, and other detailed information.
- **VR helper services:** Allow an App to run as VR helper service.
- **Wi-Fi control:** Allow an App to turn Wi-Fi on or off, scan and connect to Wi-Fi networks, add or remove networks, or start a local-only hotspot.

Other permissions



You can manage other privacy-related permissions. See [Manage other permissions](#) for more information.

Apps

You can go to  **Settings** >  **Apps** to manage Apps and their permissions, set Dual apps, and set App lock.



Manage system Apps

You can manage the services and settings of a system App. The system Apps include **Music** , **Recorder** , **Call settings** , **Camera** , **Gallery** , **Security** , **System apps updater** , and **Xiaomi Cloud**.

1. Go to  **Settings** >  **Apps** > **System app settings**.
2. Tap a system App to manage the settings.

Manage apps


Uninstall Apps

1. Go to  **Settings** >  **Apps** > **Manage apps**.
2. Tap **Uninstall**.
3. Choose one or more Apps.
4. Tap **Uninstall** at the bottom of the phone.

Set default Apps

Set default Apps for basic usages such as dial, messages, and camera.




1. Go to  **Settings** >  **Apps** > **Manage apps**.

2. Tap  at the upper-right corner of the phone.
3. Tap **Default apps**.
4. Select a basic function to set a default App for the function.

For example, you can tap **Browser** to select **Chrome** or **Mi Browser** as a default App to browse web pages.

Reset App preferences

Resets all preferences for disabled Apps, disabled App notifications, default Apps, and background data restrictions for Apps.




1. Go to  **Settings** >  **Apps** > **Manage apps**.
2. Tap  at the upper-right corner of the phone.
3. Tap **Reset app preferences**.
4. Tap **Reset apps**.

Note

The feature does not erase any App data.

Manage Home screen shortcuts




You can choose to enable the Home screen shortcuts of system Apps such as **Themes** , **File Manager** , **Services & feedback** , **Downloads** , **Music** , and **Mi Video**.

1. Go to  **Settings** >  **Apps** > **Manage Home screen shortcuts**.
2. Tap  beside an App to enable the Home screen shortcut.

The App icon shows on the Home screen.

Dual apps

Dual apps allows you to clone an existing App on your device and use it independently with a different account.

1. Go to  **Settings** >  **Apps** > **Dual apps**.
2. Tap **Create**.
3. Tap  beside an App to create a dual App.
4. Tap **Turn on**.

Note




A dual App locates next to an App name. Whenever the system requires an action from an App that has a dual App, you are asked which App is used.

Permissions

Enable the autostart

The feature enables Apps to start automatically when you turn on the phone.



Some Apps may incorrectly indicate that MIUI has prevented them from starting. You can check permissions that have been granted to individual Apps.

1. Go to  **Settings** >  **Apps** > **Permissions**.
2. Tap **Autostart**.
3. Tap  beside an App to enable autostart.

Note

You can also tap the App to choose to enable **Allow apps to start automatically** and **Allow the app to be started by other apps**.



Manage permissions

1. Go to  **Settings** >  **Apps** > **Permissions**.
2. Tap **Permissions** to enter **Permission manager**.

Permissions such as Calendar, Camera, or Contacts are displayed in the form of a permission list.

3. Tap an item to check which Apps use the permission.
4. Tap an App to manage the permission.

Manage other permissions

1. Go to  **Settings** >  **Apps** > **Permissions**.
2. Tap **Other permissions** to manage other permissions.
 - Tap an App to check or modify the permissions in **Apps** page.
 - Tap a permission to check or modify system settings in **Permissions** page.

Install via USB

The feature allows an App to be installed on your device via USB



1. Go to  **Settings** >  **Apps** > **Permissions**.

2. Tap **Install via USB** and follow the onscreen instructions.

App lock

Protect Apps with App lock

App lock checks Apps installed on your device and recommends the Apps that require protection for the first time.




1. Go to  **Settings** >  **Apps** > **App lock**.
2. Tap **Turn on**.
3. Set the **Pattern** password.
4. Choose to add or not add a Xiaomi Account.
5. Select Apps and tap **Use App lock**.

Note

You can choose to turn on fingerprint unlock.

Add Apps to App lock

Use **App lock** to protect the data of individual Apps and your privacy.





1. Go to  **Settings** >  **Apps** > **App lock**.
2. Enter the password to open **App lock**.
3. Choose an App and tap  beside to lock the App.

Tip




You can tap the search field at the top of the screen to search for Apps.

Disable App lock

Remove the protection from all Apps along with the App lock password.

1. Go to  **Settings** >  **Apps** > **App lock**.
2. Tap  at the upper-right corner of the phone.
3. Tap  to disable **App lock**.
4. Tap **OK**.




Manage App lock settings

1. Go to  **Settings** >  **Apps** > **App lock**.
2. Tap  at the upper-right corner of the phone.

3. Manage App lock settings.

- Tap **Lock settings** to choose when to apply **App lock**. You need to verify your App lock password when you open a protected App in the applied time.
- Tap **Hide notification content** to select which Apps to hide notification content. The feature allows you to see **You have a new message** instead of the actual content when you receive a notification.
- Tap to enable **Unlock all apps at once**.
- Tap to enable **Lock all apps**.

Manage App lock password settings



1. Go to  **Settings** >  **Apps** > **App lock**.
2. Tap  at the upper-right corner of the phone.
3. Manage App lock password settings.
 - Tap **Change password type** to change the App lock password type and the password itself.
 - Tap to enable **Unlock with fingerprint**. You can add a fingerprint unlock for App lock.
 - Tap to enable **Face unlock**. You can add a face unlock for App lock.
 - Tap to enable **Add Mi Account**. It is recommended to add your Mi Account before you use **App lock**. If you forget the App lock password, you can reset it with the Mi Account. Otherwise, you can only perform a factory reset.

Location


Location may use sources like GPS, Wi-Fi, mobile networks, and sensors to help estimate the location of your device.

Enable Location access

Allow Apps that have the location permission to get your location information.



1. Go to  **Settings** >  **Location**.
2. Tap to enable **Location access**.

Tip

You can also swipe down from the upper-right corner of the phone to enable  **Location** on the Control center.

Change App location permissions



You can allow the App to access the location permission all the time or only while in use, or not allowed.

1. Go to  **Settings** >  **Location** > **App location permissions**.
2. Tap an App to see the location permission.
3. Change the location permissions for the App.

Note

On some models, you tap **App access to location** to change the App location permissions.

Manage location services

1. Go to  **Settings** >  **Location**.
2. Tap **Location access** to manage location services.
 - Tap **Earthquake alerts** to check the location service.
 - Tap **Emergency Location Service** to use emergency location service.
 - Tap **Google Location Accuracy** to improve location accuracy.
 - Tap **Google Location History** to view the location history in Google Apps.
 - Tap **Google Location Sharing** to view the location sharing in Google Apps.
 - Tap **Wi-Fi scanning** to allow Apps and services to scan for Wi-Fi networks at anytime, even when Wi-Fi is off.
 - Tap **Bluetooth scanning** to allow Apps and services to scan for nearby devices at anytime, even when Bluetooth is off.

Note

On some models, you can tap **Share location info with carrier** to all the carriers to learn about your location via base station.




Chapter 12 Accessibility

The accessibility features help people with difficulties in vision, physical, hearing, and other needs.





General

Enable Accessibility menu shortcut

Accessibility menu provides convenient shortcuts that allow you to control the phone.




1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Accessibility menu** in **General** page.
3. Tap  to enable **Accessibility menu shortcut**.

Set up Accessibility button

1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Accessibility button** in **General** tab.
3. Choose to set up Accessibility button.
 - Tap  to enable **Accessibility button**.
 - Tap **Use button or gesture** to choose to access accessibility features with button or gesture.
 - Tap **Location** to set the location of the Accessibility button.
 - Tap **Size** to set the size of the Accessibility button.
 - Tap  to enable **Fade when not in use**.
 - Drag the slider left or right to adjust **Transparency when not in use**.

Enable Shortcut from lock screen




Allow features shortcut to turn on from the Lock screen. Hold both volume keys for a few seconds.

1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap  to enable **Shortcut from lock screen**.

Vision

Use TalkBack

TalkBack provides spoken feedback so that you can use the phone without looking at the screen. TalkBack is intended for situations or people who have difficulty in seeing the screen.




1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Vision** to adjust screen readers and display in **Vision** page.
3. Tap **TalkBack**.
4. Tap  to enable **Use TalkBack**.
5. Tap **Allow** and follow the onscreen instructions or listen to the talkback to perform actions.

Note

To turn off TalkBack, you press the volume buttons simultaneously.

You can now tap the phone screen to listen to the words or items aloud.



Enable TalkBack shortcut

1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Vision** to adjust screen readers and display in **Vision** page.
3. Tap **TalkBack**.
4. Tap  to enable **TalkBack shortcut**.
5. Tap **Turn on**.

Note

You can now press and hold both the volume buttons simultaneously to turn on or turn off TalkBack.




Set up Talkback

1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Vision** to adjust screen readers and display in **Vision** page.
3. Go to **TalkBack** > **Settings**.
4. Choose to set up Talkback.





You can set up the **Text-to-speech settings** , **Verbosity** , **Sound and vibration** , and customize **Focus Indicator**, gestures, menus, and other items.

Enable Select to Speak shortcut



When Select to Speak is on, you can tap specific items on your screen to hear the words read aloud.

1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Vision** to adjust screen readers and display in **Vision** page.
3. Tap **Select to Speak**.
4. Tap  to enable **Select to Speak shortcut**.
5. Tap **Allow** and follow the onscreen instructions to perform actions.




Set up Select to Speak

1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Vision** to adjust screen readers and display in **Vision** page.
3. Go to **Select to Speak** > **Settings**.
4. Choose to set up Select to Speak.
 - Tap **Text to speech settings** to set the preferred engine, language, speech rate, and pitch level.
 - Tap  to enable **Read in background**.
 - Tap  to enable **Read text on images**.

Manage Text-to-speech output

1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Vision** to adjust screen readers and display in **Vision** page.
3. Tap **Text-to-speech output**.
4. Choose to manage **Text-to-speech output**.
 - Tap **Preferred engine** to set the speech service engine.
 - Tap **Language** to select the Text-to-speech output language.
 - Drag the slider left or right to adjust **Speech rate**.
 - Drag the slider left or right to adjust **Pitch**.

Manage display




1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Vision** to adjust screen readers and display in **Vision** page.
3. Choose to manage display.
 - Tap **Display size** to select the icon display size.
 - Tap **Magnification** to enable **Magnification shortcut**. **Magnification shortcut** enables you to quickly zoom in on the screen to make content larger.
 - Tap **Color correction** to correct colors that fit your eyes.
 - Tap **Color inversion** to turn light screens dark or turn dark screens light.
 - Tap  to enable **Remove animations**.

Hearing

Use Live Caption




Live Caption detects speech on your device and automatically generates captions.

The feature supports English language currently.



1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Hearing** to adjust audio in **Hearing** page.
3. Tap **Live Caption**.
4. Tap  to enable **Use Live Caption**.

Enable Mono audio




The feature combines channels when playing audio.

1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Hearing** to adjust audio in **Hearing** page.
3. Tap  to enable **Mono audio**.

Adjust audio balance

1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Hearing** to adjust audio in **Hearing** page.
3. Drag the slider left or right to adjust the **Audio balance**.

Manage Caption preferences

1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Hearing** to adjust audio in **Hearing** page.
3. Tap **Caption preferences**.
4. Manage Caption preferences.
 - Tap  to enable **Show captions**.
 - Tap **Caption size and style** to adjust text size and caption style.




Note

Not all Apps support the caption reference.




Physical

Enable Switch Access

Switch Access lets you interact with your Android device with one or more switches instead of the touch screen. **Switch Access** can be useful if you cannot interact directly with your phone. Use switches to select items, scroll, type, and more.

1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Physical** to adjust interaction controls and input device in **Physical** page.
3. Tap **Switch Access**.
4. Tap  to enable **Use Switch Access**.
5. Tap **Allow** and follow the onscreen instructions to perform actions.

Enable Switch Access shortcut



1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Physical** to adjust interaction controls and input device in **Physical** page.
3. Tap **Switch Access**.
4. Tap  to enable **Switch Access shortcut**.

Manage interaction controls

1. Go to  **Settings** >  **Additional settings** > **Accessibility**.

2. Tap **Physical** to adjust interaction controls and input device in **Physical** page.
3. Manage interaction controls.
 - Tap **Touch & hold delay** to select a time for a continuous touch to be responded as a touch and hold.
 - Tap **Time to take action (Accessibility timeout)** to select a time for showing messages that ask you to take action.
 - Tap to enable **Power button ends call**.
 - Tap to enable **Auto-rotate screen**.
 - Tap **Vibration & haptic** to turn on feedback of rings, notifications, and touch action.

Manage input device

1. Go to  **Settings** >  **Additional settings** > **Accessibility**.
2. Tap **Physical** to adjust interaction controls and input device in **Physical** page.
3. Manage input device.
 - Tap **Autoclick (dwell timing)** to select a time for a mouse cursor to click automatically when the cursor stops moving for a certain amount of time.
 - Tap to enable **Larger mouse pointer**.

Digital Wellbeing & parental controls

Digital Wellbeing & parental controls can reduce interruptions from your phone. You can add content restrictions and set other limits to help your child balance their screen time.




View the screen time

You can check how long you use your phone.

1. Go to  **Settings** >  **Digital Wellbeing & parental controls**.
2. Tap the dashboard circle or **Dashboard** to view the screen time.



Enable Bedtime mode

Apply Bedtime mode to silence the phone and change the screen to black and white at bedtime. Only alarms and important calls can reach you.

1. Go to  **Settings** >  **Digital Wellbeing & parental controls** > **Bedtime mode**
2. Tap  to enable **Do Not Disturb for Bedtime mode** .
3. Tap **Next** to set up the time and other options.
4. Tap **TURN ON NOW**.

Enable Focus mode

Apply Focus mode to pause distracting Apps and hide notifications.



1. Go to  **Settings** >  **Digital Wellbeing & parental controls** > **Focus mode**.
2. Select distracting Apps on the App list.
3. Tap **TURN ON NOW**.

Tip


You can also tap **Set a schedule** to set a time period for Focus mode.

Set up parental controls

Parents can supervise the phone with the **Family Link** App, keep an eye on screen time and set limits as needed, add restrictions to Google services, like App approvals or content filters on **Google Play**.

1. Go to  **Settings** >  **Digital Wellbeing & parental controls**.
2. Tap **Set up parental controls** and follow the onscreen instructions to set up parental controls.

Note



The onscreen instructions guides you to [Google Family Link](#) page on  **Play Store** .
Google Family Link provides permissions for parents to access the phones of their children. You need to download and install the App on both your phone and the phone of your child.






Chapter 13 Special features

Note

The following features may not be available to some models.

Learn to use floating windows

You can go to  **Settings** >  **Additional settings** > **Floating windows** to learn how to open notifications in a floating window.

	<p>Opening floating windows</p> <p>Press and hold, and then pull down the action bar of a notification.</p>
	<p>Moving floating windows around</p> <p>Press and hold the action bar of a floating window to drag.</p>
	<p>Viewing floating windows in fullscreen mode</p> <p>Press and hold, and then pull down the action bar of a floating window.</p>
	<p>Minimizing floating windows</p> <p>Drag the floating window to the corner of the screen.</p>
	<p>Minimize an app *</p> <p>Press and hold the bottom of the window, and drag it to the upper right corner.</p>

Note

* The feature works only when system navigation is set to gestures.

Enable Sidebar


You can open a second App when you swipe the Sidebar.

1. Go to  **Settings** >  **Additional settings** > **Floating windows** > **Sidebar**.

2. Choose the scenes to enable Sidebar.

- Tap to enable **Always show**.
- Tap to enable **Show while playing games**.
- Tap to enable **Show while playing videos**.

Open an App in Sidebar




1. Swipe the Sidebar indicator right to open the **Sidebar**.
2. Tap an App in the Sidebar.

Tip

You can also add an App to the **Sidebar**.

Open an App in floating window





You can open an App in floating window without interrupting the gaming experience.

1. Open a game in  **Game Turbo**.
2. Swipe right the sidebar to open **Sidebar**.
3. Tap an App icon to open the App in floating window.

Note

If you want to learn how to move floating windows, view floating windows in fullscreen mode, minimize floating windows, or minimize an App, see [Learn to use floating windows](#) for more information.

Manage floating window shortcuts

1. Open a game in  **Game Turbo**.
2. Swipe right the sidebar to open **Sidebar**.
3. Tap  in the App list.
4. Manage App floating window shortcuts.
 - Tap  to add the App to the floating window shortcuts.
 - Tap  to remove the App from the floating window shortcuts.
5. Tap **Done**.

Note

- You can add up to 10 Apps.
- You can press and hold the App icons to rearrange the positions.


Toolbox

You can use **Sidebar** when you enter a game or play a video for quick settings.

Note


- Some models have more powerful and diverse **Sidebar** features. You can check whether the features are available to your models.
- The UI name for the feature may be **Sidebar** or **Toolbox** depending on your device.

Use Toolbox in Game Turbo

1. Open a game in  **Game Turbo**.
2. Swipe right the sidebar indicator to open **Toolbox**.
3. Choose to use toolbox features.
 - Tap **Clear memory** to free up more space for games.
 - Tap **Free up storage** to perform a deep clean.
 - Tap **Boost** to boost game performance.
 - Tap **DND** to restrict floating notifications.
 - Tap **Screenshot** to take a screenshot of games.
 - Tap **Record** to record a screen video of games.

- Tap **Settings** to set up Game Turbo.
- Tap **None** to choose to bright or saturate the screen.
- Tap **Turn off screen** to turn off the screen but keep the game running in the background.
- Tap **Cast** to cast the screen to other device.
- Tap **Wi-Fi** to turn on and off the Wi-Fi quickly.
- Tap **On-screen comments** to see notifications from other Apps without quitting the game.
- Tap **Voice changer** to change your speak voice.
- Tap **Timer** to set timers.



Use Video Toolbox

1. Play a video in  **Gallery**.
2. Swipe right the sidebar to open **Toolbox**.
3. Choose to use toolbox features.
 - Tap **Record** to record a screen video of games.
 - Tap **Screenshot** to take a screenshot of games.
 - Tap **Cast** to cast the screen to other device.
 - Tap **Play video sound with screen off** to lock the screen but play the sound in the background.
 - Tap **Upscale** to view the video automatically in higher resolution when the video resolution is less than or equal to 720p.
 - Tap **Style** to view the video in different filter effects.
 - Tap **Picture** to enhance the contour. But the feature does not work when the video resolution is higher than 4K.
 - Tap **Dolby Atmos** to enhance the sound effects such as dialogue or stereo.

Set up front camera assistant



Apply Beautify effects or adjust light when you use the front camera.

1. Go to  **Settings** >  **Additional settings** > **Front camera assistant**.

2. Tap  to enable **Front camera assistant**.
3. Choose to set up front camera assistant.
 - Drag the slider left or right to adjust the front fill light brightness.
 - Tap  to enable **Beautify for video calls**.


Turn on Second space

You can create a separate space in your phone where you can use different accounts and IDs and store data. The data in the Second space does not affect the primary space.

1. Go to  **Settings** >  **Additional settings** > **Second space**.
2. Tap **Turn on Second space**.
3. Tap **Continue**.
4. Choose the way to switch between spaces.
 - Tap **Using a password**.
 - Tap **Using a shortcut**.
5. Tap **Continue** to set the password for the second space.


Note

- The passwords for the two spaces must be different. If you are on the primary space, you can enter the password for the second space on the Lock screen to enter the second space.
- You can tap **Skip** if you choose **Using a shortcut** to switch between spaces without a password.

After you enable **Second space**, the **Switch** icon appears on the Home screen of your phone. You can tap  to switch to the primary space.

Measure heart rate

You can use the fingerprint sensor to measure your heart rate.

1. Go to  **Settings** >  **Additional settings** > **Heart rate**.
2. Cover the fingerprint sensor  with your finger for 15 seconds.

The result shows on the screen.

Chapter 14 Reboot, update, reset, and restore

Power off the phone

1. Press and hold the **Power button** until the function menu shows.
2. Choose  **Power off**.

Note



When the phone cannot be used normally, you can press and hold the **Power button** for 15 seconds to force the device to restart.

Reboot the phone

1. Press and hold the **Power button** until the function menu shows.
2. Choose  **Reboot**.

Update MIUI version



Update the MIUI system to the latest MIUI version to use the newest features.

1. Go to  **Settings** >  **About phone**.
2. Tap the **MIUI version** information.
3. Tap **Check for updates** to update to the latest MIUI version.

Note





The system informs you of the latest MIUI version update information. You can also enter the update page from the notification and choose whether to update or not.

Update system Apps

1. Go to  **Settings** >  **System apps updater**.
2. Check the update information of Apps and update the system Apps.

Manage System apps updater



You can choose to update Apps only when you connect to the Wi-Fi networks.

1. Go to  **Settings** >  **System apps updater** >  > **Settings**.
2. Manage **System apps updater**.
 - Tap  to enable **Show update notifications**.

- Tap **Auto updates** to choose **Don't update** , **Updates using Wi-Fi** , or **Updates using Wi-Fi and mobile data**.

Back up and restore

You can back up and restore data saved on your device and computer. You can also backup the data to **Xiaomi cloud**.



1. Go to  **Settings** >  **About phone**.
2. Tap **Back up and restore**.
3. Choose to back up and restore the local and cloud items.

Note

The feature needs to connect to the internet and requires some permissions to work normally.

Factory reset

You can remove all data from your phone and reset your phone to factory settings.



1. Go to  **Settings** >  **About phone**.
2. Tap **Factory reset** and follow the onscreen instructions.

Note

You need to back up all important items such as accounts, contacts, photos and videos, Apps, backups, SD card data, and other items.

Chapter 15 About device and accounts

About the phone

You can go to  **Settings** >  **About phone** to view the information such as MIUI version information, important safety information, the certification information, and other information.



Memory extension

You can go to  **Settings** >  **Additional settings** > **Memory extension** to add more RAM by occupying storage.



Note

Use this feature only when there is enough storage space available on your device.

Xiaomi Account

Xiaomi Account is an authentication method used for Xiaomi devices. It works with MIUI, Xiaomi Cloud, Xiaomi Community, and other services. You can go to  **Settings** >  **Xiaomi Account** to sign in with your Xiaomi Account.

Google




You can go to  **Settings** >  **Google** to sign in with your Google Account and set the preference services such as ads, autofill, and devices and sharing on the phone.

Accounts & sync

You can sync the calendar, contacts, drive, mail, and other information of Google and other accounts.

Enable Auto-sync data

Any changes you make to your accounts on the web will be automatically copied to your device.




1. Go to  **Settings** >  **Accounts & sync**.
2. Tap  to enable **Auto-sync data**.
3. Tap **OK**.
4. Tap **Sync** in the pop up window.

Note

You can also tap **Sync now** at the bottom of the phone to sync data manually.

Enable Wi-Fi only



The account syncs data only when you connect to the Wi-Fi network.

1. Go to  **Settings** >  **Accounts & sync**.
2. Tap  to enable **Wi-Fi only**.

Note

You need to enable **Auto-sync data** before you enable **Wi-Fi only**.

Services & feedback

You can go to  **Settings** >  **Services & feedback** to search for issues and send feedback. See [Services & Feedback](#) for more information.

Disclaimer

This generic user guide is published by Xiaomi or its local affiliated company. Improvements and changes to this user guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Xiaomi at any time and without notice. Such changes will, however, be incorporated into new online editions of the user guide (please see details at www.mi.com/global/service/userguide).

Because this generic user guide describes the comprehensive features on Xiaomi phone models, the phone appearance, features, functions, operating procedures, and configuration parameters may not be available to your actual phone models. The illustrations, including but not limited to the color, size, images, and icons, may be slightly inconsistent with your actual device. All illustrations in this manual are for reference only.