

Bluetooth crystal Speaker

Instruction manual

Thanks for using this Crystal Bluetooth Speaker. This manual includes accessories, item description, how to use and cautions. Please read it carefully before using and keep the manual properly.








Accessories:

Bluetooth crystal speaker: 1 pc USB charging cable: 1pc Manuel: 1 sheet

Item description:

Size: 3.8*3.8*8CM	Unit Weight: 52G	Bluetooth Version: V2.1+EDR
Transmission Range: 10M	Frequency Range: 150Hz-18KHz	SNR: ≥ 70 dB
Battery Capacity: 360MAH	Rated Voltage: 5V	Rated Power: 2W
Charging Time: 3H	Playing time: 3H	Loudspeaker: 4 Ω 2W

How to use

1. Turn on: long-press the button  at the bottom, notification tone heard and LED giving out light. Ready to work
2. Turn off: long-press the button  at the bottom and LED light is off.
3. How to connect Bluetooth.
 - A. While the speaker is on, turn on the Bluetooth of mobile device (cell phone, laptop, etc) and search Bluetooth device "BT SPEAKER".
 - B. Click the "BT SPEAKER", pairing and connecting automatically. Connecting successfully with a notification tone.
 - C. When connected, the speaker plays music what is playing on the cellphone or other devices. Press button  to pause/play music.
 - D. The speaker connects paired Bluetooth devices automatically when both turned on. After connected, speaker plays the latest played music with a press on button .
4. Bluetooth Call
 - A. When dial-in, speaker plays call ringtone. Press button  to answer the call. Press button  again to ring off.
 - B. When speaker is on and connected, press button  twice quickly and the latest dial-out number will be dialed again.
 - C. Call-answer shift between speaker and cellphone. Press the icon earplug/Bluetooth on cellphone when answering a call. The call-answer can be shifted between speaker and cellphone.
5. Charging mode: Connect low-powered speaker with computer with USB charging cable. The power indicator is red during charging. When fully-charged, the indicator is off.

Cautions:

1. Please do not disassemble the speaker personally to avoid possible damage.
2. Keep the speaker away from hot temperature, such as fire or heater.
3. Do not immerse the speaker into liquid. When long-term unused, speaker should be put in cool and dry place. And a regular charging every 2 month will extent the battery's lifespan.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.