
# **USER MANUAL**

# bluetooth audio speaker

# Arctic Blu



















## ArcticBlu

#### **IMPORTANT:**

Thank you for purchasing *ArcticBlu*! We have gone to great lengths to provide you a quality cooler and audio system that will last and perform for years to come. To insure the longevity and performance, please read the user manual and adhere to the instructions, warnings, care and maintenance. Any negligence or deviation from the manufacture's recommendations may result in voiding the warranty. *ArcticBlu* audio carries a limited warranty for one year from the original date of purchase, this product will be free from defects in material and workmanship. A complete warranty and registration form may be downloaded from *www.ArcticBluaudio.com*.

The AC/DC adapter is included for your audio unit. Only use the AC/DC adapter provided.

#### SAFETY ADVISORY & WARNING

Please take the time to follow the instructions in this owner's guide carefully. It will help you set up and operate your system properly and enjoy its advanced features. Please save this guide for future reference.



**CAUTION**: Do NOT open to repair. A qualified technician must carry out repair work.

**WARNING**: This unit has a built-in Lithium Ion battery. The battery must NOT be used in or near an open heat source or excessive heat. Danger of explosion if battery is incorrectly replaced.

## Arctic Blu M



**ATTENTION:** Do NOT charge while the unit is wet. Towel dry the unit AND make sure all connections are dry BEFORE plugging in the charging connector.

#### **CARE, MAINTENANCE & PRECAUTIONS**


- 1. The unit is waterproof when the silicone tab is properly closed.
- 2. Close the silicone tab properly before exposure to water. Without the silicone tab properly closed, water may enter into the unit and void your warranty.
- 3. Dry unit completely before opening the cap. Do NOT open the cap if wet or in a wet environment.
- 4. Do NOT apply excessive force to the LCD or control buttons when wet or in a wet environment.
- 5. Do NOT use or store the unit in places with high temperature.
- 6. AVOID prolonged exposure to ultraviolet radiation (UV sunlight) and strong magnetic fields.
- 7. Periodically check the silicone seal for premature wear.
- 8. Periodically clean the tab with a soft moist cloth and ensure no objects such as dirt, hair or sand are on the silicone seal tab. Do NOT use any oily solvent or chemicals for cleaning.
- 9. Rinse off the unit with tap water after use in salt water or swimming pool.
- 10. Noise and audio distortion may occur when the batteries are nearing end of charge.
- 11. Do NOT remove the built-in battery. Do NOT remove the grill covers.

This unit has been tested and approved for IPX 5, with the silicone tab in place.

ALWAYS CLOSE SILICONE TAB PROPERLY to ensure unit is watertight & waterproof!



# Controls ArcticBlu TM



Long press=2-3 seconds
Quick press=press & release

Power On: Long press the power button, the unit will announce "power on."

**Power Off:** Long press the power button, the unit will announce "power off."

**Reverse**: Quick press for incremental change / long press for search.

**Forward :** Quick press for incremental change / long press for search.

**Volume -:** Quick press for incremental change / hold down for rapid change.

**Volume +:** Quick press for incremental change / hold down for rapid change.

**Note\***3 beep tone will indicate maximum volume when bluetooth mode.


www. ArcticBlu audio.com

### Before you Begin:




Before using your *ArcticBlu* audio for the first time, charge the unit until the front LED battery charging indicator changes from red to green—indicating a full charge, when powered on, the LCD display will show a battery icon indicating the level of charge; 25%-> 100%.

Charge time is typically 2 to 3 hours. Play time is 8 to 10 hours at 60%-70% volume.



## **ArcticBlu**



Included with your unit

AUX cable

AC/DC Charger

# MODES

## ArcticBlu

- 1. Bluetooth®—the unit is defaulted to power on in BT mode.
- 2. FM Radio enjoy your local radio stations, save up to 5 of your favorite stations.
- 3. Auxiliary direct connect with the supplied 3.5mm Aux cable.

### How to pair your device



- **Step 1:** Find & enable Bluetooth® on your device.
- Step 2: In BT mode, hold down the "M" Button; "BT" icon will flash with an indication tone "pairing".
- **Step 3:** Find & select "ArcticBlu " when the device connects, the "BT" icon will stop flashing; following "your device is connected".

**Reconnecting**: Each time you power on the unit, it will automatically search for the last BT device connection and connect. If you want a different device connected, you must hold the "M" button for "pairing".

Play & Pause: Quick press the power button for pause and resume play.

Next Song: Quick press the » button for next song from your device.

Last Song: Quick press the « button for next song from your device.

**Note\*** Unlike most devices, Arctic Blu will not appear automatically on your music source device. You must hold down the "M" button until "pairing" is announced. To connect another device, you must disconnect your devices BT, then hold down the "M" button to make the unit re-discoverable. There are no codes required to connect.

### **MODES**

## Anctic Blu M



#### Dual Speaker Connection - connect two Anctic Blu coolers up to 60 feet apart!

**Note\*** (True Wireless), *DSC* only works in BT mode. The two units must have a clear line of sight. Obstacles, such as cars, walls, humans, large animals and aliens may cause interruption of play between the two coolers.

#### Make the first unit the "Master" and the second unit the "Secondary"



M Quick press the "M" and then the "Volume Up."
This icon will flash while connecting - stop flashing when connected.



On the second unit -quick press the "M" and then the "Volume Down." This icon will flash while connecting - stop flashing when connected. In 10 seconds both units will announce "Connection Successful."

Manually Disconnect: To exit DSC mode, press VOL+ and VOL- at the same time.



#### Tips on placing the speaker

When using your speaker indoors, the tonal quality can vary depending on where the speaker is placed in a room. When using your speaker outdoors, you should expect the tonal quality to change as you move farther away from the speaker. Visit <a href="https://www.ArcticBluaudio.com">www.ArcticBluaudio.com</a> for best performance speaker placement.



### **MODES**

## ArcticBlu M



**Tuning:** Quick press **»** or **«** for next increment channel.

**Auto Search:** Long press the **»** or **«**; the display will "flash" the current station will auto change to the next available station.

**Save 5 Fav's:** To save the current station you are listening to-as a favorite station - quick press both « and » buttons simultaneously.

Confirm station: Confirm setting: short press « and » together.

**Listen to Fav's**: To toggle through the saved favorite stations-quick press the mode "M" and either the » or « buttons.

Change a favorite: When listening to saved station and want to change it,press » or « button to adjust favorite station then quick press « and » buttons together, the previous saved station would be insteaded by current favorite station.



**AUX-IN:** Connect to play an audio device using a 3.5mm audio cable.

Reminder\* Dual Speaker Connection - only works in BT Mode.

### **Hands Free Phone**

## ArcticBlu \*\*



**Phone: Note\*** Your mobile device connected can perform all the functions listed below. Should you not have access to your mobile phone, the unit can manage the calls.

Answer Calls: Music will automatically fade and a ringtone will announce.

Ouick Press the "Power" button to answer.

Terminate Call: Quick Press the "Power" button."-

**Refuse Calls:** Long press the "Power" button.

Cancel a dial: Quick Press the "Power" button.

Transfer call: During a current call, long press "Power" button, the call will transfer to mobile device.

Mute the call: Long press of the "Forward" button. Re-press the "Forward" button to resume Mic

**Redial last call:** Pause the music then long press Volume "+" buttons.

**Note\*** You can also control the call features from your mobile device.

**Note\*** The unit will automatically power down if not in use for 15 minutes.

Full manual and troubleshooting: ArcticBluaudio.com

## Arctic Blum

#### **Technical information**

CSR Bluetooth® ® v4.0

**CVC®**: noise echo cancelation **aptX®** enhanced audio quality

HFP: Hands free phone

Supports: A2dp,SBC, MPS and AAC

FM Radio: 87.5 to 108 MHz Output Power: RMS 20W Speakers: 2 x10 @ 4 ohms

Frequency Range: 60Hz - 20,000Khz

S/N Ratio: 88db +/- 3dB

**THD:** < 1%

Speaker Grill: 1.3 mm anodized aluminum

Power Source: 11.1V 4000mA Battery

Storage Battery Temperature: 14°F to 131°F

Charging: AC/DC power supply

Input: AC - 100 - 240V, 50/60 Hz, 600 mA

Output: DC - 15V 2000Mah USB Charge out: 5V ~2.1 Mah

Operating Temperature: 23°F to 104°F

Charging Time: 3 hours

Playtime: 8 to 10 hours at 60%-70% volume

Waterproof Rating: IPX5
Dimensions: 9.85 x 7.87 x 2.1

Weight: 2.86lbs.





**ATTENTION:** Do NOT dispose of in a landfill. Contact your local certified recycling agent to dispose of the unit.





#### FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.