

# A69 Headset User manual



## Warning

Read the below warning thoroughly before you start using your headset. Store this manual with product packaging. The safety precaution manual reduce the risk of fire or injury when correctly complied to.

To reduce the risk of injury :

Keep batteries out of reach of children.

Do not heat, open, or dispose of battery pack in fire.

Do not allow metal objects to touch the battery on the device.

Do not expose battery pack to excessive heat.

---

## Specification:

Bluetooth version: V5.4

Bluetooth solutions: JL7003

Bluetooth working frequency: 2.402GHz-2.480GHz

Frequency response: 20Hz-20KHz

Earphones battery capacity: 200mAh

Speaker size: 40mm

Effective distance: 10M

Play time: 15-20 hours

Earphones charging time: About 2~3H

Earphone battery output voltage/current: 3.7V-4.2V

USB-C Charging cable: 30cm

Audio cable: 1m

# Operation

## 1: Power on/off .

M button :

Long press 3 seconds to turn on

Long press 3 seconds to turn off.

## 2: Play/Pause music.

M button :

When listening to music.

Tap Power switch **once** to play or pause the music.

## 3: Previous /Next Song （单击上下曲）

When listening to music.

**Single** tap **+** key to go to previous song.

**Single** tap **-** key to go to next song.

## 4: Volume -/+ （长按加减音量）

Press 2 seconds **+** key to decrease the volume.

Press 2 seconds **-** key to increase the volume.

## 5: Answer/Hang up （单击接挂）

**M BUTTON:**

When there is an incoming call.

Tap **once** to answer the call.

Tap **once** again to end the call.

## 5: Reject （长按2秒拒接）

**M BUTTON:**

When there is an incoming call.

**Long press** M button for **2 seconds** to reject the call.

6. Dial the last call:

M BUTTON:

Double tap to dial the last call.

### **6:Voice assistant （三击开启语音助手）**

M BUTTON:

**Triple** tap to activate voice assistant.

## **Charging Function**

Fully charge the headset before using for the first time.

Pairing: Blue and red light flash.

Connected successfully: Blue light flash.

Charging: Red light steady on

Charging full: Blue light steady on

配对时红蓝闪烁，配对后蓝灯闪烁。

充电是红灯常亮，充满后蓝灯常亮。

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the device and receiver.

--Connect the device into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment