

Line description

(BY-AU-BS-150-BK)

After turning on the phone, turn on the Bluetooth of the mobile phone and collect the Bluetooth speaker (BY-AU-BS-150-BK). After the connection is successful, turn on the mobile player to play music. When playing, you can press the key to switch between up and down music/volume up and down, or pause/play a song. Insert the TF/USB to play the MP3 file songs in it. When playing, you can press the button to switch the up and down music/volume increase and decrease, or pause/play the song. Press mode plus and minus to switch to AUX mode, you can play the external input source, you can press the button to increase or decrease the volume, or mute the speaker. Press mode plus and minus to switch to FM mode, press the play button to close the station, and you can press the button to switch up and down music/volume up and down during playback. Insert the charger to charge the machine, the red light will be on when charging. The red light is full.

For Bluetooth BDR/EDR:

works in the 2.4GHz (2402MHz~2480MHz) ISM band

79 channels for Bluetooth BDR/EDR

1MHz channel spacing

Modulation type: GFSK, $\pi/4$ -DQPSK, 8-DPSK