

A3

THIS IS FOR THE BLUETOOTH SPEAKER

Bluetooth speaker instructions is folded at fold lines shown.

The instructions go in between front and back panels in the clam shell

ACTUAL SIZE

Do not print red outline or dotted lines for placement only

Front

fold line

Structure

Interface Dust Cover ①

Micro USB ③

Power Switch ②

Partial View

Volume Up ④

Answer/Hang Up ⑥

LED Indicator ⑨

Mic ⑦

Volume Down ⑤

Suction Cup ⑧

Specification

Product Size: Φ2.44x2.32 in.
Weight: 3.2 oz.
Loudspeaker: 1.57 in.
Rated Power: 4Q
Interface: Micro USB

Bluetooth Parameter:
Operation Frequency: 2402~2480MHz
Power Output(peak): Class 2/4 dbm
Receiving Sensitivity: -91db, @0.1%BER
Operation Range: Up to 30 ft

Battery Parameter:
Capacity: 300mA, 3.7V, Polymer Li-ion Battery
Music Playback Time: 5-7 Hours at 70% volume
Charging Standard: DC 5V, 500mA
Charging Time: 1.5-2 Hours

Accessory:
USB Cable 1 pcs
User Guide 1 pcs

fold line

Manual

Back

fold line

Structure

① Interface Dust Cover: Protect Power Switch and Micro USB Port
② Power Switch: Switch On/Off
③ Micro USB: Charging Port
④ +: Volume Up
⑤ -: Volume Down
⑥ <: Answer/Hang Up The phone call under Bluetooth Mode.
Hold Down this button to disconnect Bluetooth connection
⑦ Mic: Serves as microphone during Hands-free call
⑧ Suction Cup: Capable of suction on any smooth surface (glass, wall, ceramic, etc.)
⑨ Led Indication: Built-in battery indicator
*Red light on: Charging
*Blue light on: Fully charged
*Blue light flashing quickly: Bluetooth pairing
*Blue light flashing slowly: Bluetooth pairing successfully

Usage

Connection with computer:
Activate Computer's Bluetooth (if the computer does not have built-in Bluetooth, plug in a Bluetooth adapter) - Turn Speaker to pairing mode (Blue light flashing quickly) - Search Bluetooth speaker pairing - Connect and Play

Connection with mobile phone:
Activate Mobile phone's Bluetooth - Turn Speaker to pairing mode (Blue light flashing quickly) - Search Bluetooth speaker - find Bluetooth speaker pairing - Connect and play

Application

Applicable to all Bluetooth devices.

Notes

1. Hands-free call is only available on Bluetooth connected status. The phone call could be interfered with high frequency electromagnetism. People should not try it use this product under high-frequency environment.
2. Bluetooth is a bidirectional transmitting device; transmitting distance is highly related to audio player. Compatible Bluetooth players are recommended
3. Some terminal players are without automatically switching play function; In this case, POP noise will exist in the interval of every 2 songs.
4. When Bluetooth transmitting devices cannot be connected, please delete the rest Bluetooth receiving device name on the list. Re-activate Bluetooth speaker, Re-searching and Re-pairing.
5. The sound performance could also be affected when Bluetooth transmitting devices is under poor signal environment, or under low battery capacity.
6. Waterproof: Only the silicone gel housing is waterproof, not including the inner structure and components.

Warning

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
The device must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ☐ Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

fold line