



VPB-12/0567

3-IN-1 VENTURE PRO

PORTABLE CHARGER • WIRELESS SPEAKER • FLASHLIGHT



INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE USE

1

Getting Started

- Remove the device from the box.
- Remove any packaging from the product.
- Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents

- Portable Charger with Wireless Speaker and Flashlight
- USB rechargeable cord
- Instruction Manual

Key Features

- Portable charger, Bluetooth wireless speaker and flashlight charges any USB device, plays your favorite songs and provides bright LED light anywhere you go
- Bluetooth wireless speaker works with iPhone, iPad, Android, Windows smartphones, tablets, computers and also has a 3.5mm audio jack for use with almost any device
- 4000mAh portable charger with built-in overcharge protection
- Dual LED flashlight perfect for outdoors, emergencies and more
- Plugs into any USB device to recharge with included USB cable


SAFETY INSTRUCTIONS

- Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.
- Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not use the unit with wet hands.
- Do not put objects into any of the openings.
- Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use.
- Keep the unit out of reach of children.
- This appliance is not a toy.

2

- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat place, such as sunshine, fire or the like.

Description of Parts



1	Dual LED Flashlight	5	Function Switch
2	Speaker	6	Function LED Indicator
3	Aux In Port	7	Charging LED Indicator
4	Charging Port	8	USB Charging Port

3

INSTRUCTIONS FOR USE

Charging the device

The device has built-in rechargeable battery. When the battery is drained out, device would turn OFF automatically. You would have to recharge the battery.

Plug the included USB cable into the charging port.

Plug the other end into a USB port on your computer or other devices made for USB charging. The Charging LED Indicator flashes Red, indicating that the device is being charged.

It takes about 8 hours to fully charge the device. Once the device is fully charged, Red LED Light would stay on.

Turning ON/OFF the Speaker

- Before Turning ON the Speaker, please ensure that the unit is fully charged.
- To Turn ON the Speaker – Slide the Function Switch to middle position for Bluetooth function, and to the foremost position for Bluetooth with Flashlight functions.
- To Turn OFF the Speaker – Slide the Function Switch to "OFF" position.

Connect using Bluetooth Technology manually

- Turn ON the device. You would hear indication tone and a sound message "Bluetooth mode" indicating that you are now in Bluetooth Pairing Mode and Blue LED Light keeps flashing.
- Activate the Bluetooth function on your Bluetooth device (Mobile Phone or Tablet). Please refer to manufacturer's instructions for instructions on enabling Bluetooth on your device.
- Once you have activated Bluetooth on your device, select the device "VENTURE PRO" from the list of available Bluetooth devices.
- If required, enter the password "0000" to conform to finalize pairing. (Password is required only during pairing devices for the first time)
- Once paired successfully, the Blue LED light will stay on.
- Choose music from your Bluetooth® device and play music wireless through the speakers.

4

[Note: You need to control the volume increase/decrease, play/pause, next/previous track through your source device only.]

Listen to Music using Auxiliary

- Turn ON the device.
 - Put the 3.5 mm Aux in cable (not included) to the Aux In Port of the device (you would hear sound message "Aux mode"). And, the other end of the cable connects in the audio device (such as computer / tablet /...etc.).
 - The Blue LED will flash. Select your favorite song at the source device and play it through the Speaker. (Note: When you put 3.5 mm Aux in cable into the Aux port of the speaker, the Bluetooth connectivity of the speaker will be lost when Aux is in use. You need to control the volume increase/decrease, play/pause, next/previous track through your source device only.)
- (Note: Suggest you turn off the Bluetooth of your mobile phone when the Aux is being used.)

USB Recharging for external devices

Use the USB Charging port to charge your external devices like smart phones etc. Using this saves you from having an extra charger to keep your devices powered.

Specifications –

- Bluetooth® Version: 3.0
 - Wireless Distance: 27 to 33 feet
 - Working time : ~Music 10 hours
 - Speaker: 2 Watts
 - Unit size: 5-1/2" x1-7/8" x1-1/8"
 - Unit weight: 5.6 Oz
 - Power Input: DC 5V
 - Built-in Rechargeable Battery: 3.7V 4000mAh
 - Charging Time: 8 Hours
 - USB Charging Port: 5V / 1A (Max) Output
- (Note: Battery life, working time & charging time may vary based on usage & types of devices used.)

5

Care and maintenance

Read the following recommendations before using the product. Following these you will be able to enjoy the product for many years.

- Do not expose the unit to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Don't use abrasive cleaning solvents to clean the unit.
- Do not expose the unit to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't dispose of the unit in fire as it will result in an explosion.
- Don't expose the unit to contact with sharp objects as this will cause scratches and damage.
- Don't let the unit fall down onto the floor. The internal circuit might get damaged.
- Don't attempt to disassemble the unit as it may get damaged if you are not professional.

FCC Instructions

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.

6

- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

LIMITED WARRANTY

This manufacturer's product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer's warranty.

WARRANTY DURATION: All materials and workmanship are warranted to the original consumer purchaser for a period of ninety (90) days from the original purchase date.

WARRANTY COVERAGE: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty doesn't cover the following which may be supplied with this product, including but not limited to: LCD Screens, glass parts, lenses, bulbs etc. This warranty is effective only if the product is purchased and operated in USA and Canada, and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

WARRANTY DISCLAIMERS: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contractor commercial law including but not limited to, negligence, gross negligence, strict liability, breach of warranty and

7

breach of contract. Under no circumstances will Manufacturer's / Distributor's maximum liability exceed the retail value of the product.

WARRANTY PERFORMANCE: During the above 90 day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the 90 day warranty period and an additional one-month period. No charge will be applicable for such repair or replacement.

SERVICE AND REPAIR: If service is required for this product, you should first contact Midwest Trading Group Customer Service at info@mtmidwestgroup.com or by calling 1 (866) 815-4714, Monday to Friday 10am to 6pm EST.

NOTE: Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment, and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

8

90mm

size: 90*69.5mm

69.5mm