

## Wireless Speaker with Clock and Wireless Charger

### EAC-SU2S



#### Instructions for using the wireless charging speaker



#### Wireless charger use: plug in the charger to automatically turn on

- Long press power / short press light switch
- Long press function switch BT / NS / FM mode, short press pause / play
- Short press the timing 15 / 30 / 60, long press the Bluetooth couplet
- Short press the next song, long press to add the volume
- Short press the last song, long press to reduce the volume
- Alarm clock setting
- Clock Settings

#### technical parameter:

Wireless charging power: 15W  
Bluetooth version: 5.3  
Bluetooth name: S-300  
Output power: 10W \*2  
Bluetooth frequency: 2.4GHZ-2.48GHZ  
Transmission distance: 10 meters  
Frequency sound range: 50 HZ-20 KHZ  
Sigto noise ratio of whole machine: greater than 75 db  
Built-in lithium battery voltage: 3.7V charging input: DC5V / 500MA  
Product size: 180\*100\*90mm  
Product weight: 820g

#### Operation description of the key function

- Start up: long press the start button for two seconds to start up, start up the default heating light
- The Bluetooth function is used for use:
  - This audio supports the use of Bluetooth devices with A2DP function, boot default into the Bluetooth mode, Bluetooth indicator blue light shining, accompanied by voice prompt, when the stereo is waiting for pairing connection, only in this state, can be paired and connected with the Bluetooth audio.

#### 2. Mobile phone connection

The first step is to open the phone Bluetooth setting switch in the phone Settings and click the search device  
The second step, when the available device displays the S-300 character indicating that the phone finds the Bluetooth stereo, click S-300 to enter the pairing mode. After the phone is successfully paired with the stereo, there will be a voice prompt and display the connected.

#### 三、 TWS couplet function (this function is suitable for Bluetooth mode only)

When you have two S-300 Bluetooth speakers, by long pressing one of the keys to match, Bluetooth connected to each other, the two speakers will automatically become the left and right sound channels to produce stereo surround sound effect, achieving real wireless stereo.

#### Light use

- The S-300 Bluetooth speaker is equipped with 13 lighting effects
- Start the default warm lamp effect of the equipment, and press the light key to adjust the light

#### FM radio to use:

M key long press to switch to the FM function, connect the charging cable to the product type-c interface as a radio antenna, the other end does not need to connect any equipment, through the pause button to enter the station automatic search and automatically save, the cable station through + -saved station selection.

#### TF card / U disk function for use:

By inserting the TF card / U disk into the card slot, the corresponding voice prompt will

appear. The product will automatically read the audio file in the card and play it. The user can use the voice to control the music with the speaker + -button.

#### Clock Setting

Press the time key to enter the clock / minute setting, press / adjust the hour / minute + / - /

#### Alarm clock setting

+ / - / Press the alarm button to enter the clock / minute setting, press / adjust the hour / minute, press the alarm key and then press / select your favorite alarm, there are 7 groups of alarm bells, and finally press the alarm key to open the alarm clock (the alarm mark appears on the screen after successful setting). When the alarm rings, press any key to close the alarm. When no one turns off, the alarm will automatically turn off for 1 minute (the alarm will ring normally in the shutdown state, please cancel the alarm clock without the need)  
Cancel alarm setting: long press the alarm key (the alarm sign disappears on the screen after successful cancellation)

#### White noise use:

M to switch to white noise mode, press / choose your favorite sleep music + / - /

#### Safety Instructions:

- Do not expose the product into the water or humid areas, such as bathrooms.
- Please do not hit or drop the product hardly to avoid manual damage.
- When not in use for a long time, please turn off the power.

#### Warranty and After Sales Service :

If you have any questions during use, please feel free to contact us, we are responsible for every customer.

#### Instruções para utilizar altifalantes de carregamento



- Long press power on / short press light switch
- Pressione longa para alternar o modo NS/FM, pressione curta para pausar/reproduzir
- Tempo de pressão curto 15/30/60, pressão longa emparelhamento
- Pressione uma música curta, pressione longa para aumentar o volume
- Pressione curto a música anterior, pressione longo para diminuir o volume
- Configuração do alarme
- Configuração do relógio

#### Parâmetro Técnico

Potência de carregamento: 15W  
Versão : 5.3  
Nome: S-300  
Potência de saída:10W \*2  
Frequência : 2.4GHZ-2.48GHZ  
Distância de transmissão:10 metros  
Intervalo de resposta de frequência:50HZ - 20KHZ  
Relação sinal-ruído total: superior a 75db  
Tensão interna da bateria de lítio: 3.7V  
Entrada de carregamento: DC5V / 500MA  
Tamanho do produto: 180 \* 100 \* 90 mm  
Peso do produto: 820g

#### Instruções de funcionamento da função chave

- Power on: Pressione e segure o botão de ligar por dois segundos para ligar o dispositivo, e a luz quente padrão estará acesa ao iniciar o dispositivo
- Utilização da função :
  - Este sistema de áudio suporta dispositivos com função A2 DP para entrar por padrão quando ligado No modo, a luz azul da luz indicadora pisca, acompanhada por um prompt de voz, e o sistema de áudio está aguardando a configuração Para o status da conexão, emparelhamento e conexão com áudio só podem ser feitos nesse estado.

#### 2. Ligação telefónica móvel

Passo 1: Ligue o interruptor de configurações nas configurações do telefone e clique para procurar dispositivos.  
Passo 2: quando o dispositivo disponível exibe o caractere S-300 indicando que o telefone encontrou o áudio, clique em S-300 Depois de entrar no modo de emparelhamento e emparelhar com sucesso o telefone com o sistema de áudio, um prompt de voz aparecerá indicando que ele está conectado.

#### 三、 Função de emparelhamento TWS (esta função só é aplicável ao modo )

Quando você tiver dois alto-falantes S-300, pare-os pressionando uma das teclas interagirá entre si Quando conectados, os dois alto-falantes mudarão automaticamente para os canais esquerdo e direito para produzir um efeito de som surround tridimensional, conseguindo Verdadeiro estéreo sem fios.

#### Utilização da luz

- Alto-falante S-300 equipado com 13 efeitos de iluminação
- O efeito de aquecimento padrão quando o dispositivo está ligado, pressione o botão de luz levemente para ajustar a luz

#### Utilização do rádio FM:

Pressione e segure a tecla M para alternar para a função FM e conecte o cabo de carregamento à interface tipo c do produto como uma antena de rádio Na outra extremidade, não há necessidade de conectar nenhum dispositivo. Pressione o botão de pausa brevemente para entrar na pesquisa automática de rádio e Salve automaticamente, selecione estações de rádio salvas através "+/-".

#### Utilização da função do cartão TF/unidade USB:

Insira a unidade TF/USB no slot para cartão e um prompt de voz correspondente aparecerá. O produto irá ler e reproduzir automaticamente os arquivos de áudio dentro do cartão. Os usuários podem usar os botões de alto-falante "+/-" para controlar o tamanho da música e o som.

#### Configuração do relógio

Pressione rapidamente a tecla de tempo para inserir a configuração do relógio/minuto, pressione + / - / para ajustar a hora/minuto

#### Configuração do alarme

Pressione rapidamente o botão de alarme para entrar na configuração do relógio /minuto, pressione + / - / para ajustar a hora/minuto, ajuste Depois de um bom tempo, pressione brevemente o botão de alarme e, em seguida, pressione + / - / para selecionar seu alarme favorito. O toque é opcional e, finalmente, pressione o botão de alarme para ativar o alarme (após a configuração bem sucedida, o símbolo de alarme aparecerá na tela Zhi). Quando o alarme tocar, pressione qualquer tecla para desligar o alarme. Quando não há ninguém para desligá-lo, o alarme soará Se tocar durante 1 minuto, desligará automaticamente (o despertador também soará normalmente quando estiver desligado). Quando não houver necessidade de um despertador, por favor Cancelar o despertador)

**Para cancelar a configuração do alarme:** Pressione muito tempo o botão de larme (após o cancelamento bem sucedido, o símbolo de alarme na tela desaparece)

#### Utilização de ruído branco:

Pressione e segure a tecla M para mudar para o modo de ruído branco, pressione + / - / para selecionar sua música favorita de ajuda de sono

#### Instruções de segurança:

- Não exponha o produto a água ou áreas úmidas, tais como banheiros.
- por favor, não bata ou solte com força o produto para evitar danos manuais.
- quando não estiver em uso por um longo tempo, por favor, desligue a fonte de alimentação

#### Garantia e serviço pós-venda:

Se você tiver alguma dúvida durante o uso, não hesite em contactar-nos Os clientes são responsáveis.

### EAC-SU2S



# FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.