

# **Wileyfox Pro Instruction User manual**

# Table of Contents

Quick Guide .....	3
1.1 Install SIM card and battery .....	3
1.2 Charging the battery.....	3
1.3 On and off the screen .....	3
1.4 Phone locking and unlocking .....	3
1.5 Press the power button on the lock screen to light up the screen and swipe up to unlock the screen . .....	4
1.6 Key introduce.....	4
1.7 Status Bar.....	4
1.8 Call .....	4
1.9 Answer the phone.....	4
1.10 When a new call is coming, the touch answer menu can answer the call, and the handle hanging menu can hang up the picture to reject a call. ....	5
1.11 Send message.....	5
Main Functions.....	5
1.12 Settings.....	5
1.13 People.....	7
1.14 Messaging .....	8
1.15 Phone .....	8
1.16 Cortana.....	9
1.17 Storage .....	9
1.18 Maps.....	9
1.19 Films and TV .....	9
1.20 Excel .....	9
1.21 Groove Music.....	9
1.22 Get help .....	9
1.23 Calculator .....	9
1.24 Microsoft Edge .....	10
1.25 Alarms and Clock.....	10
1.26 OneDrive .....	10
1.27 OneNote .....	10
1.28 Outlook Calendar.....	10
1.29 Outlook Mail.....	10
1.30 Skype.....	11
1.31 Weather .....	11
1.32 Word.....	11
1.33 File Medic .....	11
1.34 Xbox .....	11

1.35	Camera .....	11
1.36	News.....	11
1.37	Store .....	11
1.38	Voice recorder.....	12
1.39	Photos .....	12
	Rights Statement .....	12
	FCC Warning:.....	12

## Quick Guide

### 1.1 Install SIM card and battery

Install SIM card or battery, make sure your phone is turned on.

- Open the back cover and remove the battery.
- Facing down the SIM card into the Card slot .
- Put the battery back in place and close the phone cover.

### starting up

After installing the SIM card and battery correctly, press the power button to switch on.

### Shutdown

Press power button to prompt 'slide down to power off'. Manual drop can be turned off.

### 1.2 Charging the battery

When the battery is low, the phone displays battery status bar icon. In this case, you may not be able to use the phone part of the function. When the battery is below the threshold, the phone will automatically shut down. Please give phone battery.

- Connect the USB data cable into the phone's USB interface.
- After charging is complete, unplug the USB data cable light.
- Phone is switched on when charging, the screen flashing battery icon in the status bar displays. When charging is complete, the screen displays full battery icon in the status bar.

### 1.3 On and off the screen

#### Off the screen

You can press the power button to turn off the screen to save power and prevent misuse by.

#### On Screen

To turn on the screen, press the power button to light up the screen.

### 1.4 Phone locking and unlocking

## Lock the phone

Press the power button to lock the phone.

**Explanation:** If you set the system default lock screen or within the time without any action on the phone, the phone will automatically lock.

## Unlock the phone

- 1.5 Press the power button on the lock screen to light up the screen and swipe up to unlock the screen .

### 1.6 Key introduce

**Search key :** Short press open Cortana function (voice assistant).

**Home key :** Back to the main standby screen.

**Return key :** Return to the previous user interface.

**Power Key:** Namely the power button, switch, turn off or turn on the function screen.

**Volume keys :** Adjust the phone volume.

### 1.7 Status Bar

Phone icon on the left top of the screen there is a notification about information and events; The right of the icon is the status indicator.

If you have missed calls or new messages, then an event notification bar at the top of the screen displays a message with your finger tips from the incident at the bar slide down, that will display all open message "notice Panel", click on "Notifications panel "in the message, you can view missed calls or new messages.

### 1.8 Call

Click the Dial icon, enter the dial-up interface; Tap a number key, enter the phone number; Click the Dial button, call; Tap the end key to end the call.

### 1.9 Answer the phone

- 1.10 When a new call is coming, the touch answer menu can answer the call, and the handle hanging menu can hang up the picture to reject a call.

### 1.11 Send message

Enter information interface; enter recipient number or select a contact as the recipient address book; enter text; tap Send button to send the message.

## Main Functions

### 1.12 Settings

#### Systems

- **Display :** Related to the menu screen display settings, Adjustable screen brightness, Turn on/off "rotate lock".
- **Notification and actions :** The quick operation menu, open/close operation center display notification (when the phone is locked), display application (SIM card application, phone, information) notification.
- **Storage:** View the SD card and phone memory related information display.
- **Battery:** Check the battery status and battery condition.
- **Driving mode:** Start driving mode and need a bluetooth device, Close all notifications other than text messages and phone calls, and you can shut down calls and text messages completely.
- **About:** Can display device name, device information, or reset your phone.

#### Equipment

- **Default camera:** Can choose the default camera application and select whether the camera USES location information.
- **Bluetooth and other devices:** Turn on/off bluetooth, search, match, and connect other bluetooth devices. Setting up the Settings and menu screen display Settings for ring tones,

vibration, reminder sound and management application sound.

- **USB:** Open/close the charging prompt notification, open/close the USB data connection before asking.

## Network and wireless

- **Data usage:** Set data usage restrictions to show traffic usage.
- **Mobile and SIM:** Open/close the data connection, and the backstage usage can be avoided. can select data roaming options.
- **WiFi:** With WLAN functionality to connect to a wireless WIFI, can directly access.
- **Flight mode:** After the opening, Automatic shutdown of mobile phone network, WIFI, FM radio and bluetooth, can also manually open these functions.
- **Mobile hotspot:** Share my phone network data connection with other devices.
- **VPN:** Add a VPN connection.

## Individualization

Settings for desktop background, lock screen, and alert sound.

## Apps

Access application, View storage space used by the application, can uninstall and move the application ,Download or remove an offline map.

## Accounts

Add a Microsoft account and manage the logged in account, synchronizing data.

## Time and language

- **Date and time:** Open/close the " 24-hour Settings " automatically or manually set the time, date and time zone.
- **Language:** Add and switch languages.
- **Region:** Set national/regional and regional formats.
- **Keyboard:** Can add different keyboards and more keyboard Settings.

- **Speech:** Add different phonetic languages and make relevant Settings.

## **Easy to Access**

For text size, high contrast, narrator, "narrator" quick start, etc.

## **Privacy**

Permission Settings for location, notification, account information, contacts, email and other functions .

## **Update and security**

Can connect to the network, find and update the mobile phone version. Backup information, device encryption, find my phone and other functions Settings.

### **1.13 People**

#### **View a contact**

When standby, enter the contacts, click open a contact person, can view the contact information.

#### **Search for contacts**

Contact list screen, tap the search box; enter a search character; will automatically match and display the need to find a contact.

#### **New Contact**

Tap Create new contact, select the storage location of the new contact, in the editing interface, enter the contact information, tap Done to save the new contact to your contact list.

#### **Editing a contact**

Long press the contact you want to edit, select Modify, you can re-edit the contacts.

#### **Delete contacts**

Long press the contact you want to delete, select delete, then confirm the deletion.

#### **Import / Export contacts**



Contact list screen, tap the Menu key – Import / Export, select Import / Export category, after confirmation, complete the import / export.

## 1.14 Messaging

### New message

Compose a new message into the editing interface, enter the recipient number or select a contact from your address book as the recipient, enter the message content; tap Send, Send SMS.

### view information

Enter information, display all information list, click on any information, see information details.

### delete messages

The information list interface-[menu],-[select], can select all or part of the selected information, and can do "delete" operations.

### Searching for information

The information list interface - [menu] - [search], the input box enters the sender's name or number, and the search information is displayed in the interface.

### Drafts

Select "+" to create new information, enter the recipient number or information content, press the return key to exit to the information list interface, and select "draft" from the pop-up option to enter the draft list interface.

### Information Settings

Setting information related parameters, such as: the number of SMS session limit, send reports, etc.

## 1.15 Phone

### Dial plate

Enter the selection [dial], pop up number keypad, can enter 0-9 arbitrary number; Press 1 to make voice calls; Long press 0 to

enter "+".

## Call records

In the telephone menu interface, select [historical records], The interface will show call records that have not been connected, incoming calls, and phone calls.

## Speed dial

In the phone menu interface, select [quick dial], click "+" to add the contact of frequent call, convenient and quick call.

## call settings

In the phone menu interface - [Settings], Change more Settings for the call, such as voice mail, call transfer, SIM card fixed dialing (FDN).

### 1.16 Cortana

Get help by voiceGet help by voice.

### 1.17 Storage

Display the use of mobile phones and SD space, you can set the music, video, photos, new application storage location.

### 1.18 Maps

Locate, navigate, and download an offline map.

### 1.19 Films and TV

Watch devices and online video.

### 1.20 Excel

Excel mainly deals with table data, including data processing, analysis, statistics, etc.

### 1.21 Groove Music

You can easily use the music player to play music files in your phone.

### 1.22 Get help

User feedback on the problems encountered in the phone .

### 1.23 Calculator

Calculator functions including basic arithmetic operations, and advanced computing.

### 1.24 Microsoft Edge

Use the Internet features, you can browse news, search online resources, and access to online entertainment services. Using the browser, you will need to account for data and network configuration settings. Related parameters, please consult your network service provider.

### 1.25 Alarms and Clock

**clock** : Set the alarm and response time.

**World clock** : Add a world time zone, compared to national regional time view.

**Stopwatch** : The related timing function can be stopwatch.

### 1.26 OneDrive

Onedrive is Microsoft's cloud storage service.

### 1.27 OneNote

Standby interface, open [OneNote], can add notes quickly.

### 1.28 Outlook Calendar

You can view the Gregorian date calendar function, lunar schedule, but also can set event reminders.

### 1.29 Outlook Mail

Can send and receive e-mail messages.

**Explanation:** You must first set up e-mail, send and receive e-mail only. E-mail must be the Internet connection to send and receive e-mail messages. Specific settings parameters, please consult your local service provider.

#### Set up e-mail

Enter a valid e-mail address and password, login E-mail operations.

#### Send e-mail

Mailing list interface, select Add e-mail, you can edit the message and send the message.

## **Receiving e-mail**

Mailing list interface, select the refresh icon, you can receive mail.

### **1.30 Skype**

Standby interface, open [Skype], use the Internet to log in and use Skype (download updates to use).

### **1.31 Weather**

Local weather – a quick look at the 10 days and hourly weather forecasts.

### **1.32 Word**

Standby interface, open [Word] to view, edit, and create documents(download updates to use).

### **1.33 File Medic**

View, manage phone memory and SD card files.

### **1.34 Xbox**

Standby interface, open [Xbox], Access to the Xbox app is available on the web, (download updates to use).

### **1.35 Camera**

You can use the camera to shoot videos and take photos.

Explanation: In the absence of the parties involved to allow or another's privacy, please do not take pictures, expressly do not take pictures in a place where forbidden to take pictures.

### **1.36 News**

Check the popular news and latest news on the day.

### **1.37 Store**

Standby interface, select [app store] to enter the app store operation screen, can download the installation application.

Explanation:

When you download the installation application from the app store,

you need to log in to the Microsoft account properly.

### **1.38 Voice recorder**

Save and play recorded sound.

### **1.39 Photos**

Preview the photos and videos.

## **Rights Statement**

1. Without our written permission, in any form is strictly prohibited to modify, copy, distribute, store, disseminate, some or all of the contents of this manual.
2. In any case, the Company assumes responsibility for any accidents caused by data or other direct or indirect responsibility for the loss.
3. All pictures in this manual are for reference only, please prevail in kind, if any discrepancies.
4. The Company reserves the right to revise this manual without prior notice.

## **FCC Warning:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable

protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### **FCC RF Exposure Information and Statement:**

Product has been tested against this SAR limit. The device was tested for typical body-worn operations with the back of the handset kept 1 cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.0 cm separation distance between the user body and the back of the handset. The use of belt clips, holders and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.