


1、 **Power on:** Press the button of the right side for 2S.



2、 **Power-off**

Manual power-off : Press the button of the right side for 2S.

Automatic power-off : It will automatic power off after 10 minutes music paused on conditional that not touch the screen.

3、 **Headphone mode:**


Wired mode: After inserting the wired earphone into the headphone jack of the left side, turn on the wired headphone mode.

Wireless mode: Turn on the BT, and connect wireless headphone.



4、 Selection :

BT mode: Bluetooth on/off; search for device; device list.



SLEEP mode: There are 20 songs, each song for 1 hour.

REST mode: there are 10 songs, each song for 20 minutes.

(note: When wired or wireless headphones are connected, the music can only be played.)

5、 The home button in the upper left corner of the screen returns to the previous layer, the middle is the pause button, and the battery level is displayed in the upper right corner.

5、Charging:

charging time: about 2 hours. Battery display in the upper right corner.

Please charge for the case by DC5V/1A output end, and other DC5V is OK. (must match with original approved charger.)

7、 **Stand-by mode:** Do not touch the screen for 90 seconds, it will enter stand-by mode; And touch again the screen will brightened.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.