

折后尺寸: 76*102mm 100g双铜 折页

GETTING STARTED

- Remove the product from the box.
- Please retain all packaging after you have checked and counted all the parts and the contents against the Package Contents list.

PACKAGE CONTENTS

- Qi enabled Bluetooth stereo Headphone
- USB charging cable
- Auxiliary audio cable
- Wireless Charging Pad
- Instruction Manual

KEY FEATURES

- Qi Enabled Bluetooth Stereo Headphone
- Auxiliar sound with passive noise cancellation & enhanced bass
- Connect and stream wireless music anytime, anywhere
- Built-in microphone, never miss your phone calls - answer hands-free
- Your music & calls at finger-tips with built-in controls
- Built-in rechargeable battery
- Wireless charging capability for easy wireless charging, just place the Headphone on the wireless charging pad.
- Wireless charging pad included

SAFETY INSTRUCTIONS

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.

Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, personal injury and/or injury to the unit.

Do not use the unit if it has been dropped or damaged in any way.

Report to electrical equipment should only be performed by a qualified electrician. Improper repairs may cause damage to the unit.

Do not use the unit with wet hands.

Do not pull objects into any of the openings.

Keep the unit free from dust, lint etc.


Do not use this unit for anything other than its intended use.

Keep the unit out of reach of children.

This product is not a toy.

Do not use the handset at excessive volume levels, as damage to hearing may occur.

DESCRIPTION OF PARTS:



INSTRUCTIONS FOR USE

Charging Instructions

The Bluetooth Headphone has built-in rechargeable battery and wireless charging receiver. When the battery is drained out, it would turn OFF automatically. Please recharge the battery by following either method every time it drains out.

Method 1: Plug the Micro USB end of the included USB rechargeable cable into the charging port. Plug the other end into a USB port on your computer or other device. **Method 2:** For USB charging, Red LED Light illuminates indicating that the device is being charged.

It takes 2-3 hours to fully charge the Headphone. Once the Headphone is fully charged, LED Light on the device would turn blue.

Switching on/off the device: Press and hold the ON/OFF button for 4 seconds to turn on the device, or 3 seconds to turn off.

Pairing the device with Bluetooth devices (phone or music device): Ensure the device is turned off, then press and hold the ON/OFF button for 4 seconds to turn on the device, and the LED flashes red and blue. After few

(included) to a power outlet rated DC 5V 2A, red LED indicator light around the wireless charging pad turns on, then put the Headphone with its Wireless charging receiver on the middle position of the Wireless charging pad. Red LED Light on the Headphone illuminates and the red LED indicator light around the wireless charging pad will turn to a change of blue LED light indicating that the device is being charged.

It takes 2-3 hours to fully charge the Headphone. Once the Headphone is fully charged, red LED Light on the device would turn blue.

Method 2: Fold the Headphone to a state with its Wireless receiver at the bottom position and the LED light indicator on vertical position for viewing easily (as the diagram shows). Connect the Wireless charging pad (included) with the USB cable

(included) to a power outlet rated DC 5V 2A, red LED indicator light around the wireless charging pad turns on, then put the Headphone with its Wireless charging receiver on the middle position of the Wireless charging pad. Red LED Light on the Headphone illuminates and the red LED indicator light around the wireless charging pad will turn to a change of blue LED light indicating that the device is being charged.

It takes 2-3 hours to fully charge the Headphone. Once the Headphone is fully charged, red LED Light on the device would turn blue.

Switching on/off the device: Press and hold the ON/OFF button for 4 seconds to turn on the device, or 3 seconds to turn off.

Pairing the device with Bluetooth devices (phone or music device): Ensure the device is turned off, then press and hold the ON/OFF button for 4 seconds to turn on the device, and the LED flashes red and blue. After few

seconds, you would hear an indication tone. Place the Bluetooth Headphone and Bluetooth device (phone or music device) so that they are no further than 1 meter apart.

Activate the Bluetooth function on your bluetooth device (phone or music device). Please refer to the manufacturer's instruction for instructions on enabling Bluetooth on your device.

Once you have activated Bluetooth on your device, select the 'SL Freedom HP' from the list of available Bluetooth devices.

If required, enter the password '0000' to confirm & finalise pairing.

Once paired successful, you would hear another indication tone, and the led flashes blue slowly.

You can now start using the device.

pairing is successful, turn the device off and then repeat following the above steps.

The Bluetooth headphones will attempt to automatically connect to the last device it was paired with when switched on. If you want to pair it with a new device, please follow the steps outlined above.

Once the Bluetooth headphones is paired with your device, the music will transmit through the Bluetooth headphones. Please refer to your device's user manual for further information.

Making a call with the Bluetooth Headphone in Bluetooth mode

Basic operation

Function	Operation	Button
Answer a call	Answer a call	Press the Phone button twice to answer a call.
End/cancel a call	End/cancel a call	Press and hold the Phone button for 2 seconds to end a call.
Redial a call	Redial a call	Press the Phone button to redial the last number.
Volume up	Volume up	Press the Volume up button to increase the volume.
Volume down	Volume down	Press the Volume down button to decrease the volume.
Previous track	Previous track	Press the Previous track button to return to the previous track.
Next track	Next track	Press the Next track button to skip to the next track.
Hold/Release	Hold/Release	Press the Hold/Release button to hold or release a call.

PLEASE NOTE

• Not all mobile phones support all the functions listed above. Please refer to your phone's user's manual for further information.

• Call functions and indication tone maybe vary depending on your mobile phone.

VOICE ASSISTANT OPERATION

Voice Assistant is a built-in interactive feature that allows you to Start Conversation with Your Siri or Google Assistant, with a click of a button on your device.

To know more about Soundlogic visit our website www.soundlogic.in

To connect with us for assistance please contact us on 1800 22 2468

FREEDOM

WIRELESS CHARGING

STEREO HEADPHONES



This feature enables you to ask questions and seek assistance on a number of things from your Voice Assistant, even when you're several feet away from the headphones, what's the time now?

Voice Assistant will reply with something like: It's 8:00 AM.

• More examples:

Set an alarm for 7 AM tomorrow.

Play some music.

What's in the news?

Listening to Music using Micro SD (TF) card slot

1. Turn on the headphones.

2. Insert Micro SD (TF) card preloaded with songs into the Micro SD (TF) card slot, music would be automatically streamed.

3. To skip Next Track - Short press the Next Track button.

4. To Skip Previous Track - Short press the Previous Track button.

5. Press Play / Pause button to Play or Pause a track.

6. Long press the + or - button to increase or decrease the volume.

• Example 1: short press the Voice Assistant button once, when you speak into the headphones, how's the weather today?

Voice Assistant will reply with something like:

mainly cloudy with a few showers.

Example 2: Short press the Voice Assistant button once, and then speak into the headphones, what's the time now?

Voice Assistant will reply with something like: It's 8:00 AM.

• More examples:

Set an alarm for 7 AM tomorrow.

Play some music.

What's in the news?

Listening to Music using Micro SD (TF) card slot

1. Turn on the headphones.

2. Insert Micro SD (TF) card preloaded with songs into the Micro SD (TF) card slot, music would be automatically streamed.

3. To skip Next Track - Short press the Next Track button.

4. To Skip Previous Track - Short press the Previous Track button.

5. Press Play / Pause button to Play or Pause a track.

6. Long press the + or - button to increase or decrease the volume.

• Example 1: short press the Voice Assistant button once, when you speak into the headphones, how's the weather today?

Voice Assistant will reply with something like:

mainly cloudy with a few showers.

Note: While using Bluetooth, if you insert Micro SD (TF) card, Headphone would disconnect the Bluetooth connection and switch to Micro SD (TF) card function. You can short press the Mode button twice again, to select the Bluetooth mode.

LED INDICATOR Please refer to the below tables for a list of the LED statuses whilst using the Bluetooth headphones.

Charging Indication

LED indicator	Status of the BT Headphone
Red LED	Charging
Red LED On	Charging Completed

LED Indication

LED indicator	Status of the BT Headphone
Red LED and white LED	Pairing mode
White LED	Connected

Symptom

Solution

No Sound

• Power on the headphones and turn up the volume.

• Increase the volume on your headphones.

• Turn up the volume on your mobile device to the headphones.

• Check for any obstructions or debris.

• Check for any loose connections.

• Connect another media device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.