





Duty Cycle NVNT ac40 5230MHz Ant0



Duty Cycle NVNT ac80 5210MHz Ant0



Shenzhen LCS Compliance Testing Laboratory Ltd.


Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China

Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com


Scan code to check authenticity



Duty Cycle NVNT ax20 5180MHz Ant0




Duty Cycle NVNT ax20 5200MHz Ant0








Duty Cycle NVNT ax20 5240MHz Ant0



Duty Cycle NVNT ax40 5190MHz Ant0







Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5180	Ant1	96.08	0.17	0.72
NVNT	a	5200	Ant1	96.08	0.17	0.72
NVNT	a	5240	Ant1	96.01	0.18	0.72
NVNT	n20	5180	Ant1	95.7	0.19	0.77
NVNT	n20	5200	Ant1	95.78	0.19	0.77
NVNT	n20	5240	Ant1	95.71	0.19	0.77
NVNT	n40	5190	Ant1	92.22	0.35	1.56
NVNT	n40	5230	Ant1	92.07	0.36	1.56
NVNT	ac20	5180	Ant1	92.19	0.35	1.46
NVNT	ac20	5200	Ant1	92.32	0.35	1.46
NVNT	ac20	5240	Ant1	92.32	0.35	1.46
NVNT	ac40	5190	Ant1	86.83	0.61	2.81
NVNT	ac40	5230	Ant1	86.83	0.61	2.81
NVNT	ac80	5210	Ant1	37.02	4.32	5.24
NVNT	ax20	5180	Ant1	90.65	0.43	1.84
NVNT	ax20	5200	Ant1	90.48	0.43	1.85
NVNT	ax20	5240	Ant1	90.5	0.43	1.84
NVNT	ax40	5190	Ant1	84.64	0.72	3.3
NVNT	ax40	5230	Ant1	84.68	0.72	3.29
NVNT	ax80	5210	Ant1	35.46	4.5	5.62




Shenzhen LCS Compliance Testing Laboratory Ltd.
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
Scan code to check authenticity




Test Graphs

Duty Cycle NVNT a 5180MHz Ant1




Duty Cycle NVNT a 5200MHz Ant1






Duty Cycle NVNT a 5240MHz Ant1




Duty Cycle NVNT n20 5180MHz Ant1






Duty Cycle NVNT n20 5200MHz Ant1




Duty Cycle NVNT n20 5240MHz Ant1






Duty Cycle NVNT n40 5190MHz Ant1




Duty Cycle NVNT n40 5230MHz Ant1






Duty Cycle NVNT ac20 5180MHz Ant1




Duty Cycle NVNT ac20 5200MHz Ant1






Duty Cycle NVNT ac20 5240MHz Ant1




Duty Cycle NVNT ac40 5190MHz Ant1






Duty Cycle NVNT ac40 5230MHz Ant1




Duty Cycle NVNT ac80 5210MHz Ant1






Duty Cycle NVNT ax20 5180MHz Ant1




Duty Cycle NVNT ax20 5200MHz Ant1





Duty Cycle NVNT ax20 5240MHz Ant1



Duty Cycle NVNT ax40 5190MHz Ant1

