



HUMMINGBIRD

WIRELESS HEADPHONES

Thanks for purchasing the Hummingbird Headset from bliiq. This guide contains instructions for the set up and use of your Hummingbird Headset.

What's in the box?

Hummingbird Headset X1
Carrying Case X1
Insulation Ear Tips X2
Ear Tips X3
Micro USB Charging Cable X1
User Manual X1
Thank you Card X1 (optional)



Headset Overview

Power Button
Headset Indicator Light
Volume Button
Charging Port



User Guide

Power On / Power Off

Power On : Press the Power button for three seconds until you hear the audio cue.

Power Off : Press the Power button for three seconds until you hear the audio cue.

* When the device is on, the LED indicator light will flash white for 3 seconds.

* When the device is off, the LED indicator light will flash red for 3 seconds.

Pairing Bluetooth

First Time Pairing:

Step1 : Power on the headset

Step2 : Activate Bluetooth® on your phone and set it to search for new devices.

Step3 : The device will automatically enter "pairing mode", and the LED light will flash red/white.

Step4 : Select "bliiq Hummingbird" in the list of discovered devices.

Step5 : You will hear the audio cue and the indicator light will stop flashing.

* If the pairing is not successful, switch off your headset by pressing the Power Button until you hear the audio cue and repeat the steps outlined above.

* Devices will automatically search and pair after the first successful pairing.

* If pairing is successful, the light will flash white twice every 7 seconds.

* If pairing is not successful, the light will flash white once every 3 seconds.

Music Mode

Play or pause music - Press the Power button once to pause the music, press the Power button once again to resume playing music.

Volume Up: To increase the volume, tap the (+) button.

Volume Down: To decrease the volume, tap the (-) button.

Skip to next track : long press the (+) volume button

Play previous track : long press the (-) volume button

he Power button once again to resume playing music.

Volume Up: To increase the volume, tap the (+) button.

Volume Down: To decrease the volume, tap the (-) button.

Skip to next track : long press the (+) volume button

Play previous track : long press the (-) volume button

Voice Control Mode

Press the power button three times to enter Voice Control Mode.

Press the power button once to end Voice Control Mode.

*Some devices do not support Voice Control Mode

Call Mode

To answer calls, press the power button once to accept the call.

To reject the call, press the power button twice.

To hang up the call, press the power button once.

To accept Incoming Calls during a call: press the power button once

To reject Incoming Calls during a call : press the power button twice.

To switch between calls: press the power button once to put current call on hold and to switch to the other call.

Three way calls: to hang up the call, press the power button twice to hang up on person A, and press the power button twice again to hang up on person B.

* During call mode, the light will flash white once every 7 seconds.

Ambient Mode Communication without taking your headset off.

To enter Ambient Mode, press the power button twice.

To exit Ambient Mode, press the power button once.

To increase the outside volume, tap the (+) button. To decrease the outside volume, tap the (-) button.

*Ambient Mode will not activate if Bluetooth is not connected.

*Ambient Mode will not activate under Voice Mode and Call Mode.

*Music Mode will automatically resume after Ambient Mode is turned off.

Charging / Reset Communication without taking your headset off.

Charging : Open the USB door to charge via a micro USB cable.

Reset : To perform the reset, press the power button and (+) volume button at the same time and hold for seven seconds.

The reset is successful once you hear a beep.

* When charging, the red LED light will turn on.

* When the headset is fully charged, the LED will change to white.

* When charging, headset will automatically shut off, and will not be available to use.

* Once the battery reaches 10%, the red light will remain on.

* Once the battery reaches 5%, the light will flash red continuously.

Fit

For the best sound performance and a secure comfortable fit, drape the wire around the back of your head and insert the ear buds securely.

Rotate the ear tip between a plus and minus 20° range to achieve an optimal fit and sound experience.

Included are 2 different types of ear tips: 3 sets of silicone ear tips and 2 sets of insulation ear tips. If the fit of the ear buds are uncomfortable, please try either a different size or type of ear tip.

Trouble Shooting

If your headset is not responding, you may want to perform a reset.

To perform the reset, press the power button and (+) volume button at the same time and hold for seven seconds . The reset is successful once you hear a beep.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.