


TOZO®
www.tozostore.com



NC7 TWS ANC Earbuds



info@tozostore.com



www.tozostore.com

Thank you for purchasing the TOZO authentic product.
For more latest products, parts and accessories,
please visit: www.tozostore.com
For any assistance please contact Email: info@tozostore.com



English

03 - 10



日本語

11 - 18



Deutsche

19 - 26



Français

27 - 34



Italiano

35 - 42




Español

43 - 50



1.0 Product description



2.0 Wearing Steps

- Step 1: Ensure the earbud tip facing downwards, then place earbuds into ear.
 Step 2: Rotate earbuds back to auricle side to fit snugly.



3.0 Operation of earbuds

3.1 How to pair

1. Take out the 2 earbuds from charging case, they will power on automatically and will connect each other automatically within 10 seconds.
2. The two earbuds flash red and blue alternately. (Pairing Mode)
3. Search for pairing name [TOZO - NC7] and select it.



3.2 Power on/off

Power on:

Press & hold both earbuds' MFB Touch Panel for over 3 seconds.

Power off:

1. When earbuds are not playing music, long press MFB Touch Panel for 5 seconds to turn off.
2. The earbuds will turn off automatically after it is disconnected for more than 5 minutes.

3.3 Reset

In case only one earbud works or two earbuds cannot be connected, please consider to reset by following the below steps:


1. Turn off your phone's Bluetooth
2. Pick up 2 earbuds from the charging case, long press both earbuds' MFB touch panel for 5 seconds till blue light goes out.
3. Double click both earbuds' MFB touch panel within 2 seconds, when 2 earbuds flash in blue rapidly, it means both earbuds re-enter the pairing mode.

NOTE: In case there is any unsuccessful connections, please consider to delete all historical records of [TOZO-NC7] and try the pairing process again.

4.0 Switch between noise-control modes

Tap the left earbud's MFB Touch Panel to switch between the Active Noise Cancellation (ANC) & Transparency Mode. The ANC function are not available when using single earbud.

NOTE: If the electromagnetic interference signal is strong in your area, it may affect the Bluetooth connection, and the earbuds will be silent or disconnected, please reconnect it or change the place of use.



4.1 Active Noise Cancellation Mode (ANC Mode)

With Active Noise Cancellation, an outward-facing microphone detects external sounds, which your TOZO NC7 earbuds then counter with anti-noise, canceling the external sounds before you hear them. An inward-facing microphone listens inside your ear for unwanted internal sounds, which your TOZO NC7 earbuds also counter with anti-noise.



4.2 Transparency Mode


Transparency mode can enhance the voice frequency band and improve the perception of the surrounding sound, so you can hear what's going on around you without taking off the earbuds.

Active Noise Cancellation and Transparency mode work best when your TOZO NC7 fit well and wearing correctly.



5.0 BOX Wireless Charging


Designed for the modern life, never be strangled by headphone cables.



Designed for modern life, there is no need for charging cables, enjoy the convenience of unplugged charging and instant charging.

6.0 Detailed Function List

Turn on	<ol style="list-style-type: none"> 1. Manually Turn On: After the earbud is in close status, tap and hold the touch control for 3 seconds and release it, the blue light will turn on. Then looking for the phone with the last connect connection memory within 10s after the headset is turned on. If it is not found, enter the pairing state (the red and blue lights flash alternately). 2. Auto Turn On: When the earbuds are in the charging case, you can pick it up and it will automatically turn on. Then finding the phone with the last connect connection memory within 10s after the earbud is turned on. If it is not found, enter the pairing state (the red and blue lights flash alternately).
Turn off	<ol style="list-style-type: none"> 1. Manually Turn Off: Tap the MFB touch panel 5 seconds for turn off in not playing status, and then release it, the red light will turn off after one second. 2. Auto Turn Off: Take the earbuds into the charging case and charge it for 3 seconds, then the red light will be on to turn off automatically.
TWS pairing Timeout	After the two earbuds are paired for more than 15 seconds on TWS, if they are not successfully paired, they will enter the mobile phone pairing state.
Phone Pairing	<p>When the earbuds are turned off, tap and hold the MFB touch panel simultaneously for 5 seconds and release them to pairing mode (the red/blue light flashes alternately), then searching for pairing name "TOZO-NC7" and select it in your mobile phone.</p> <ol style="list-style-type: none"> 1. Take out the 2 earbud from charging base, they will power on automatically and will connect each other automatically within 10 seconds. 2. The two earbuds flash red and blue alternately (Pairing mode) 3. Search for pairing name "TOZO-NC7" and select it in your mobile phone.
Auto Turn Off	<p>Automatically Turn Off after no connection for more than 5 minutes.</p> <p>After the earbud is disconnected from the phone at a long distance, it will automatically turn off after more than 5 minutes. (Normal mode)</p>

Restore Factory Settings	<p>In case reset step not resolve your issue, please restore to factory setting:</p> <ol style="list-style-type: none"> 1. Pick up two earbuds from charging case, then holding both earbuds button for 5 seconds till red lights on to turn off earbuds. 2. Holding the MFB Touch Panel on each of earbuds for 5 seconds till blue light turn on and off, and then clicking the MFB Touch Panel on each of earbuds 3 times quickly, the Restore Factory Settings process will be done when the red light. 3. Put earbuds into charging case, and then take them out to connect records of "TOZO-NC7" on your phone. <p> NOTE:</p> <p>After Restore Factory Settings successfully, please delete all connection records of "TOZO-NC7" on your phone, then research again.</p>
Turn on for re-connection	<ol style="list-style-type: none"> 1. Tap the MFB touch panel for 3 seconds and release to turn on the earbuds → wait for a few seconds for the earbuds to automatically interconnect with each other → wait for a few seconds for the earbuds to connect with the paired phone → the connection is successful. 2. Take out the earbuds from charging case → wait for a few seconds for the earbuds to automatically interconnect with each other → wait for a few seconds for the earbuds to connect with the paired phone → the connection is successful.
Over distance for re-connection	After the earbud is disconnected from the phone at a long distance, it can automatically reconnect when it returns to the close distance with the phone within 5 minutes. More than 5 minutes, the headset will automatically turn off.
Answer Phone Call	Tap the MFB touch panel once to answer the incoming call.
Hang up Phone Call	Tap and hold the MFB touch panel for 2 seconds to hang up the phone.
Reject Incoming Call	Tap and hold the MFB touch panel for 2 seconds to reject the incoming call.
Cancel dialing	Tap and hold the MFB touch panel for 2 seconds to cancel dialing before dialing out and the other party fails to answer.

Play/Pause	When playing music, tap the Right MFB touch pannel once to pause/play(The left headset cannot switch to play/pause).
Next Track	Double- Tap the Right MFB touch pannel twice for backward when playing music.
Previous Track	Double- Tap the Left MFB touch pannel twice for previous when playing music.
Volume up	Tap and hold the MFB touch pannel on Right earbud when playing music.
Volume down	Tap and hold the MFB touch pannel on Left earbud when playing music.
Voice Interaction of Siri	In standby mode, quickly tap the MFB touch pannel 3 times to turn on voice interaction of mobile phone.
Primary / Secondary switch automatically	When listening to music, put either headset back into the charging case, and the other headset will not be affected.

7.0 Function List

7.1 Leftearbud	
Turn On	Pick up the earbuds from the case it will turn on automatically. Tap the MFB Touch Pannel for 3 seconds to turn on
Turn Off	Put back into the charging case, it will turn off & charge automatically. Tap the MFB Touch Pannel for 5 seconds to turn off when not playing. Automatically turn off after no connoction fot more than 5 minutes.
Previous Track	Tap the MFB Touch Pannel to play backward.
Volume down	Tap and hold the MFB Touch Pannel to reduce volume.
ANC Mode	Tap the MFB Touch Pannel Once.
Transparent mode	Tap the MFB Touch Pannel Once.
Answer Phone Call	Tap the MFB Touch Pannel Once.
Hang up Phone Call	Long press the MFB Touch Pannel for 2 seconds.
Reject Incoming Call	Long press the MFB Touch Pannel for 2 seconds.
Cancell Phone Call	Long press the MFB Touch Pannel for 2 seconds.

7.2 Right earbud

Turn On	Pick up the earbuds from the case it will turn on automatically. Tap the MFB Touch Pannel for 3 seconds to turn on.
Turn Off	Put back into the charging case, it will turn off & charge automatically. Tap the MFB Touch Pannel for 5 seconds to turn off when not playing. Automatically turn off after no conncetion fot more than 5 minutes.
Next Track	Tap the MFB Touch Pannel twice to play backward.
Volume up	Tap and hold the MFB Touch Pannel to increase volume.
Play/Pause	Tap the MFB Touch Pannel Once.
Answer Phone Call	Tap the MFB Touch Pannel Once.
Hang up Phone Call	Long press the MFB Touch Pannel for 2 seconds.
Reject Incoming Call	Long press the MFB Touch Pannel for 2 seconds.
Cancel Phone Call	Long press the MFB Touch Pannel for 2 seconds.

SPECIAL REMINDER:

Wipe the hardware contacts of the headset and charging box when the headset is not charging.



Note:

If your problem is not answered above,
please contactus via email ,
we will respond within 24 hours.



Email: info@tozostore.com



Battery Warning!

This product has built-in lithium battery.
Do not expose the product to strong sunlight,
fire or throw it into the fire to avoid explosion.

TOZO®

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

TOZO®

Label

