

Tripod user manual

PACKAGE INCLUDES

Tripod legs & ball head, universal clamp, remote shutter.

SAFETY INFORMATION

- Not for children under 3 years.
- To protect your phone from damage, ensure that the clip attachment is clean from any dirt and debris
- Concentrate on driving and do not use the product when in transit
- Avoid dusty, damp or dirty environments.
- Observe local laws and regulations and respect the privacy and legal rights of others.
- Do not dismantle or remanufacture the device against its original use purpose. This voids warranty and releases the manufacturer from liability for damage. Contact authorized dealer/distributor for assistance or repair.
- Avoid extreme temperatures.
- *Fire might cause the button cell battery to explode

Compatibility with the remote shutter:

The remote shutter is compatible with all smartphones that have a Bluetooth function

Pairing between the Remote Shutter and your smartphone

1. Make sure Bluetooth is "ON" in your smartphone.
2. Turn on the Remote Shutter
3. Check for Remote Shutter on your smartphone Bluetooth connections
4. Connect to Remote Shutter on your smartphone
5. You are now ready to start using the Remote Shutter

Taking photos:

1. Open the camera mode
2. Press the shutter button to take a picture

Deleting and re-Pairing the Kodak – Shutter

1. Turn the Remote Shutter off
2. Go to your smartphone Bluetooth connections
3. Click on the Remote Shutter and choose "forget device"
4. Turn the Remote Shutter back on and you can re-connect

Remote Shutter Specifications:

Battery Cell: Li-MnO₂ Button Cell (Lithium Metal Battery)

Battery model: CR2032

Capacity: 220mAh

Output: 3.0V

Dimension: 30*30*20mm

Weight: 12g

Product structure:




1. Remote shutter button
2. On / Off switch
3. Holder clip
4. Battery compartment

Warranty Information and period:

EU 24 months. Other countries 12 months from date of purchase.

This product is manufactured by Eye Caramba LTD, Henryfordinkatu 5C 00150 Helsinki.



FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.