



Picture 13: Internal view



Picture 14: Internal view





Picture 15: Internal view




Picture 16: Internal view





Picture 17: Internal view



Picture 18: Internal view






Picture 19: Internal view




Picture 20: View of the System board






Picture 21: View of the System board




Picture 22: View of the TPS board






Picture 23: View of the TPS board




Picture 24: View of the Tilt sensor circuit board






Picture 25: View of the Tilt sensor circuit board




Picture 26: Internal view of the keyboard





Picture 27: Internal view of the keyboard




Picture 28: Internal view of the keyboard






Picture 29: Internal view of the second keyboard




Picture 30: Internal view of the second keyboard





Picture 31: Internal view of the second keyboard removed



Picture 32: Internal view