

风琴折: 75mm×75mm



Y80
True wireless stereo
功能操作说明

■ 产品示意图



■ 产品信息

·型 号:Y80	·工作时间:≈8小时 (最大音量)
·蓝牙版本:V5.3+EDR	·工作电压:3.3V-4.2V
·耳机电池容量:60mAh	·充电时长:≈2小时
·充电仓电池容量:450mAh	·喇叭阻抗:Φ10mm 32Ω
·电源输入:5V	·频率响应:20Hz-20KHZ
·待机时间:约180天	·传输距离:10米以上

■ 包装明细



■ 蓝牙配对

步骤一: 将耳机从充电仓取出。
步骤二: 将手机蓝牙打开。
步骤三: 找到耳机蓝牙名Y80。
步骤四: 点击连接, 连接成功后语音提醒。

注意: 如果已有配对设备信息, 耳机会在2-4S内自动回连设备; 若未连接到设备, 耳机待机3分钟后自动关机。

■ 开机

(1) 打开充电仓上盖并取出耳机, 此时耳机自动开机匹配, 等待连接手机。
(2) 耳机不在充电仓里并且耳机是关机的状态, 长按左右中间键3秒开机。

■ 关机

(1) 将左右耳机放入充电仓, 关上充电仓上盖, 耳机会自动关机并充电。
(2) 开机状态双耳长按中间键约5秒关机, 单耳使用时, 单耳长按5秒可关机。

■ 耳机操作说明

待机状态	耳机手动开机	长按中间键约3秒
播放状态	耳机手动关机	长按中间键约5秒
播放状态	播放/暂停	单击任一侧中间键
播放状态	上一曲	三击中间键
播放状态	下一曲	双击中间键
通话状态	音量 +	单击侧面“+”按键
通话状态	音量 -	单击侧面“-”按键
通话状态	接听/挂断	单击任一侧中间键
通话状态	拒接电话	双击中间键
语音助手	语音助手	长按中间键3秒

■ LED灯显示

开机	红白灯交替闪
关机	红灯闪3次
低电状态	红灯闪烁 提示音提示
充电状态	红灯常亮
充满电状态	红灯灭(无灯效)

■ 使用注意事项

① 耳机需存放在干燥通风的环境下, 避免与油、水汽、蒸触, 以免影响产品性能。
② 避免使用刺激的, 有机溶剂或含有这些成份的物品清洁。
③ 耳机需按正确规范要求使用, 注意使用环境对耳机的影响, 为保证连接顺畅, 建议手机和耳机之间的距离在10米范围内。
④ 如耳机有连接不上或通讯不畅等其他问题, 请勿私自拆卸耳机本体及其配件否则不予保修。
⑤ 给耳机充电, 请选用标配的车载充电器或本公司指定的符合要求的充电器。
⑥ 为保证您正常使用耳机, 请确保耳机的电量充足。



Y80
True wireless stereo
Function instructions


■ Diagrammatic sketch



■ Specifications

·Model: Y80	·Working time: ≈ 8 hours (maximum volume)
·Bluetooth version: V5.3+EDR	·Working voltage: 3.3V-4.2V
·Earbud battery: 60mAh	·Charging time: ≈ 2 hours
·Charging case battery: 450mAh	·Speaker impedance: Φ10mm 32Ω
·Power input: 5V	·Frequency response: 20Hz-20KHZ
·Standby time: ≈ 180 days	·Transmission distance: over 10 meters

■ Package list



■ Bluetooth pairing

Step 1: Take the earphones out of the charging bin.
Step 2: Turn on bluetooth.
Step 3: Find the headset bluetooth name Y80.
Step 4: Click Connect, voice reminder after successful connection.
Note: If there is pairing device information, the headset will automatically connect to the device within 2-4s. If the headset is not connected to the device, The headset automatically turns off after 3 minutes of standby.

■ Turn on

(1) Open the top cover of the charging compartment and take out the headset. At this time, the headset automatically starts and matches, waiting for the connection of the mobile phone.
(2) The headset is not in the charging warehouse and the headset is shut down. Long press the left and right intermediate keys for 3 seconds.

■ Turn off

(1) Put the left and right earphones into the charging bin, close the top cover of the charging bin, and the earphones will automatically shut down and charge.
(2) Press the two -ear long -pressing the middle key for about 5 seconds. When the single ear is used, the single ear length can be turned off for 5 seconds.

■ Operation of earphone

Standby State	Turn on manually	Long press for 3 seconds
Playing State	Turn off manually	Long press for 5 seconds
Playing State	Play/Pause	Click the middle key
Playing State	Previous track	Three -click middle key
Playing State	Next track	Double -click the middle key
Call State	Volume +	Click the side '+' button
Call State	Volume -	Click the side '-' button
In Siri	Answer/End a phone call	Click the middle key
In Siri	Reject a phone call	Double -click the middle key
In Siri	Activate voice assistant	Long press for 3 seconds

■ LED light display

Turn On	The red and white lights flash alternately
Turn Off	Red light blinks three times
Low power status	Red light flash, voice prompt
Charging status	Red light is steady on
Full charge	Red light off

■ Precautions for use

① Headphones should be stored in a dry and ventilated environment to avoid contact with oil, water vapor and steam. In order to avoid affecting product performance.
② Avoid cleaning with irritating, organic solvents or materials containing these ingredients.
③ The headset should be used according to the correct specification requirements, and pay attention to the influence of the using environment on the headset. To ensure smooth connection, it is recommended that the distance between the mobile phone and the earphone be within 10 meters.
④ If the earphone fails to connect or communicate properly, do not remove the earphone without permission. The machine body and its accessories are not guaranteed otherwise.
⑤ To charge the earphone, please use the standard car charger or the one specified by our company Chargers required.
⑥ To ensure normal use of the earphone, ensure that the power of the earphone is sufficient.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.