




LOVENSE  
**Solace**  
USER MANUAL

## Parts & Buttons

Cap



Main Body


Inner Sleeve

Inner Sleeve Holder

Desk Mount




Screw (X) ×2

English



- Charging Port
- On/Off (hold for 3 seconds) & Start/Stop Thrusting (one tap)
- Button A: Thrusting Length (one tap to cycle "up" through preset modes)
- Button B: Thrusting Length (one tap to cycle "down" through preset modes)
- Button C: Thrusting Speed (one tap to cycle "up")
- Button D: Thrusting Speed (one tap to cycle "down")
- Indicator Light

# Charging & Desk Mounting




a) Attach the desk mount to the main body by turning screws (X) clockwise.

b) Mount the main body to the desk by turning screw (Y). Maximum table thickness for mounting - 5.5 cm.


c) Adjust the angle by loosening or tightening screw (Z).

## Button Functions


### Turn On & Start



Hold for 3 seconds to turn on & tap to start thrusting.




### Stop & Turn Off



Tap to stop thrusting and hold for 3 seconds to turn off.




## Thrust Length/Patterns



Tap A to cycle "up" & B - to cycle "down" through preset modes.

## Thrust Speed



Tap C to cycle "up" & D - to cycle "down" through preset modes.

## What's Included

- (1) Bluetooth® Automatic Thrusting Male Masturbator
- (1) Desk Mount
- (1) USB Charging Cable
- (1) User Manual
- (1) Storage Bag

## Specifications

Materials	ABS Plastic/Skin-Like TPE/Aluminium Alloy
Weight	980 g (Solace), 375 g (Desk Mount)
Battery	Li-Ion Rechargeable
Charging	100 Minutes
Use Time	up to 750 Minutes
Standby	up to 120 Hours
Waterproof	IPX4 Water-Resistant

## Charging


Turn off Solace. The cable can be plugged into any USB port or USB/AC power adapter. It will take approximately 1.5 hours to fully charge. Once it is fully charged, the solid red light will turn off.

***Note: Push the pin firmly, but slowly, into the charging port. Stop pushing when you see the indicator light glow.***


## Cleaning & Care

- Clean Solace before and after each use.
- The main body can only be cleaned with a cloth.
- Clean the inner sleeve with warm water (do NOT use soap, as it may degrade the material).
- Clean the sleeve holder with warm water and soap.
- Dry thoroughly before storing.
- When storing, make sure to put the sleeve back into the sleeve holder and then into the main body.

## Cleaning




a) After Solace has stopped, press button B for 3 seconds to let the head of the inner holder come out.




b) Gently press both sides to pull out the inner sleeve and inner holder completely.


## Cleaning



c) Only the inner sleeve and the sleeve holder can be washed with water. After, dry them thoroughly.



d) Put the inner sleeve back into the sleeve holder and make sure the plastic ring sits in the groove.



e) Insert the inner holder back into the main body. You will hear a click when it is stored correctly.

## Usage Tips

- Before insertion, generously apply lube to the inside of the sleeve, the entry hole, and your penis.
- You can adjust the thrust speed, length, or patterns to suit your needs.

## Warning

- Keep away from extreme heat or cold.
- Make sure your toy is recharged at least once every six months.
- DO NOT use the toy while charging.

## Links

Check out the newest guide/download links here. Our software is constantly updated.

Online guide: [www.lovense.com/guide](http://www.lovense.com/guide)

App download: [www.lovense.com/download](http://www.lovense.com/download)

If you have any feedback or need any additional assistance, use the contact form at [www.lovense.com/contact](http://www.lovense.com/contact). Someone from the Lovense team will normally reply within 12-24 hours.

## **Warranty Terms & Conditions**

LOVENSE warrants Solace (excluding TPE sleeve) for a period of ONE (1) YEAR, and the Solace sleeve for NINETY (90) DAYS, after the date of original purchase, against defects due to faulty workmanship or materials. If you discover a defect and notify LOVENSE during the warranty period, LOVENSE will, at its discretion, replace the product free of charge.

Visit [www.lovense.com/warranty](http://www.lovense.com/warranty) for detailed warranty and product return information.

## FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,

may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

FCC ID Code: 2AXNT-SOLACE