



USER MANUAL

Your Creative Companion Wearable Sound Everywhere

Model: MC001

PROHEAR - MC001

MEET YOUR MC001 SPEAKER

This PROHEAR MC001 redefines portable audio with 45g ultra-lightweight design. Designed for women, this sleek and portable speaker delivers **bass and Hi-Fi sound**, keeping the rhythm alive wherever you go! Whether crafting, cooking, or cycling, the MC001 stays securely attached with its **magnetic back or clothing clip**. Featuring **Bluetooth 5.3** for instant pairing, **voice assistant access**, and **IP66 water/dust resistance** to tackle sweat and splashes, its **17-hour battery life** fuels your day. Switch seamlessly between **music and calls**, blending productivity with joy—your ultimate companion for a vibrant lifestyle!

Enjoy Music, Enjoy Work, Enjoy Life!

KEY FEATURES & ICONS

- Bluetooth 5.3 — Stable, fast pairing
- Hi-Fi Sound + Bass — Crystal-clear audio
- Voice Assistant — Hands-free control
- IP66 Rating — Water & dust resistant
- 17-Hour Playtime — All-day power
- 45g Featherlight — Barely-there comfort
- Hands-Free Calls — Talk while you work/play

PRODUCT AND ACCESSORIES

- A Wearable Wireless Speaker
- USB-C charging cable*1
- User guide*1

USAGE TIPS

⚠ Important Notes

- 1 Avoid submerging in water (IP66 = splash-proof, not waterproof).
- 2 Dry thoroughly after exposure to moisture.
- 3 Keep away from extreme heat or sharp objects.
- 4 Clean with a soft, dry cloth.

*Do not disassemble, puncture, crush, heat or put into fire.
Severe swelling or immersion in water prohibits usage.*

*Operating temperature range: -20°C to 50°C
Storage temperature range: -20°C to 50°C
Charging temperature range: 0°C to 50°C*

PROHEAR BRAND INTRODUCTION

PROHEAR is dedicated to crafting premium audio devices tailored for active lifestyles. Our mission is to blend innovation with practicality, empowering women to enjoy immersive sound in every adventure—whether crafting, cooking, or conquering the day.

📱 Visit Our Store:




SCAN FOR SUPPORT
Enjoy Music, Enjoy Work, Enjoy Life!



Your PROHEAR MC001 is backed by a 1-year limited warranty.
For support, contact us at: support@proheartac.com
MADE IN CHINA


CONTROL BUTTONS

- ① "M": Bluetooth Pairing Control / Voice Assistant Control
- ② "⏻": Power Control / Device Reset Control
- ③ "+": Volume Control Buttons / Next Track Buttons
- ④ "-": Volume Control Buttons / Previous Track Buttons



PRODUCT COMPONENT

- ⑤ Indicators:
 - Charging ———— ■
 - Connected ———— ■
 - Pairing Mode ———— ■ ■
- ⑥ Microphone Pickup Hole
- ⑦ TYPE-C Charging Port
- ⑧ Strong Clip
- ⑨ Magnetic Clip



INSTRUCTIONS FOR USE

Power On – press and hold ⏻ for 3s. (voice promot: power on, Battery high/Medium/Low, Bluetooth mode)

Power Off – press and hold ⏻ for 3s

BT - Bluetooth Pairing

Bluetooth name: MC001

- After powering on, manually connect to the device's Bluetooth.
- In Bluetooth connection mode, short press ⏻ to disconnect to pair with a new device. (voice promot: Connected/Disconnected)
- With Bluetooth disconnected, short press ⏻ to reconnect to the last paired device.

BT - Wake up Siri/Give a command – press and hold M

Music - Pause/play – short press ⏻

Music - Previous Track – double press –

Music - Next Track – double press +

Music - Volume Up/Down – short press + –

Calling - Answer/End Call – short press ⏻

Calling - Decline Call – press and hold ⏻ for 3s

CHARGE IT UP!

- ① **Charging Port:** Locate the Type-C port on the speaker's side.
 - ② **Plug In:** Use the included cable (or any Type-C charger).
 - ③ **Full Charge:** 2 hours → Enjoy 15-17 hours of playtime at medium volume.
- ⚠ For best battery health, avoid overcharging.

HOW TO WEAR & USE

3 DIFFERENT WAYS OF USING

📍 ATTACH IT ANYWHERE!

① Clip-On

- 👕 Shirts
- 👙 Bra Straps
- 👔 Belts

② Magnetic/Mount

- 🧊 Fridge
- 🔧 DIY Workbench
- 🚲 Bike Handles
- 👕 Sports-clip on clothes

③ Freestanding Mode

- 👉 Desk
- 🍳 Kitchen Counter
- 🌿 Garden Table

FCC COMPLIANCE STATEMENT

FCC ID: 2AYWU-MC001

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.