



WIRELESS HEADPHONE

user manual




ENGLISH

Dear Customers:
Thanks for buying Bluetooth headphone, please read this user's manual thoroughly before using.

Packaging includes

Headphone x1 Pc
Charging Cable x1 Pc
AUX Cable x1 Pc
User's Manual x1 Pc



Design Modes:




Headphone Mode:
When earcups are twisted inward direction, the headphone is activated.



Speaker Mode:
When earcups are twisted outward direction, speaker mode is activated.

Function button diagram



- Volume Up: Connected with one Bluetooth device, press once to increase the volume. Press and hold for 3 seconds to increase the volume quickly.
- Multifunction Button: Connected with one Bluetooth device, press once to play/pause; In playback state: double-click -- next song, triple-click -- prev song; Incoming call: press once to answer, press and hold for 3 seconds to reject; Ongoing call: press once to cancel; Press and hold for 3 seconds to choose the call hearing and talking via cellphone or headphones. Press and hold for 3 seconds when playing music-redial the last number.
- Volume Down: Connected with one Bluetooth device, press once to decrease the volume. Press and hold for 3 seconds to decrease the volume quickly.
- EQ Button: short press to switch EQ modes (Only playing music with headphone mode have EQ), press and hold on 8s will clear the headphone pairing list from all devices.
- Power on/off, short press - mode switch, press and hold -power on/off.
- AUX output/Built-in reset button.
- TF slot

Specifications

Bluetooth: 5.3
Bluetooth distance: 10M(33 feet)
Lithium Battery: 600mAh
Speaker mode output power: 3W*2(CLASS D)
Headphone mode output power: 500mW*2(CLASS AB)
Speaker size: Ø40mm
Speaker impedance: 4Ω±15%
Frequency response: 180HZ-16KHZ
Sensitivity: 102±3DB
Speaker Signal to noise ratio: > 85dB
Headphone Signal to noise ratio: > 90dB
Speaker Total Harmonic Distortion: < 5%
Headphone Total Harmonic Distortion: < 3%
Input power: DC 5V(400mA)
Charging time: 2~3 hours
Playing time: Headphone mode is about 18 hours, speaker mode is about 4 hours, and playing time may vary depending on volume.

3 Sound Effects, you choose the one you like

Press once EQ, the sound effect shifts to another one once you hear sound prompt (total 3 different effects).

- Normal sound effect (The treble, middle and bass equal)
 - Bass sound effect (Super bass)
 - High definition sound effect (Voice clear)
- Note: This headphone will remember the sound effect you enjoyed last time once you power on again. The speaker mode has no EQ function.



Bluetooth pairing, start to enjoy music:

- Factory setting VOGUE 3 enters into bluetooth pairing mode when first time using, and the white indicator light flashes quickly.
- Turn on the bluetooth of your device, as cell-phone, ipad, PC or else, search and select "VOGUE 3" from the list of Bluetooth devices. The bluetooth PIN is 0000 if there is necessary to enter.
- After connected, the white light flashes twice every 5S, at which point you can start playing music.

Power management, Power off automatically:

- Bluetooth headphone will automatically power off after 15 minutes when it is not connected!

Charging:

* Do not use the adaptor without Safty certification, not rated 5V. (The headphone is designed with power protection circuit. The headphone will stop charging to protect the battery and itself if use the adaptor unmatched.)

- Power-on state: charge the product immediately when low battery is prompted.
- When the Bluetooth icon on the mobile phone indicates that the battery is low, please charge the headphone as soon as possible.
- The red led light is on when charging, the white led light is on which indicates that the battery is fully charged.

Reset:

The Reset button is built-in the AUX jack. On some uncertain conditions, the headphone is disorder and need to be activated. Please use a screw or other small thing which can be inserted into the AUX jack and press the Reset button inside. Then please power on the unit again. (please charge first if no power.)

FAQ:

- Q: How to pair with a smartphone via Bluetooth?
A: Press the On/Off button for 2 seconds, the LED indicator will flash white. Turn Bluetooth on your device, search and select "VOGUE 3" from the list of Bluetooth devices. Once paired successfully, the white light flases 2 times every 5 seconds.
- Q: What is the Bluetooth version?
A: The VOGUE 3 Bluetooth headset built-in the latest technology Bluetooth chip, Bluetooth version 5.3.
- Q: Can be connected with laptop, iPad?
A: The headphones can be compatible with any Bluetooth enabled devices, including smartphone, laptop and iPad, etc.
- Q: Can make phone calls via headphones wirelessly?
A: Yes, VOGUE 3 headphones are with built-in mic which can deliver clear hands-free calls.
- Q: How long can be used for one time after fully charged? What about the stand-by time?
A: VOGUE 3 headphones are with 600 mAh poly-li battery. After fully charged, they can be used more than 18 hours.

▲ Safety Instructions:

- Please fully charge this headphone before first time using.
- Please charge this headphone at least once every 3 months to keep battery in good condition.
- To protect your ear, please do not use this headphone long time with too high volume.
- Free from extreme temperature, humidity and dust.
- Please do not avoid shock or hit with tough things. Will may damage this headphone.
- Do not bring in contact with liquids.




ESPAÑOL

Estimado Cliente:
Muchas gracias por comprar Auriculares Bluetooth, para facilitar su utilización, lea por favor el manual de usuario antes de operar. ¡Deseamos que los disfrute!

Equipo Principal y Sus Accesorios

Auricular bluetooth x 1
Cable de carga x 1
Cable de audio x 1
Manual de usuario x 1



Introducción de Modos




Modo de Auriculares:
Cuando los auriculares giran hacia adentro, se activa el modo de auriculares.



Modo de Altavoz:
Cuando los auriculares giran hacia fuera, se activa el modo de altavoz.

Diagrama de Funciones de los Botones



- Subir Volumen (+): Con el dispositivo conectado por Bluetooth pulsar una vez aumenta el volumen. Manteniendo pulsado 3 segundos sube el volumen rápido.
- Botón Multifunción (M): Con el dispositivo conectado por Bluetooth, pulsar una vez para reproducir/pausar; En estado de reproducción: haga doble clic -- siguiente canción, haga triple clic -- canción anterior, En llamadas entrantes: pulsar una vez para responder, mantenga pulsado 3 segundos para rechazar la llamada; En llamadas salientes: pulsar una vez para cancelar la llamada; Durante una llamada: pulsar una vez para colgar; mantenga pulsado 3 segundos para cambiar la salida de audio entre la llamada del móvil y la reproducción de música. Mantener pulsado durante la reproducción de música -- volverá a marcar el último número de llamada.
- Bajar Volumen (-): Con el dispositivo conectado por Bluetooth, pulsar una vez para bajar el volumen. Manteniendo pulsado 3 segundos baja el volumen rápido.
- Botón de modo de equalizador, presione brevemente el modo de cambio (sólo responde cuando se reproduce música en modo de auriculares), Mantenga presionado durante 8S para borrar todos los registros de dispositivos conectados previamente.
- Encendido/apagado, presione brevemente -- cambio de modo, presione largamente -- encendido/apagado.
- Entrada de audio AUX/botón de restablecimiento incorporado.
- Ranura para tarjetas TF

Parámetros Técnicos

Versión Bluetooth: 5.3
Distancia del Bluetooth: 10M(33 pies)
Batería de polímero incorporada: 600mAh
Potencia de salida del modo de altavoz: 3W*2 (CLASE D)
Potencia de salida del modo de auriculares: 500mW*2 (CLASE AB)
Unidad de control: Ø40mm
Impedancia de altavoz: 4Ω±15%
Frecuencia: 180HZ-16KHZ
Sensibilidad: 102±3DB
Ratio señal-ruido del modo de altavoz: > 85dB
Ratio señal-ruido del modo de auriculares: > 90dB
Distorsión del modo de altavoz: < 5%
Distorsión del modo de auriculares: < 3%
Datos de carga: DC 5V (400mA)
Tiempo de carga: 2~3 horas
Tiempo de reproducción: aprox. 18 horas en el modo de auriculares, aprox. 4 horas en el modo de altavoces, el tiempo de reproducción puede variar según el volumen.

3 efectos de sonido para personalizar su música:

Pulsar una vez EQ, el efecto de sonido cambia a otro una vez que se escucha el aviso de una voz humana (3 modos de sonido disponibles).

- Modo normal (Balance entre agudos, medios y graves)
- Modo subwoofer (Amplifica los graves)
- Modo alta definición (Voz clara)



Nota: Los auriculares tienen una función de memoria, cuando los encienda nuevamente, funcionarán con el último modo de sonido. El modo de sonido externo no lleva la función de conmutación de EQ.

Conectividad Bluetooth para que su música comience aquí:

- Cuando el VOGUE 3 se encienda después de salir de la fábrica, entra automáticamente en el modo de emparejamiento de Bluetooth y la luz indicadora blanca parpadea rápidamente.
- Encienda el móvil, el ipad, la PC u otro dispositivo electrónico que se pueda conectar a los auriculares Bluetooth, active la función Bluetooth y busque el número de dispositivo de auricular Bluetooth "VOGUE 3" para emparejar. El PIN de emparejamiento es 0000.
- Una vez que la conexión es exitosa, la luz blanca apaga y 5S parpadea dos veces, en ese momento puede empezar a reproducir música.

Función de apagado automático, excelente administración de energía:

- Cuando el auricular Bluetooth no está conectado al dispositivo, se apagará automáticamente después de 15 minutos;

Cargue sus auriculares para que funcionen bien:

- No use un cargador que no tenga certificación de seguridad y cuyo voltaje nominal no sea de 5V (esta unidad tiene un circuito de protección de carga. Si usa un cargador que no cumple con los requisitos, esta unidad activa la función de protección automática y termina la carga).
- En el modo encendido, si el aparato muestra que la batería está baja, cárguelo cuanto antes.
- Cuando el icono de Bluetooth en el móvil indica que la batería tiene poca carga, cargue los auriculares lo antes posible.
- La luz Led roja se enciende durante la carga. La luz Led blanca se ilumina cuando la batería está completamente cargada.

Reiniciar:

El botón de reinicio se encuentra en el agujero AUX IN, cuando el control del programa interno se desorde en ciertas condiciones, se necesita reiniciar el sistema. Inserte con un pin pequeño en el agujero AUX IN para presionar el botón de reinicio, luego encienda el dispositivo nuevamente. (Deber cargarlo primero si la batería está agotada)

Resolución de Preguntas Frecuentes:

- P: ¿Cómo conectar al Bluetooth?
R: Pulse el botón de encendido ON/OFF durante 2 segundos, el indicador LED parpadeará en blanco. Encienda el Bluetooth en su dispositivo, busque y seleccione "VOGUE 3" de la lista de dispositivos Bluetooth. Una vez emparejados correctamente, la luz blanca parpadea 2 veces cada 5 segundos.
- P: ¿Cuál es la versión de Bluetooth?
R: El auricular Bluetooth VOGUE 3 incorpora el chip Bluetooth de última tecnología, Bluetooth versión 5.3.
- P: ¿Se puede conectar con un portátil o iPad?
R: Si, los VOGUE 3 Auriculares Bluetooth tienen un micrófono incorporado que admite la función de llamada.
- P: ¿Puedo usar inalámbricamente los auriculares para hablar por teléfono?
R: Sí, los VOGUE 3 Auriculares Bluetooth tienen un micrófono incorporado que admite la función de llamada.
- P: ¿Cuáles son los tiempos de trabajo y de espera después de una carga completa?
R: Los VOGUE 3 Auriculares Bluetooth están equipados con una batería de 600mAh, lo que les permite trabajar hasta 18 horas.

▲ Advertencias durante el Uso:

- Antes de usarlo por primera vez, cárguelos por completo, la calidad del sonido será mejor.
- Cargue los auriculares al menos una vez cada 3 meses para mantener la batería de litio en buenas condiciones.
- Para proteger su audición, no escuche música a un volumen alto durante largo tiempo.
- No los utilice en un ambiente caluroso, húmedo o polvoriento.
- Evite que los auriculares se caigan o choquen con objetos duros durante su uso, lo que puede dañar el auricular y sus piezas.
- No exponga los auriculares a la lluvia, líquidos o humedad.



Enjoy your life!
Thanks for choosing this product
Please read carefully before using this product



Federal Communications Commission (FCC) Statement.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by Electronic World LLC.

may void the FCC authorization to operate this device. Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The device is installed and operated without restriction.