

# CVS-52-ASST INSTRUCTION MANUAL (CVS-58, 59, 60, 61)

## DO NOT PRINT THIS LAYER

### PRINT BACK TO BACK


**Folded Size: 3.2" (w) x 4" (h)**

**Pairing name: "iHip Art Speaker"**


**DIELINE:** \_\_\_\_\_

**FOLDING LINE:** \_\_\_\_\_

### FOLDING INSTRUCTIONS



### OUTSIDE



#### Features:

Bluetooth® Version 5.1  
30ft Wireless Range  
Portable Art Experience  
800mAh rechargeable battery  
Extra interchangeable design  
Perfect for any room

#### Package Contents:

(1) Wireless Speaker  
(2) Wall Art  
(1) 30cm Charging Cable  
(1) User Manual

#### FCC Statement:


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.  
Increase the separation between the equipment and receiver.  
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



## WALL ART WIRELESS SPEAKER



#### USER MANUAL:

Retain these instructions for future reference.



### INSIDE

<b>Specifications:</b> PRODUCT: BLUETOOTH SPEAKER WALL ART ASST Speaker: 4.0 3W Model No.: CVS-58 Size: 30 x 30 x 4.6cm Material: MDF Board BT Version: 5.1	<b>Turning ON/OFF Speaker:</b> Move the "ON/OFF" switch to the left to turn the speaker ON, Move the "ON/OFF" switch to the right to turn the speaker OFF.	<b>FM Mode:</b> Press "MODE" button to switch from Bluetooth Mode to FM Mode, When in FM mode, press the <b>▶ II</b> button to automatically select the station.	<b>Music Controls:</b> Please ensure that your device (Smartphone, tablet, or computer) is paired with the Elliptooth Speaker to stream music wirelessly. Once it is paired, play music from your device.
<b>Charging Instructions:</b> For best results, fully charge the speaker before use, Connect the Type-C cable (included) to the charging port of the speaker and insert the other end into a PC, AC/DC adapter, or similar suitable power source. The LED indicator will flash, indicating the battery is being charged. Once the speaker is fully charged, the LED light will go out.	<b>Bluetooth® Wireless Connection:</b> Your speaker can wirelessly stream audio from any Bluetooth® enabled device within 30 Feet. Simply follow the steps below: Turn ON the speaker, You will then hear the indication tone, Activate the Bluetooth on your mobile phone, tablet, or computer, It will search for various devices, The pairing name of this speaker is "iHip Art Speaker." Pair it with this device, Once paired successfully, you would hear an indication sound, If you fail to pair it within the time frame or you want to pair it with a new device (please repeat steps 1-3) Select your favorite song on your device and music will now stream through the Bluetooth speaker.	<b>TF Card Slot:</b> This speaker can play MP3 and WAV music files using the TF card slot, Once the TF card is inserted, the speaker will auto-switch from Bluetooth mode to TF card mode, Once the TF card is removed, the speaker will auto-switch to Bluetooth mode.	<b>Phone Call Controls:</b> Please ensure that your cell phone is paired with the speaker to use the below functions. Answer Incoming Call - Short press the <b>▶ II</b> button once to answer an incoming call. End Call - After your phone conversation, short press the <b>▶ II</b> button to end the call. Volume Increase (During a call) - Long press the <b>▶ II</b> / <b>V+</b> button to increase the volume.
<b>Control Panel:</b> 	<b>Pairing Name:</b> "iHip Art Speaker" 	<b>Switching the Artwork:</b> You can change out the artwork in your speaker in 3 simple steps: 	<b>Decrease Volume (During a call) -</b> Long press the <b>◀ / V-</b> button to decrease the volume. Repeat this process (Playing music): Short press the <b>▶ II</b> / <b>V+</b> button to play the next track. Decrease Volume (Playing music): Long press the <b>◀ / V-</b> button to decrease the volume. Increase Volume (Playing music): Long press the <b>▶ II</b> / <b>V+</b> button to increase the volume.