

Operation is subject to the following two conditions:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different

-- Consult the dealer or an experienced radio/TV technician for help.


The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

E20 Voice Amplifier 扩音器

Made in China

English

Wireless Microphone Amplifier



- ① Wireless mic pairing indicator
- ② Bluetooth indicator:
Flashing: Disconnected (BT mode)
Solid: Connected
Off: Auto-switched to TF mode
- ③ Battery indicator
- ④ Power/Volume knob:
Turn to "V+": "Click"=Power ON (LED① ON)→Wireless mic mode→Paired (LED① Solid)→Volume+
Turn to "V-": Volume down→"Click"=Power OFF (LED① OFF)
- ⑤ Previous track: Short press (TF/Wireless modes)
- ⑥ Play/Pause Button: During playback: Single click: Play/Pause music;
Double click: Toggle loop mode
In microphone mode: Short press: Start/Stop recording (saved to TF card)
- ⑦ Next track: Short press (TF/Wireless modes)
- ⑧ "M" mode button: Short press to switch; Long press to switch between Chinese and English (voice prompt)
- ⑨ Wireless microphone
- ⑩ AUX input
- ⑪ Wired microphone jack
- ⑫ LED display: Modes: TF (TF card), MIC (Microphone), BT (Bluetooth), AUX (External audio)
BT mode shows playback time; Hold play button 3s to display battery level (5s)
- ⑬ TF card slot
- ⑭ USB-C charging port

日本語

Instructions

1. Power on both the wireless amplifier and microphone simultaneously
2. Blue indicator on mic will flash (~2 sec) for auto-pairing
3. Pairing successful when both amplifier's LED ① and mic's LED ② stay solid blue
4. Ready for use after pairing
5. Gain Adjustment in Wired Mic Mode: Decrease Gain: Long press the Previous Track button for 2 seconds to reduce gain by one level.

Specifications

Amplifier Specifications

Frequency Response: 20Hz-16KHz
Peak Power: 10W
Speaker Impedance: 4Ω
Battery Capacity: 3.7V 5000mAh
Charging Time: ~2.5 hours
Bluetooth Version: 6.0
Weight: ~265g
Dimensions: 125.0×92.5×38.5mm


Note: Actual performance may vary depending on usage conditions and environment.

Accessories List

- | | |
|--------------------------|----------------------|
| 1. Wireless Amplifier x1 | 4. Shoulder Strap x1 |
| 2. Wired Mic x1 | 5. Charging Cable x1 |
| 3. Lanyard x1 | 6. User Manual x1 |

Note: Accessories vary by package. Refer to your actual product. This manual describes general features.

ワイヤレスマイクアンプ



使用方法

- 1、将无线麦扩音器与无线麦克风同时开机。
- 2、开机后无线麦克风蓝色指示灯闪烁, (约2秒左右) 进行自动配对。
- 3、当无线麦扩音器蓝色指示灯①与无线麦克风蓝色指示灯⑨常亮, 表示配对成功。
- 4、配对成功后可正常使用
- 5、有线麦模式下增益加减档: 长按上一曲按键2秒增益减一档 长按下一曲按键2秒增益升一档。

详细参数

无线扩音器参数

频响范围:	20Hz-16KHz(F0)
峰值功率:	10W
喇叭阻抗:	4Ω
电池容量:	3.7V 5000mAh
充电时间:	约2.5小时
蓝牙版本:	6.0
产品重量:	约265g
产品尺寸:	125.0x92.5x38.5mm

注:以上数具使用情况,因使用者使用环境和情形不同,有所差距,请以实际为准。

配件清单

- | | | | |
|---------|----|-------|----|
| 1.无线扩音器 | x1 | 4.背带 | x1 |
| 2.有线麦克风 | x1 | 5.充电线 | x1 |
| 3.挂绳 | x1 | 6.说明书 | x1 |

注:不同套装内所含物品不同,请以实际购买套装为准。本说明书所描述均为通用功能。

使い方

- 1.ワイヤレスアンプとマイクの電源を同時にON 2.起動後マイクの青ランプが点滅(約2秒)→自動ペアリング
3.アンプのLED①とマイクのLED⑤が青色点灯でペアリング成功 4.ペアリングが成功すると正常に使用できる
5.有線マイクモードでのゲイン調整
ゲイン低下:前の曲ボタンを2秒間長押しすると、ゲインが1段階低下します。
ゲイン上昇:次の曲ボタンを2秒間長押しすると、ゲインが1段階上昇します。

詳細仕様

アンプ仕様


周波数特性: 20Hz-16KHz
最大出力: 10W
スピーカーインピーダンス: 4Ω
バッテリー容量: 3.7V 5000mAh
充電時間: 約2.5時間
Bluetoothバージョン: 6.0
重量: 約265g
外形寸法: 125.0×92.5×38.5mm

1. ワイヤレスアンプ x1
2. 有線マイク x1
3. ネックストラップ x1
4. ショルダーベルト x1
5. 充電ケーブル x1
6. 取扱説明書 x1

注:セット内容はパッケージにより異なります。実際の製品をご確認ください。本書は共通機能を記載しています。

简体中文

无线麦扩音器



- ③ 与无线麦克风⑨配对指示灯。
- ② 蓝牙指示灯: 蓝牙播放模式下灯闪未连接, 灯亮连接成功; 连接TF卡自动进入TF卡模式灯灭。
- ③ 电量指示灯。
- ④ 电源开关和音量调节旋钮: 向“V+”方向旋转, 听到“哒”一声, 表示扩音器已开机指示灯①亮灯, 并进入无线麦人声扩音状态; 与无线麦克风配对成功后指示灯①亮灯; 继续旋转声音逐渐增大。反之向“V-”方向旋转, 声音逐渐减小, 直至听到“哒”一声, 表示扩音器已关机, 此时指示灯①熄灭。
- ⑤ 上一曲键: 在TF卡、无线播放状态下, 短按切换为上一曲。
有线麦模式下增益加/减档: 长按上一曲按键2秒增益减一档。
- ⑥ 播放/暂停键: 正常播放状态下, 单击控制音乐的播放及暂停; 双击控制循环播放模式。
麦克风工作模式下, 短按播放/暂停键切换录音开始/停止, 文件存储在TF卡。
- ⑦ 下一曲键: 在TF卡、无线播放状态下, 短按切换为下一曲。
有线麦模式下增益加/减档: 长按下一曲按键2秒增益升一档。
- ⑧ “M”模式切换键: 开机状态下, 短按可切换工作模式, 长按可切换中英文; 并伴随相应的语音提示。
- ⑨ 无线麦克风 ⑩ AUX接口: 连接播放器放音乐。 ⑪ 有线麦克风接口
- ⑫ LED屏: TF-SD卡模式; MIC-麦克风模式; BT-蓝牙模式; AUX-外设音频输入模式;
BT-蓝牙模式播放时, LED屏显示播放时间; 长按播放/暂停键3S, LED屏显示5S当前电量。
- ⑬ TF卡座 ⑭ USB-C充电口

注:使用環境や操作条件により記載数値と実績が異なる場合があります