





11AX80SISO-Ant3-5985-30~3000-PASS




11AX80SISO-Ant3-5985-3000~10000-PASS



11AX80SISO-Ant3-5985-10000~40000-PASS



11AX80SISO-Ant4-5985-30~3000-PASS




11AX80SISO-Ant4-5985-3000~10000-PASS



11AX80SISO-Ant4-5985-10000~40000-PASS




11AX80SISO-Ant1-6145-30~3000-PASS




11AX80SISO-Ant1-6145-3000~10000-PASS




11AX80SISO-Ant1-6145-10000~40000-PASS



11AX80SISO-Ant2-6145-30~3000-PASS




11AX80SISO-Ant2-6145-3000~10000-PASS



11AX80SISO-Ant2-6145-10000~40000-PASS




11AX80SISO-Ant3-6145-30-3000-PASS




11AX80SISO-Ant3-6145-3000-10000-PASS




11AX80SISO-Ant3-6145-10000-40000-PASS



11AX80SISO-Ant4-6145-30-3000-PASS




11AX80SISO-Ant4-6145-3000-10000-PASS



11AX80SISO-Ant4-6145-10000-40000-PASS



11AX80SISO-Ant1-6385-30~3000-PASS




11AX80SISO-Ant1-6385-3000~10000-PASS




11AX80SISO-Ant1-6385-10000~40000-PASS




11AX80SISO-Ant2-6385-30~3000-PASS




11AX80SISO-Ant2-6385-3000~10000-PASS



11AX80SISO-Ant2-6385-10000~40000-PASS




11AX80SISO-Ant3-6385-30~3000-PASS




11AX80SISO-Ant3-6385-3000~10000-PASS




11AX80SISO-Ant3-6385-10000~40000-PASS



11AX80SISO-Ant4-6385-30~3000-PASS




11AX80SISO-Ant4-6385-3000~10000-PASS



11AX80SISO-Ant4-6385-10000~40000-PASS




11AX80SISO-Ant1-6465-30-3000-PASS




11AX80SISO-Ant1-6465-3000-10000-PASS




11AX80SISO-Ant1-6465-10000-40000-PASS



11AX80SISO-Ant2-6465-30-3000-PASS




11AX80SISO-Ant2-6465-3000-10000-PASS



11AX80SISO-Ant2-6465-10000-40000-PASS




11AX80SISO-Ant3-6465-30~3000-PASS




11AX80SISO-Ant3-6465-3000~10000-PASS




11AX80SISO-Ant3-6465-10000~40000-PASS




11AX80SISO-Ant4-6465-30~3000-PASS




11AX80SISO-Ant4-6465-3000~10000-PASS



11AX80SISO-Ant4-6465-10000~40000-PASS




11AX80SISO-Ant1-6545-30~3000-PASS




11AX80SISO-Ant1-6545-3000~10000-PASS



11AX80SISO-Ant1-6545-10000~40000-PASS



11AX80SISO-Ant2-6545-30~3000-PASS



11AX80SISO-Ant2-6545-3000~10000-PASS



11AX80SISO-Ant2-6545-10000~40000-PASS