

# 便携式无线音箱 Portable Wireless Speaker

# Simplicity

# ((一)) 产品使用说明



- 1 短按,上一曲;长按音量减;收音机模式下,短按进入上一电台
- ② 长按3秒开/关机;播放时,短按模式切换(T卡、收音机、无线、AUX输入); 关机模式下,长按开机键10秒复位
- 短按: 免提/挂断/播放/暂停: 长按(约1秒): 拒接收音机模式下,短按静音,长按进行搜台双击: 切换LED灯圈的灯效
- 4 短按,下─曲;长按音量加;收音机模式下,短按进入下─电台
- 5 TF 卡槽
- ⑥ 充电指示灯: 充电时红灯常亮, 充满电红灯熄来
- 7 TYPE-C充电口 8 MIC 口
- 3.5mm音類线接□
- 音箱炫彩灯效指示灯:开机炫彩指示灯为冰蓝色快闪;无线连接后,指示灯呼吸闪;播放时炫彩灯颜色共有冰蓝色/红色/橙色/黄色/绿色/点/紫7种颜色,双击播放暂 停键可切掉不同颜色和效果。
- F據可切映作问题已至以來。 IF卡模式/收音机模式/无线模式的灯效切换操作一样;AUX输入模式时播放音乐LED



两台音箱开机后按其中一台的开关键两次,音箱会寻找另一台配对,配对成功 后有提示音,此时再连接手机蓝牙可以两台一起播放

## ((一)) 规格参数

无线版本:	5.3
传输距离:	≥10米
工作电压:	3.7V
输入电压:	DC 5V==1A
电池容量:	1800mAh 锂聚合物
额定功率:	5W
电池电压:	3.7V
TF ‡:	支持 (最大32G)
产品重量:	270±5g
产品尺寸:	75*94mm

1.播放时长依据所播放的音乐类型/音量不同而有所差异; 2.开机后5分钟左右未连接手机蓝牙音箱会自动关闭

# ((一)) 注意事项

- 首次使用请将本产品充满电。 请勿以任何理由拆除或维修改装本产品,否则可能会导致起火,电子击穿甚至
- 如充电完毕,请断开充电器与本设备的连接,需拔掉充电器,连续充电时间请
- 勿商立[2] 时。 请不更将旧电池扔在旧生活垃圾中进行处理,若电池处置不当可能会导致电池 起火或爆炸。请遵守当地规定处理本产品,电池及其他附件。 电池禁止拆卸,撞击,挤压或投入火中,若出现严重膨胀,请勿继续使用。

- 请勿自行维修本产品。 电池不得暴露在过热的环境中。
- 请使用符合国家标准日诵讨CCC认证的直流SV电源话配器进行充电。



此设备符合FCC规则的第15部分,操作需满足以下两个条件: (1) 本设备可能不会造成有害干扰; (2) 该设备必须接受接收割的任何干扰,包括可能导致不期望操作的干扰; 未经合规责任为阴栅批准的任何变更或修改可能会导致用户无权操作设备。


注:根据FCC规则第15部分的规定,本设备经过测试,符合良类数字设备的限制。 这些限制旨在为住宅设施提供合理的保护,防止有事干扰。该设备可产生用途并 可服制材施胜。如果未按取银兜袋和伊田,可能会对无处通信造成有事干扰。 然而,不能保证在特定安装中不会发生干扰。如果该设备确实对无线电或电视接收 选定有事干扰。(可避过关闭和打开设备来确定) ,则鼓励用户尝试通过以下一项或 多明措施纠正干扰: ● 推闭设备和接收器之间的间隔。 ● 排资的造程到与接收器注极的电路不同的电路上的措施。 ● 排资的通程到与接收器注接的电路不同的电路上的措施。

### (( )) Precautions

The radio function is not applicable to the products in Europe, Canada and the United States

★The waterproof grade is ipx4. Please do not immerse the product in

# ((())) Product instruction:



- 1 Short press to the previous song;long press volume down; when in Radio mode, shot press to previous channel
- 2 Long press 3s to power on/off; short press transfer to (TF Card Memory, Radio, Wireless, AUX Input) function; If it is powered off,it will be "Reset" after long press 10s
- 3 Short press: play/pause/handsfree/hand Up; Long press (1s) :refuse the phone call When in Radio mode, short press to mute the speaker, long press to search Double click: switch the light effect of LED light circle

- 4 Short press to next song;long press volume up. When in the radio mode, short press to next channel
- 5 TF card Slot
- 6 Charging indicator light: the red light is always on when charging, and the red light is off when fully charged
- 7 TYPE-C charging port 3 MIC 3.5mm Audio Connetor
- Speaker dazzle light effect indicator: the dazzle light is ice blue flash when starting up; After Wireless connection, the indicator light flashes; When playing, the color of the colorful lights is ice blue/red/orange/ yellow/green/white/purple. Double click to play temporarily Stop button can switch different colors and effects. The lamp effect switching operation of TF card mode/radio mode/ Wireless mode is the same; In AUX input mode, the LED light for playing music is always on, and it flashes in breath state when pausing

### (( TWS Function:

After the two speakers are turned on, press one of the " "buttons twice, and the speaker will find another pair. After the pairing as retained, a brisk tone was found. At this point, connect Wireless to play muisc together.

# (( Specifications

Wireless version:	5.3
Working distance:	≥10 meter
Working voltage:	3.7V
Input voltage:	DC 5V1A
Battery capacity:	1800mAh lithium polymer
Rated power:	5W
Battery voltage:	3.7V
TF card:	Support (up to 32G)
Weight:	270±5g
Dimensions:	75*93mm

- 1.The working time of the speaker varies depending on the music type or
- 2.The speaker will turn off automatically if you leave Wireless unconnected after turning on over about 5 minutes.

# Warranty Service

- Please fully charge this product for the first time.
- Do not remove or repair this product for any reason, otherwise it may cause fire, electronic breakdown or even completely damage the product.
- Do not soak the product in liquid.
  If charging is completed, please disconnect the charger from the device, unplug the charger, and charge continuously do not exceed 12 hours. Please do not throw the old battery into the old household garbage for disposal. Improper disposal of the battery may cause the battery in case of fire or explosion, please handle this product, battery and other accessories according to local regulations.
- The battery shall not be disassembled, impacted, squeezed or put into the fire. In case of serious expansion, please do not continue to use it
- Do not repair this product by yourself.
  The battery shall not be exposed to overheating.
- Please use a DC 5V power adapter that complies with national standards and has passed CCC certification for charging.

### FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to

- the following two conditions: (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- (1) Reorient or relocate the receiving antenna.
- (2) Increase the separation between the equipment and receiver.
- (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.