



## 标准配置



## 产品外观



## 操作说明

### ① 开关机及蓝牙配对

#### ● 开关机

- 长按2秒MFB键开/关机，开机时蓝色LED闪烁，语音提示“power on”；关机时红色LED闪烁，语音提示“power off”

#### ● 配对模式

- 开机后进入配对模式，打开需连接设备蓝牙，搜索Lecoo-C8进行配对，配对成功后（语音提示“联机成功”）蓝灯3秒闪一次，断开蓝牙连接，重新进入配对模式。
- 开机后自动回连最后连接过的蓝牙设备，5分钟无蓝牙连接自动关机。

### ② 音频模式

#### ● 音量设置

- 单击触控区域为音量+，调节到最大音量时有提示声
- 长按触控区域为音量-

#### ● 调用语音助手

- 语音助手/Siri：双击MFB键

#### ● 通话设置

- 接听电话：单击MFB键
- 拒接电话：单击触控区域
- 挂断电话：单击MFB键

### ③ 充电模式

- 充电时间约1.5小时，低电报警语音提示“battery low”
- 低电报警间隔60秒，红灯闪烁，充电时红色LED灯亮，充满后蓝色LED灯亮
- 充电过程中不能开机


## 4 保修说明

### ④ 保修说明


●就本文件附随的产品做如下保证：如产品在您购买日起十二（12）个月内，在正常使用情况下因质量瑕疵发生损坏，免费修理；维修后的产物，在剩余保修期内继续享有保修。购买日以销售发票日期为准；如无法确定购买日，则保修期自产品生产日期起按十三（13）个月计算。

| Lecoo 来酷产品保修卡  |       |    |  |  |  |  |  |  |
|--|-------|----|--|--|--|--|--|--|
| 用户名  | 性别    | 年龄 |  |  |  |  |  |  |
| 联系电话   |       |    |  |  |  |  |  |  |
| 联系地址   |       |    |  |  |  |  |  |  |
| 邮政编码   | 电子邮箱  |    |  |  |  |  |  |  |
| 销售日期   | 产品序列号 |    |  |  |  |  |  |  |
| 销售单位名称   |       |    |  |  |  |  |  |  |
| 销售发票号码   |       |    |  |  |  |  |  |  |
| 1.涂改保修卡、产品编码与产品本体不符；<br>2.因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏；<br>3.因不可抗力（如地震、战争、火灾等）或意外导致的故障或损坏；<br>4.任何因尖锐物体造成的损坏<br>5.有烧损或水浸迹象的产品<br>6.因擅自拆改导致的损坏<br>7.产品正常使用过程中发生的老化、脱色、磨损、破裂和其他损耗 |       |    |  |  |  |  |  |  |
| 非维修范围  |       |    |  |  |  |  |  |  |

## Standard configuration



## Appearance



## Instructions

### ① Power on/off & Bluetooth pairing

#### ● Power on/off

- Long press the MFB button for 2 seconds to turn on/off, the blue LED flashes when turning on, and the voice prompt “power on”；the red light flashes when turning off, and the voice prompt “power off”

#### ● Bluetooth pairing

- Power on, enter the pairing mode, and turn on the Bluetooth of the device to be connected, search for “Lecoo-C8” for pairing, and the blue light will flash per 3 seconds after the pairing is successful. (voice prompt “Lian ji cheng gong”) It will automatically enter the pairing mode after disconnecting
- Automatically connect back to the last connected Bluetooth device after power on, Automatic shutdown without Bluetooth connection in 5 minutes

### ② Audio mode

#### ● Volume setting

- One click the touch area to be volume +, there will be a prompt sound when the volume is adjusted to the maximum
- Long press the touch area for volume -

#### ● Voice assistant

- Double-click the MFB button

#### ● Call mode

- One click the MFB button to answer phone call
- One click the touch area to reject phone call
- One click the MFB button to hang up the current call

### ③ Charging mode

- Charging time about 1.5 hours, low battery alarm voice prompt “battery low”
- Low battery alarm interval is 60 seconds, red light flashes, The red LED is on when charging, and the blue LED is on when it is full
- Unable turning on while charging

## Instructions

### ④ Warning message

● This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

邮箱：

lxlecoo@163.com

服务监督热线：

400-010-8300

想要更详细的了解真无线蓝牙眼镜请登录

www.lecoo.com