

户外露营灯



用户手册

使用产品前请仔细阅读此说明书以保证产品得到正确使用

使用说明

1.蓝牙音箱功能

长按 ● 按键3秒开启/关闭蓝牙音箱，短按 ● 按键减小音量，短按 ● 按键增加音量，长按 ● 按键切换上一曲，长按 ● 按键切换下一曲。

*音箱出现语音提示（Power on）表示开启蓝牙音箱；

*音箱出现语音提示（Power off）表示关闭蓝牙音箱；

*音箱出现语音提示（Connect）表示连接蓝牙设备；

*音箱出现语音提示（Disconnect）表示断开蓝牙设备；

*音箱功能与灯光功能同时开启状态下， ● 按键和 ● 按键仅用于调节灯光亮度，音量调节和切换音乐需在您的蓝牙设备上完成。

2.灯光功能

短按 ● 按键开启/关闭灯光，灯光分为四种，依次为暖光/白光/暖白光/SOS信号灯，短按 ● 按键灯光亮度逐步降低，短按 ● 按键灯光亮度逐步增加。

*SOS信号灯不能调节亮度。

3.手电筒功能

长按 ● 按键0.5秒开启/关闭手电筒。

4.指示灯状态说明

充电中，指示灯为红色闪烁状态；

充满电，指示灯为红色常亮状态；

本产品为其他设备充电时，指示灯为蓝色常亮状态。

产品规格

产品名称：户外露营灯	色 温：1800–7000K
产品型号：K11	充电接口：Type–C
产品材质：ABS+PC+电子元件	额定输入：5V – 2A
流 明：30–720LM	产品尺寸：77*77*190mm
额定功率：≥5W	彩盒尺寸：82*82*199mm
电池容量：3000mAh	执行标准：Q/LCSJ003
蓝牙版本：5.3	产 地：中国东莞
扬 声 器：4Ω 5W	

产品示意图



注意事项

*产品最佳使用及存储环境温度为一10℃至45℃，请勿在极寒极热环境下使用。

*禁止灯光直射眼睛，儿童需在成人监督引导下正确使用产品

*请勿私自拆卸或维修本产品,以免发生意外或可能会导致产品损坏。

*请用优质电源插座与标配的USB充电线给本产品充电

产品标配

主机x1、硅胶手提带x1、充电线x1、中英文说明书x1

合格证
检测员
QC-010

FCC警告

该设备符合FCC规则第15部分。操作须满足以下两个条件：

- (1)该设备可能不会造成有害干扰，并且
- (2)该设备必须接受接收到的任何干扰，包括可能导致不良操作的干扰。

注1：根据FCC规则第15部分，该设备已过测试，并符合B类数字设备的限制。这些限制旨在提供合理的保护，防止住宅设施中的有害干扰。该设备产生、使用并可以辐射无线电频率能量，如果未按照说明安装和使用，可能会对无线电通信造成有害干扰。然而，不能保证特定安装中不会发生干扰。如果此设备确实对无线电或电视接收造成有害干扰（可以通过关闭和打开设备来确定），则鼓励用户尝试通过以下一项或多项措施来纠正干扰：

- 重新定位或重新定位接收天线。
- 增加设备和接收器之间的距离。
- 将设备连接到与接收器连接的电路不同的电路上的插座。
- 咨询经销商或经验丰富的广播/电视技术人员以寻求帮助。

注2：未经合规责任方明确批准对该单元的任何更改或修改都可能导致用户操作设备的权力无效。

该设备已接受评估，以满足一般射频暴露要求。该设备可在便携式暴露条件下使用，不受限制。

Outdoor Camping Lamp



user manual

Please read this manual carefully before using the product to ensure that the product is used correctly

Instructions

1. Bluetooth Speaker Function

Turning On/Off: Press and hold the power button for 3 seconds to turn the Bluetooth speaker on or off.

Volume Control: Press the minus button briefly to decrease the volume, and the plus button briefly to increase the volume.

Track Control: Press and hold the minus button to switch to the previous track, and press the plus button briefly to switch to the next track.

Voice Prompt "Power on": Indicates the Bluetooth speaker is turned on.

Voice Prompt "Power off": Indicates the Bluetooth speaker is turned off.

Voice Prompt "Connect": Indicates the Bluetooth device is connected.

Voice Prompt "Disconnect": Indicates the Bluetooth device is disconnected. When both the speaker and light functions are on, the minus and plus buttons are used only for adjusting the light brightness. Volume control and track switching should be done on your Bluetooth device.

2. Light Function

Turning On/Off: Press the light button briefly to turn the light on or off. The light has four modes: warm light, white light, warm white light, and SOS signal light.

Brightness Control: Press the minus button briefly to decrease the brightness gradually, and the plus button briefly to increase the brightness gradually. The brightness of the SOS signal light cannot be adjusted.

3. Flashlight Function

Turning On/Off: Press and hold the flashlight button for 0.5 seconds to turn the flashlight on or off.

4. Indicator Light Status

Charging: The indicator light flashes red while charging.


Fully Charged: The indicator light remains solid red when fully charged.

Charging Other Devices: The indicator light remains solid blue when charging other devices.

Product Specifications

Product Name: Outdoor Camping Lamp	Product Model: K11
Color Temperature: 1800–7000K	Charging Port: Type–C
Material: ABS + PC + Electronic Components	Rated Input: 5V – 2A
Product Dimensions: 77 x 77 x 190 mm	Lumen Output: 30–720 lm
Color Box Dimensions: 82*82*199 mm	Rated Power: ≥5W
Standards Complied: Q/LCSJ003	Battery Capacity: 3000mAh
Speaker: 4Ω 5W	Bluetooth Version: 5.3
Place of Origin: Dongguan, China	

Schematic diagram of product



Precautions

* The optimal operating and storage environment temperature of the product is–10℃ to 45℃. Do not use it in extremely cold and hot environments.

* Direct lighting into the eyes is prohibited. Children must use the product correctly under adult supervision and guidance.

* Please do not disassemble or repair this product without permission to avoid accidents or possible product damage.

* Please use a high–quality power outlet and standard USB charging cable to charge this product

Packaging content

Outdoor camping light x1 Hand strap x1
USB charging cable x1 User Manual x1

certificate
surveyor
QC-010

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.