

欢迎使用多功能支架 CMIIT ID:XXXXX

连接操作步骤：

- ① 长按开机键 “ ” 两秒钟开启设备
- ② 待蓝灯亮起闪烁
- ③ 打开手机设置，搜索连接设备
- ④ 点击 “ADYSS” 连接设备等待5秒，蓝灯亮配对成功

支持手机型号：

苹果系列机型 (iOS 5.0 以上系统)

安卓系列机型 (Android 4.2.2以上系统)

请按时更新手机系统，避免版本过低无法兼容使用

注意事项 (不在保修范围) :

- 使用自拍杆前请确保手机完好的固定在夹头上，智能机脱落等产生的损伤
- 使用前请确认使用地域和设施限制的场所，禁止违反公共秩序的行为。
- 使用期间将电源线强力拉、旋转等导致断线。
- 高出跌落导致外壳损伤不良。
- 使用超出产品负荷电源，导致产品发热及电路板烧坏。

① 请勿将产品置入低温、潮湿地方

② 请勿将产品丢入火中、远离火源

③ 警告：内含小零件

不适合3岁及以下儿童使用


一年有限保修摘要

ADYSS 声明保证所附带的硬件产品，从原先零售购入的日期一年内在材料和工艺方面无瑕疵，均可受理售后问题。ADYSS 声明对正常使用磨损不做担保，对于事故或滥用造成的损坏也不做担保。若要获取服务可访问ADYSS 声明拥有的零售店或ADYSS 声明授权服务提供商，即可为你的产品酌情进行修理、更换你享有的保修权益是附加在本地消费者法律所提供的权利以外的。当您根据本保修政策提出索赔时，可能需要提供购买证明的详细信息。


执行标准:Q/HHLH 003-2019




产品操作步骤:




松开扭头可上下角度调节
完成角度调节后锁紧扭头



支持横拍/竖拍模式




单夹扩展: 65mm-95mm
双夹扩展: 142mm-260mm
①往回按下防滑夹头 “ ”
②可以打开防滑卡盘以夹住手机或平板电脑 “ ”




长按 “ ” 三秒蓝色灯闪烁，等待连接中，打开手机设置，蓝牙，搜索并刷新蓝牙名：“ADYSS”点击连接，蓝色灯熄灭说明已配对成功了，开启相机即可拍照、摄像。




遥控器跟手机连接,遥控有效距离10米，遥控器长按三秒是开机，遥控器不操作，5分钟后会自动关机，已配对的，下次打开遥控器，打开蓝牙新手机会自动连接，旧款手机需要点一下蓝牙名称。




1/4云台螺丝通用摄影配件



先从底部向外拉开三脚架



向外打开三脚架



按住螺纹滑套并将其向下拉末端展开，可以稳定 “ ” 并按住螺纹滑套可拉起和收回 “ ”

Welcome to use multi-function bracket

Connection steps:

- ① Press and hold the power button “ ” for 2 seconds to turn on the device.
- ② Wait until the blue light is on
- ③ Open phone settings, search for link devices
- ④ Click “ADYSS” to connect the device and wait for 5 seconds.

Supported mobile phone model:

Apple Apple series models (iOS 5.0 and above)

Android Android series models (Android 4.2.2 and above)
Please update your phone system on time to avoid the version being too low to be compatible for using.

⚠ Matters need attention (not involved in the warranty)

- Before using the selfie stick, please make sure that the phone is properly fixed on the collet, and the damage caused by the smart phone falling off.
- Please confirm the place of using region and facility restrictions before using, and prohibit the behavior of public property violations.
- Pulling and rotating the power cord during using period which causes short circuit.
- Falling from a high place that causes damage to the outer casing.
- Using a power supply that exceeds the product load that causes the product heating up and the circuit board burning out.

① Do not place the product in low-temperature and humid place.

② Do not throw the product into the fire and keep away from the fire.

③ Warning: Contains small parts. Not suitable for children 3 years old and below.


One Year Limited Warranty Summary

ADYSS warrantied that the delivered hardware product to be free from defects in materials and workmanship for a period of one year from the original retail purchase date, and the after-sales problem can be accepted. ADYSS would not guarantee neither the normal use of wear nor the damage caused by accident or abuse. Visit a retail store owned by ADYSS or ADYSS Authorized Service Providers for the service, where you can have the product repaired accordingly. Replacing your warranty rights is not included in the additional rights provided by local consumer law. When you make a claim according to this warranty policy, you may need to provide the detail information of proof of purchase.


Executive standard: Q/HHLH 003-2019




Product operation steps




Loosen the twist head and adjust the angle up and down. After the angle adjustment is completed, lock the twist.



Vertical mode




Single clip expansion: 65mm-95mm
Double clip expansion: 142mm-260mm
① Push back the anti-skid collet “ ”
② The anti-skid chuck can be opened to clamp the mobile phone or tablet PC “ ”




Long press “ ” for three seconds and blue light will flash, mobile phone settings search: “ADYSS” click the link. If the blue light goes off, it means that the pair has been successfully paired. Turn on the camera to take photos and video.




The remote control is connected to the mobile phone, the effective distance of the remote control is 10 meters, the remote control is turned on for three seconds, the remote control does not operate, and it will automatically shut down after 5 minutes, the paired one, the next time you open the remote control, open the Bluetooth new mobile phone will automatically connect, the old mobile phone needs to click the Bluetooth name.




1/4 camera screw



First pull the tripod out from the bottom



Open the three feet outward



Press and hold the threaded sliding sleeve and pull it down to the end to unfold, it can be stable “ ”. Press and hold the threaded sliding sleeve to pull up and retract “ ”

尺寸：80*120 正面中文，背面英文

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.