

110x38mm

Bluetooth pairing instructions

1. Press the Auto pairing button on the device
2. When the TV screen says "Start pairing." Hold down the Back and Home buttons on your remote until the LED light on your remote starts flashing. Chromecast TV will automatically pair with the remote control (note: If automatic pairing is not successful, you can select Chromecast Remote by clicking the automatic pairing button, and then press and hold the button to confirm. The yellow light of Chromecast TV will light up to complete the pairing operation)

How to set Power/ volume / Input Buttons:

- 1, Go to Chromecast TV Setting -> Remotes and accessories -> Set up remote buttons -> Add device -> TV/Soundbar/AV receiver
- 2, Select the device, select the brand, and follow the prompts to complete the operation.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction