




# 智能眼镜 Y11 ( 按键款 ) 中英文说明书

单页尺寸 : 40mm×175mm 展开尺寸 : 280mm×175mm

PS: 重点字体已标注红色, 印刷出来也需是红色。

V1.0		按键功能概述	智能节能关机	2. 欣赏音乐	重要安全信息	产品保修凭证	蓝牙连接示意图																														
<h2>智能眼镜</h2> <h3>Y11 按键款使用说明书</h3> <p>1. 同时按眼镜左右腿电源键2秒开机 (只按一边腿则另一边腿功能不会启动) 2. 任意按左(右)电源键2下唤醒AI语音助手 3. 快速按左镜腿电源键2下播放下一曲 4. 快速按右镜腿电源键2下播放下一曲 5. 更多功能详情请看使用说明书</p> <p><b>• 声明</b> 首先对您使用本公司的产品表示感谢! 在使用之前请先详细阅读此说明书, 正确使用此产品。为了更好的服务, 本用户手册的内容可能变更。因为产品的性能和功能而产生的变更将不做另行通知。</p> <p><b>• 产品简介</b> 多功能智能眼镜采用蓝牙芯片, 兼容主流品牌手机和平板电脑等蓝牙设备, 支持aptX音频解码技术, 达到CD级高品质音质, 持久续航, 左右双喇叭, 开放式定向发音, 无缝接入外界声音, 可时刻获取周围环境信息, 安全、智能、健康、便捷。</p> <p>多功能智能眼镜, 本产品是具有立体声音响功能的蓝牙眼镜, 操作简便, 美观实用, 便于携带。</p> <p><b>• 包装清单</b> 智能眼镜、智能眼镜充电线、使用说明书、眼镜清洁布</p>		 <p>① 右按键 (开关机/语音助手/下一曲/拒接来电/接听电话/挂断电话/暂停/播放/中英文切换/导航/拍照功能) ② 左按键 (开关机/语音助手/上一曲/拒接来电/接听电话/挂断电话/暂停/播放/中英文切换/导航/拍照功能) ③ 磁吸充电口 ④ 扬声器 ⑤ 麦克风 ⑥ LED指示灯</p>	<p>未连接设备状态下3分钟自动关机。</p> <p><b>中英文切换</b> 任意按左(右)电源键4下中英文切换。</p> <p><b>开关机与配对</b></p> <p><b>1. 开机与配对:</b> 打开手机等蓝牙设备, 同时按眼镜左右腿电源键2秒开机, 红蓝灯闪烁开机成功; TWS开机自动配对, 主(红蓝闪烁)副(熄灭); 蓝牙设备与眼镜配对成功后左右腿LED灯熄灭。 (手机进行蓝牙连接请参考倒数第一页示意图)</p> <p><b>2. 关机:</b> 同时按眼镜左右腿电源键3秒, 语音提示【关机】, 即与手机断开连接。</p> <p><b>电量提示</b></p> <p>1. 低电报警, 语音提示【电量低, 请充电】; LED指示灯持续闪烁3秒间隔5秒。 2. 低电关机, 语音提示【关机】; LED指示灯长亮1秒。 3. 充电中, LED指示灯红灯长亮。 4. 充电完成, LED指示灯红灯自动熄灭。</p> <p><b>功能操作</b></p> <p>已连接手机蓝牙, 待机状态下, 任意按左(右)电源键2下可唤醒AI语音助手。</p> <p><b>1. 接打电话</b></p> <ul style="list-style-type: none"> <li>拨打电话: 先暂停音乐, 任意按左(右)电源键2下唤醒AI语音助手, 然后根据提示音进行语音操作, 打电话给*** (通讯录里面名字) 或者对方手机号码, 即可呼出电话;</li> <li>接听电话: 来电状态下任意按左(右)电源键1下接听电话;</li> <li>挂断电话: 通话状态下任意按左(右)电源键1下挂断电话;</li> <li>拒接来电: 任意按左(右)电源键1.5秒拒接来电;</li> <li>重拨: 音乐关闭状态下任意按左(右)电源键3下可直接拨打最后一次通话记录号码。</li> </ul>	<p><b>2. 欣赏音乐</b></p> <ul style="list-style-type: none"> <li>精准选歌: 任意按左(右)电源键2下, 听到提示音后说, 播放音乐(如上海滩), 即可调用并播放手机里面的歌曲;</li> <li>随机放歌: 任意按左(右)电源键2下, 听到提示音后说, 播放音乐, 即可调用并随机播放手机里面的歌曲;</li> <li>播放上一曲: 快速按左镜腿电源键2下;</li> <li>播放下一曲: 快速按右镜腿电源键2下;</li> <li>暂停/播放: 任意按左(右)电源键1下;</li> </ul> <p><b>3. 播放音乐与拨打电话之间切换:</b></p> <ul style="list-style-type: none"> <li>当在听音乐过程中需要拨打电话时, 任意按左(右)电源键1下将音乐暂停, 然后快速按电源键2下, 听到提示音后即可拨打电话。</li> </ul> <p><b>4. 导航:</b></p> <ul style="list-style-type: none"> <li>开启导航: 先暂停音乐, 任意按左(右)电源键2下, 语音唤醒功能开启, 然后根据提示音进行语音操作, 帮我导航到“地方”。</li> <li>关闭导航: 任意按左(右)电源键2下, 听到提示音后说“关闭地图”。</li> </ul> <p><b>5. 拍照功能:</b></p> <ul style="list-style-type: none"> <li>打开相机状态下, 安卓系统手机任意按左(右)电源键1下即可拍照, iOS系统手机需任意长按左(右)电源键2秒即可拍照。</li> </ul> <p><b>6. 警告</b></p> <p>1. 请勿以任何理由拆除或维修改装本产品, 否则可能会导致起火, 电子击穿甚至彻底损坏本产品。 2. 请勿将设备置于温度过低或过高(0°C以下或45°C以上)环境。 3. 请勿将产品接触腐蚀性液体及浸泡在液体里。 4. 不能将眼镜放在阳光下长时间曝晒, 否则容易变色、老化、折断。 5. 请勿将充电线缆前端靠近金属物体, 防止磁吸金属物体后引起的短路危险。 6. 请遵守在任何环境里明确禁止使用的相关法律法规。</p>	<p><b>重要安全信息</b></p> <p>1. 在使用本产品前, 请先阅读所有安全信息以确保正确和安全使用。 2. 使用未经授权制造商认可的电源、充电器或电池, 可能引发火灾、爆炸或其他危险。 3. 请使用本制造商认可且与此型号设备配套的配件。 4. 请在温度0°C~35°C范围内使用本产品, 并在温度-20°C~45°C范围内存放设备及其配件。当环境温度过高或过低时, 可能会影响设备故障。 5. 若设备使用不可拆卸的内置电池, 请勿自行更换电池, 以免损坏电池或设备, 电池只能由授权服务中心更换。 6. 如充电未完, 请断开充电器与本设备的连接, 并从电源插座上拔掉充电器。连续充电时间请勿超过12小时。 7. 请保持设备干燥。 8. 若设备或其他任何部件不能正常工作, 请勿自行维修产品。 9. 连接其他设备时, 请参考使用说明书的连接方法, 不要随意连接不配套的设备。 10. 为避免听力受损, 请勿长时间使用高音量。</p> <p><b>使用警告</b></p> <p>请遵循相关法律法规, 不要在以下环境使用。 • 如加油站, 油库, 化学仓库附近等存储有易燃易爆物或化学品的环境, 严禁使用设备。 • 请勿在医院手术室、急诊室、深切治疗部等场所使用此设备, 为避免干扰医疗仪器工作, 使用此设备时请远离心脏起搏器、助听器, 植入耳蜗等医疗设备, 请保持此设备和起搏器之间超过15厘米的距离。 • 若要在个人医疗设备附近使用此设备, 请咨询医师和设备制造商。 • 请遵守有关车辆时使用此设备的所有安全警告和规定。 • 雷雨天气时, 为避免雷击事故, 请勿在室外使用。 • 充电时, 请勿边充电边通话。 • 请勿在浴室等高湿度的地方对产品进行充电, 否则会导致触电, 人身伤害, 起火和电器损坏。 • 请遵守在任何环境里明确禁止使用的相关法律法规。</p>	<p><b>产品保修凭证</b></p> <p>产品保修期内出现非人为损坏的性能故障可以享受下列三包服务: • 自收货之日起7日内, 产品出现非人为损坏的性能故障, 用户可选择退回货款或者更换同型号同规格的产品。 • 自收货之日起15日内, 产品出现非人为损坏的性能故障, 用户可选择更换同型号同规格的产品。 • 自收货之日起一年内, 产品出现非人为损坏的性能故障, 用户可寄回维修。 属于下列情况不在“三包”服务范围之内: • 未经授权的维修、误用、碰撞、疏忽、滥用、进水、事故、改动或撕毁、涂改产品标贴、封条。 • 超过“三包”服务有效期的。 • 因火灾、水灾、雷击等不可抗力造成的损坏。 • 因人为原因导致的产品性能故障。 • 未按产品说明书要求使用而造成损坏的。</p> <p><b>保修卡</b></p> <p>尊敬的用户, 本保修卡是您将来申请保修的凭证, 请配合销售商填写并妥善保管。</p> <table border="1" data-bbox="1819 1522 2113 2028"> <tr><td>用户名</td><td></td></tr> <tr><td>联系人电话</td><td></td></tr> <tr><td>通讯地址</td><td></td></tr> <tr><td>电子邮箱</td><td></td></tr> <tr><td>邮编</td><td></td></tr> <tr><td>产品名称</td><td></td></tr> <tr><td>产品型号</td><td></td></tr> <tr><td>产品条码</td><td></td></tr> <tr><td>名称</td><td></td></tr> <tr><td>地址</td><td></td></tr> <tr><td>联系电话</td><td></td></tr> <tr><td>邮编</td><td></td></tr> <tr><td>销售日期</td><td></td></tr> <tr><td>发票号码</td><td></td></tr> <tr><td>备注</td><td></td></tr> </table>	用户名		联系人电话		通讯地址		电子邮箱		邮编		产品名称		产品型号		产品条码		名称		地址		联系电话		邮编		销售日期		发票号码		备注		 <p>① 进入设置 ② 选择蓝牙选项 ③ 确保蓝牙开关处于 ON 状态 搜索设备名: Y11 点击蓝牙名进入连接 ④ 蓝牙连接成功</p>
用户名																																					
联系人电话																																					
通讯地址																																					
电子邮箱																																					
邮编																																					
产品名称																																					
产品型号																																					
产品条码																																					
名称																																					
地址																																					
联系电话																																					
邮编																																					
销售日期																																					
发票号码																																					
备注																																					

V1.0		Key Function Overview	Energy saving shutdown	Warning	Use of Warnings	Warranty card																																											
<h2>Smart Glasses</h2> <h3>Y11 Keyed model instruction manual</h3> <p>1. Press the power button of the left and right legs at the same time for 2 seconds to turn on the glasses (if you press only one side of the glasses, the function of the other side of the glasses will not be activated). 2. Press the left (right) power button at any time for 2 seconds to wake up the AI voice assistant. 3. Quickly press the left mirror leg power button 2 times to play the previous song. 4. Quickly press the power button on the right leg 2 times to play the next song. 5. Please refer to the instruction manual for more functions.</p> <p><b>• Disclaimer</b> First and foremost, thank you for using our company's products! Please read this manual before using and use this product correctly. For the better service, changes due to the performance and functionality of the product will be revised without notice.</p> <p><b>• Product Introduction</b> The smart glasses feature Bluetooth chips that are compatible with mainstream brand smartphones, computers, tablets, and learning devices. With innovative product design, the functions include protecting eyes, protecting ears, phone call, enjoy music, speech typing, intelligent photography, intelligent navigation, speech control. While enjoying high-quality sound, you can also constantly access information about the surrounding environment, making activities safer, healthier, smarter, and more convenient.</p> <p><b>• Packing List</b> Audio glasses, Glasses charging cable, Instruction manual, Glasses cleaning cloth.</p>		 <p>① Right button(Switch on/Off/Voice assistant/Next song/Reject call/Answer call/Hang up/Pause/Play/Chinese and English switching/Navigation/Photo function) ② Left button(Switch on/Off/Voice assistant/Previous song/Reject call/Answer call/Hang up/Pause/Play/Chinese and English switching/Navigation/Photo function) ③ Magnetic charging port ④ Speakers ⑤ Microphones ⑥ LED Indicator</p>	<p>Auto shutdown for 3 minutes when no device is connected.</p> <p><b>Chinese and English switching</b> Press the left (right) power button arbitrarily 4 times to switch between English and Chinese.</p> <p><b>Switch machine / Pairings</b></p> <p><b>• Booting and Pairing</b> Turn on your cell phone and other bluetooth devices, press the power button of the left and right legs of the glasses at the same time for 2 seconds to turn on the glasses, the red and blue lights flash successfully; TWS power on and auto-pairing, the main (red and blue blinking) and the glass and the bluetooth device and the glasses pairing success after the left and right mirror leg LED lights go out.</p> <p>(Please refer to the diagram on the last page for the bluetooth connection of your cell phone.)</p> <p><b>• Product Parameters</b></p> <p>Frame Material: Stainless steel / Plate Lens specifications: Transparent gradient / Sunglasses color (a variety of options) Lens Material: PC Bluetooth Protocol: V5.3 Charging Time: 1.5H Use Time: 4-5H Standby Time: 120H(Bluetooth connection) Battery Capacity: 100mAh*2 Charging Voltage: DC5V/1A Channel Mode: Dual speakers, Stereo</p> <p><b>• Warn Prompt</b> When not in use for a long time, charge the battery at least once every 1 months.</p> <p><b>• Tips</b></p> <p>1. Please read the instructions carefully before using this product and keep this manual. 2. For the first time, please fully charge this glasses. 3. If the glasses does not charge for a long period of time (more than two weeks), charge it before use.</p>	<p>2 times to wake up the AI voice assistant, and then according to the prompts for voice operation, call *** (name inside the address book) or the other side of the cell phone number, you can call the phone.</p> <p><b>Answering a call:</b> Answer the call by pressing the left (right) power button 1 time at any time during incoming call.</p> <p>- Hanging up a call: Hang up the phone by pressing the left (right) power button 1 time at any time during a call.</p> <p>- Rejecting a call: Press the left (right) power button at will for 1.5 seconds to reject a call.</p> <p>- Redial: Press the left (right) power button 3 times at any time when the music is off to directly dial the last call record number.</p> <p><b>• Enjoy the music</b></p> <ul style="list-style-type: none"> <li>Precise song selection: Arbitrarily press the left (right) power button 2 times, hear the beep and say, play music, (e.g. Shanghai Tang), you can call and play the songs inside the cell phone.</li> <li>Randomly play songs: Arbitrarily press the left (right) power button 2 times, hear the tone and say, play music, you can call and randomly play the songs inside the cell phone.</li> <li>Play the previous song: Quickly press the left mirror leg power button 2 times.</li> <li>Play the next song: Quickly press the right mirror leg power button 2 times.</li> <li>Pause/Play: Press the left (right) power button 1 time arbitrarily.</li> </ul> <p><b>• Switch between playing music and making calls</b></p> <ul style="list-style-type: none"> <li>When you need to make a call while listening to music, arbitrarily press the left (right) power button 1 time to pause the music, and then quickly press the power button 2 times to make a call when you hear the tone.</li> </ul> <p><b>• Navigator</b></p> <ul style="list-style-type: none"> <li>Turn on the navigation: First pause the music, press the left (right) power button arbitrarily for 2 times, the voice wake-up function is on, and then the voice operation according to the prompts helps me navigate to *** page.</li> <li>Close the navigation: Press the left (right) power button 2 times at any time, hear the beep and then say, "Turn off the map".</li> </ul> <p><b>• Camera function</b></p> <ul style="list-style-type: none"> <li>When the phone is connected to Bluetooth and in standby mode, press the left (right) power button 2 times to wake up the AI voice assistant.</li> <li>• Make a telephone call</li> <li>• Make a call: First pause the music, arbitrarily press the left (right) power button</li> </ul>	<p><b>Warning</b></p> <p>1. Do not dismantle or repair this product for any reason, as this may result in fire, electronic breakdown or even complete damage to the product. 2. Do not place the device in an environment where the temperature is too low or too high (below 0°C or above 45°C). 3. Do not expose the product with corrosive liquids or immerse them in liquids. 4. Do not expose the glasses to the sun for a long time, otherwise it will be easily deformed, broken and broken. 5. Do not place the magnetic end of the charging cable close to metal objects to prevent the risk of short circuit caused by magnetically attracting metal objects.</p> <p><b>Safety information</b></p> <p>1. Before using this product, please read all safety information to ensure correct and safe use. 2. Using a power supply, charger or battery not approved by the original manufacturer may cause fire, explosion or other hazards. 3. Please use the accessories approved by the manufacturer and matched with this model of equipment. 4. Use accessories approved by this manufacturer and compatible with this model. Please use the device within the temperature range of 0°C~35°C, and the device and its accessories within the temperature range of -20°C~55°C. When the ambient temperature is too high or too low, it may cause equipment failure. 5. If the device uses a non-removable internal battery, do not replace the battery yourself to avoid damaging the battery or device. The battery can only be replaced by an authorized service center. 6. If charging is complete, disconnect the charger from the device and unplug the charger from the power outlet. Do not charge more than 12 hours. 7. Please keep the device dry. 8. If the equipment or any other parts do not work properly, please do not repair the product by yourself. 9. When connecting other devices, please refer to the connection method in the instruction manual and do not connect unsuitable devices at will.</p>	<p>Please follow the relevant laws and regulations and do not use headphones in the following environments.</p> <ul style="list-style-type: none"> <li>Such as gas stations, oil depots, chemical warehouses and other environments where flammable and explosive substances or chemicals are stored. Use of the device is strictly prohibited.</li> <li>Do not use this device in hospital operating rooms, emergency rooms, intensive care units, etc., in order to avoid interfering with the work of medical equipment, please keep away from pacemakers, hearing aids, cochlear implants and other medical equipment when using this device and the pacemaker.</li> <li>To use this device near personal medical equipment, consult your physician and device manufacturer.</li> <li>Follow all safety warnings and regulations regarding the use of this device while driving.</li> <li>During thunderstorms, do not use it outdoors in order to avoid lightning accidents.</li> <li>When charging, do not make a call while charging.</li> <li>Do not charge the product in a place with high humidity such as a bathroom, or it may cause electric shock, personal injury, fire and damage to the charger.</li> <li>Please comply with the relevant legal provisions that are expressly prohibited in any environment.</li> </ul> <p><b>Warranty certificate</b></p> <p>During the product warranty period, non-human-damaged performance failures can enjoy the following three-guarantee services:</p> <ul style="list-style-type: none"> <li>Within 7 days from the date of receipt, if the product has a performance failure that is not artificially damaged, the user can choose to return the payment or replace the product with the same model and specification.</li> <li>Within 15 days from the date of receipt, if the product has a performance failure that is not artificially damaged, the user can choose to replace the product with the same model and specification if the product has a performance failure that is not artificially damaged.</li> <li>Within one year from the date of receipt of the product, if the product has a performance failure that is not artificially damaged, the user can send it to the merchant for repair.</li> </ul>	<p>Dear users, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it in a safe place.</p> <table border="1" data-bbox="2141 2262 2435 2729"> <tr><td>User Information</td><td>User name</td><td></td></tr> <tr><td></td><td>Contact number</td><td></td></tr> <tr><td></td><td>Mail address</td><td></td></tr> <tr><td></td><td>E-mail address</td><td></td></tr> <tr><td></td><td>Postal code</td><td></td></tr> <tr><td>Products Information</td><td>Product name</td><td></td></tr> <tr><td></td><td>Product bar code</td><td></td></tr> <tr><td>Sellers Information</td><td>Name</td><td></td></tr> <tr><td></td><td>Address</td><td></td></tr> <tr><td></td><td>Contact number</td><td></td></tr> <tr><td></td><td>Postal code</td><td></td></tr> <tr><td></td><td>Sale date</td><td></td></tr> <tr><td></td><td>Invoice number</td><td></td></tr> <tr><td>Note</td><td></td><td></td></tr> </table> <p><b>Bluetooth connection schematic</b></p>  <p>① Go to settings ② Select the bluetooth option ③ Make sure the bluetooth switch is on, search for the device name: Y11, click the bluetooth name to enter the connection. ④ The bluetooth connection is successful.</p>	User Information	User name			Contact number			Mail address			E-mail address			Postal code		Products Information	Product name			Product bar code		Sellers Information	Name			Address			Contact number			Postal code			Sale date			Invoice number		Note		
User Information	User name																																																
	Contact number																																																
	Mail address																																																
	E-mail address																																																
	Postal code																																																
Products Information	Product name																																																
	Product bar code																																																
Sellers Information	Name																																																
	Address																																																
	Contact number																																																
	Postal code																																																
	Sale date																																																
	Invoice number																																																
Note																																																	

## FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

### RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.