


SWITCH JOY-CON PAD

User's Manual

Model: CH-JC03L

- ◆ make sure you read this guide before using the joy-con pad
- ◆ reading the guide will help you learn to use the controller properly

1. Product overview



2. Products Features

- ✧ This product for switch console
- ✧ Include the vibration and gyro-sensor functions
- ✧ Supports pressing the home button to wake up from sleep mode


3. How to pair joy-Con Control

Complete these steps

The Joy-Con can be paired to the Nintendo Switch console in the following ways:

✧ **Joint pairing**

Simply attach the Joy-Con controllers to the console.





✧ **Button pairing**

From the HOME Menu, select Controllers, then Change Grip and Order. While the following screen is displayed, press and hold down the SYNC Button for at least one second on the controller you wish to pair.

Once paired, the player LED(s) corresponding to the controller number will remain lit.



✧ Confirm how the Joy-Con will be held

How to Use the Joy-Con	Buttons to Press
<p>As a dual-controller grip</p>  <p>Joy-con controllers used as dual-controller grip</p>	<p>L Button (on left Joy-Con) + R Button (on right Joy-Con)</p> <p>ZL Button (on left Joy-Con) + ZR Button (on right Joy-Con)</p>
 <p>Joy-con controller used as a solo horizontal grip</p>	<p>SL Button+SR Button on each joy-con you wish to use horizontally</p>

4. Specification

Mass	Approx 120g
Battery	400mah
Charging current	<500mA
Charging time	About 1 hours
Charging method	DC 5V
Battery using time	About 20 hours
Motion sensor	Six axis gyroscope sensor

intendo switch are registered trademark or a trademark of Nintendo Inc, in the japan and/or other countries. This product is not designed, manufactured, approved, sponsored or endorsed by Nintendo. All trademarks belong to their respective owners.



MADE IN CHINA

FCC warning:

1. This device should be installed and operated with minimum distance 0cm between the radiator&your body.
2. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
4. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.