

Portable Projector



※ User Manual ※



Attention

Please read this manual carefully before use and keep it for future reference.


- 1.The projector is non dustproof or waterproof.
- 2.In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.
- 3.Please use the original power adapter. The projector should work under specified rated power supply.
- 4.When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
- 5.Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.
- 6.Regularly clean projector vents, or dust may cause cooling malfunction.
- 7.Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.
- 8.Please handle with care during daily use.
- 9.Please cut off the power if the projector is out of use for long time.
- 10.Non-professionals are forbidden to disassemble the projector for testing and maintenance.

Structure Description

This manual is for reference only. It is subject to change without prior notice. Hotack reserves the right of final interpretation.




Remote Component and Functions



Power ON/OFF

Power On
Long press Power button on projector for 3 seconds.
Power Off
When the projector is power-on, press and hold the power button on the projector or the remote control for 3s to power off.




Focus Adjustment

When projector is on, adjust sharpness by focus wheel on the back of projector.




Launcher Ui




Wi-Fi

Wifi Setting > To choose the network and type the password that you want to connect to.




BT Setting

BT setting, BT"ON", click Refresh Device and choose objective device to pair.




About this machine

Setting-Device Preferences>About.Local machine information can be viewed




Application

Hone page-ly Apps.All installed apps can be viewed.



OSD Language

Setting-Device Preferences-LanguageTo choose your language Langusg




Home Background

Hone page-Projector Setting-WallpapersChoose the Home Background you want.




Projector Mode

Home page-Projector Setting-Keystone Adjust-Projection ode > To select different mode according to your application scenario. Four modes are available < Front Table, Front Ceiling, Back Table, Back Ceiling >.




Factory Restore

Setting-Device Preferences-Reset > To reset system. he user data will be cleared.




Trapezoid

Home page-Projector Setting-Keystone Adjust-Trapezoid-You can adjust the four points of the pictureseparately to ensure that the picture achieves the




Media Player

Insert the U disk and click the USB icon on the homepage to read the local video & music & photo & Book.



HDMI Signal

Connect projector and external sourcing device by HDMI cable. Enter HDMI on the homepage, the signal from the sourcing device will be transmitted to projector and cast out.





Wireless Screen

(The Android Mobile/Pad must be on the same network as the projector device.)



- 1.Open the settings menu on your Android Mobile/Pad.
- 2.Access your display settings or screen mirroring.
- 3.Select the device name.

iOS



DLNA

(The phone/Pad must be on the same network as the projector device.)



- 1.Open the video playing app.
2. Click the TV icon and select the device name.

iOS Cast

iOS Cast AP

Connect with iOS Phone via screen mirroring:

- 1.Open WIFI and find the device name from your phone. Then input the password on your phone.
- 2.Click Airplay/Screen mirroring on your phone and connect the projector.



iOS Cast

(The phone/Pad must be on the same network as the projector device.)

- 1.Open your iPhone Control Centre and select Screen Mirroring.
- 2.Click the device name

【Safety instructions】

- Please pay attention to important information related to the operation and maintenance of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of projector.
- Please consult the qualified personnel for installation and repair services, and do not use damaged wires, accessories and other peripherals.
- Projector should be kept away from flammable, explosive, strong electromagnetic interference (large radar stations, power stations, substations), etc. Strong ambient light (avoid direct sunlight), etc.
- Do not cover projector vents.
- Please use the original power adapter.
- Keep adequate ventilation and make sure vents are not covered to avoid projector overheating.
- When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain.
- Do not bend or drag the power cord.
- Do not put power cord under projector or any heavy objects.
- Do not cover other soft materials on power cord.
- Do not heat the power cord.
- Avoid touching power adaptor with wet hands.

【Disclaim】

This manual is general instructions, The pictures and functions in this manual should subject to the actual product. Our company is devoting to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice. Please keep your device properly.We are not responsible for any loss caused by wrong operation of software/hardware or repairing or any other reasons. We are not responsible for any loss of any third party claims. This manual has been carefully checked by professional engineer, please understand for any inevitable omissions.



Attention:

Please do not look directly into the lens when projecting to prevent the strong light doing harm to your eyes. Kids should use the projector under the supervision of adults.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.