


名称: DK710S说明书
 料号: 42DK710S001
 材质: 120g哑粉纸
 尺寸: 130x80mm
 页数: 16页(8折页)
 印刷: 4c

封面



Product introduction / 产品介绍

FN combination function keys / FN组合功能键:
 FN+ESC=Ⓞ: FN+1=F1; FN+2=F2; FN+3=F3; ...
 See the following page for detailed functions / 功能键说明页

Indicator light / 指示灯:
 ① Caps lock / 大写锁定
 ② Low battery and charging / 低电量及充电
 ③ 2.4G
 BT: Bluetooth / 蓝牙

With Bluetooth +2.4G+ wired three connection modes, RGB backlight, Win/Mac system switching, mouse functions and so on / 具有蓝牙+2.4G+有线三种连接模式、RGB背光、Win / Mac 系统切换、鼠标功能等

FN Key / FN 键

Cable connection / 有线连接

① Data cable, charging cable / 数据线、充电线

② 2.4G Dual end receiver / 2.4G 双头接收器 USB/Type-C

③ Charging/data port / 充电/数据接口

④ Power switch / 电源开关

⑤ Mode switch / 模式切换

FN combination function keys / FN组合功能键

FN + [F1-F12] (with icons)

FN + [ESC] Long press 3S to restore factory default / 长按3秒恢复出厂默认

FN + [TAB] Switching between the Win and Mac systems / Win / Mac 系统切换

FN + [Q] Long press 3S to start Bluetooth device 1 pairing, short press to switch to Bluetooth device 1. / 长按3秒启动蓝牙设备1配对, 短按切换到蓝牙设备1.

FN + [W] Long press 3S to start Bluetooth device 2 pairing, short press to switch to Bluetooth device 2. / 长按3秒启动蓝牙设备2配对, 短按切换到蓝牙设备2.

FN + [E] Long press 3S to start Bluetooth device 3 pairing, short press to switch to Bluetooth device 3. / 长按3秒启动蓝牙设备3配对, 短按切换到蓝牙设备3.

FN + [ESC] Long press 3S to restore factory default / 长按3秒恢复出厂默认

FN + [TAB] Switching between the Win and Mac systems / Win / Mac 系统切换

FN + [Q] Long press 3S to start Bluetooth device 1 pairing, short press to switch to Bluetooth device 1. / 长按3秒启动蓝牙设备1配对, 短按切换到蓝牙设备1.

FN + [W] Long press 3S to start Bluetooth device 2 pairing, short press to switch to Bluetooth device 2. / 长按3秒启动蓝牙设备2配对, 短按切换到蓝牙设备2.

FN + [E] Long press 3S to start Bluetooth device 3 pairing, short press to switch to Bluetooth device 3. / 长按3秒启动蓝牙设备3配对, 短按切换到蓝牙设备3.

FN + [PGUP] Prev song 上一曲

FN + [PGDN] Next song 下一曲

FN + [A] Mouse left key 鼠标左键

FN + [ENTER] Play/Pause 播放/暂停

FN + [S] Move the cursor up 光标向上移动

FN + [X] Move the cursor down 光标向下移动

FN + [BACKSPACE] Backlight color switch 背光颜色切换

FN + [BACKSPACE] Backlight mode switch 背光模式切换

FN + [↑] Increase the backlight brightness 增加背光亮度

FN + [↓] Reduce the backlight brightness 降低背光亮度

FN + [D] Mouse right key 鼠标右键

FN + [F11] The scroll wheel scroll up 滚轮向上滚动

FN + [F12] The scroll wheel scroll down 滚轮向下滚动

Hexgears (DONGGUAN) Intelligent Technology Co., Ltd.
 黑峡谷 (东莞) 智能科技有限公司
 Building 9, Ruiying International Hi-Tech Innovation Park No.9 Daxue Rd, Songshan Lake, Dongguan, Guangdong, China.
 523808 广东省东莞市松山湖大道9号瑞鹰国际科技创新园9号楼
<http://hexgears.store> / www.hexgears.com / www.hyeku.com

封底

Bluetooth connection / 蓝牙连接

① Turn on Bluetooth / 打开蓝牙

② Select device / 选择设备

③ Add bluetooth / 添加蓝牙

Select one of them and Long press for 3S to enable the device matching code / 选择其一, 长按3秒启动设备对码

④ Device name / 设备名称: G-Hyeku KB1 / Hyeku BT 3.0 KB

⑤ OS:Hyeku KB2 / Hyeku BT 3.0 KB

⑥ OS:Hyeku KB3 / Hyeku BT 3.0 KB

Add bluetooth/添加蓝牙

Your equipment is ready / 您的设备已准备就绪

2.4G connection / 2.4G连接

① Turn on 2.4G / 打开2.4G

② Plug in receiver / 插入接收器

③ Plug in keyboard / 插入键盘

Cable connection / 有线连接

① Plug in USB cable / 插入USB线

② Plug in USB cable / 插入USB线

Low battery and charging instructions / 低电量及充电说明

In wireless mode, if the charging indicator "②" blinks when the battery is low, please connect the USB cable for charging. When the data cable is connected to the computer will be automatically charged, charging indicator "②" flashes, fully charged after the indicator off. / 在无线模式使用时, 如果电池电量不足时充电指示灯"②"闪烁, 请插入USB数据线进行充电, 当数据线连接电脑后将自动充电, 充电时指示灯"②"闪烁, 充满电后指示灯灭。

Instructions for the top cover / 上盖使用说明

Magnetic suction 磁吸式

Improve the portable 提升便携

Dustproof 防尘

Collision avoidance 防撞

Mobile phone holder 手机支架

Comfortable hand rest / 舒适的手托

Assembly method / 安装方法

The keyboard and the hand rest (top cover) are aligned and lay flat, press the hand rest and push it towards the keyboard until the buckle is locked with the keyboard slot. / 键盘和手托(上盖)对齐放平, 按住手托推向键盘, 直至卡扣与键盘卡槽相扣。

Place the keyboard flat, tilt the hand rest about 30° to align with the keyboard slot. / 键盘放平, 手托倾斜30°左右对准键盘卡槽, 压住手托再放平直至卡扣与键盘卡槽相扣。

Methods ① / 方法 ①

Methods ② / 方法 ②

Basic specifications / 基本参数

Keyboard type / 键盘类型: Three-mode mechanical keyboard / 三模机械键盘

Attended mode / 连接方式: Bluetooth, 2.4G, Wired / 蓝牙, 2.4G, 有线

Switch / 开关: Custom kaib box switch v2 / 客制甲BOX v2轴

Switch life / 开关寿命: 100 Million Cycles / 1亿次

Report Rate / 回报率: 1000Hz (Wired mode / 有线模式)

Backlight / 背光: RGB

Cable Material / 线材材质: USB Cable braided wire / USB 编绳线

Supporting / 适用系统: Windows all / Mac OS / Android

Function / 按键功能: FN combination function key / FN组合功能键

Key layout / 按键布局: 68 key / 68键

Keypac material / 键帽材质: PBT

Battery capacity / 电池容量: 2900mah

Input voltage current / 输入电压电流: 5V / 500mA

Transmission distance / 传输距离: 10m

Size / 产品尺寸: 313 x 104 x 50 mm

Weight / 产品重量: 1008g

Warning / 警告

If liquid enters the product, please disconnect it from the computer and remove the product immediately. Continuing to use may cause fire or electric shock. / 如果液体进入产品, 请立即断开与电脑连接并移开本产品。继续使用可能会引起火灾或触电, 请及时联系客服检查维修。应定期检查产品外壳有无损伤, 维护操作不属于产品合规性要求的范围。

Disassembly, replacement of parts, modification, and transformation of this product without express approval will cause the user to lose the right to operate this equipment and invalidate the product warranty. / 未经许可擅自对产品进行拆卸、更换零件、改装、改造将导致用户丧失操作本设备的权利和产品保修失效。

The name and content of the hazardous substance in the product / 产品中有害物质的名称及含量

Component name	Hazardous substances						This form has been prepared in accordance with the requirements of SJ/T 11364. O: Indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit specified in GB/T 26572. X: Indicates that the hazardous substance is contained in at least one homogeneous material of the component. The quantity exceeds the limit specified in GB/T 26572.
	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)	
keyboard body	X	O	O	O	O	O	本表格依据 SJ/T 11364 的规定编制。 O: 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。 X: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。
Metal case	O	O	O	O	O	O	
Plastic keys	O	O	O	O	O	O	

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.