说明书成品尺寸：73X93mm 80g书纸

Airmars-ABW07 真无线蓝牙耳机
使用说明书



1

包装清单

产品指示图



2

产品参数

蓝牙版本：V5.4
传输距离：≥10m
喇叭直径：Φ13mm
喇叭阻抗：32Ω±15%
灵敏度：108±3dB @1kHz
工作频率：2.402~2.480GHz
频率响应：20Hz~20KHz
使用时长：约4.5小时
充电时间(耳机)：约1.5小时
电池容量(耳机)：30mAh/3.7V
额定输入(耳机)：5V ⎓ 30mA
充电时间(充电盒)：约1.5小时
电池容量(充电盒)：280mAh/3.7V
额定输入(充电盒)：5V ⎓ 280mA

3

充电指南

1、若耳机放在充电盒内，给充电盒充电的同时也能为耳机充电。

额定输入：5V ⎓ 30mA（耳机）　　额定输入：5V ⎓ 280mA（充电盒）

温馨提示

1、除说明书有特殊标示的操作方式以外，请勿尝试拆卸或更换产品内的任何零件。
2、请勿将产品放入水或其他任何液体中，此产品非防水设计。
3、如果有任何液体不小心进入产品内时，请立即断开连接并移开此产品。
4、为避免触电，请在安装或卸载产品时，确保手上没有沾水。
5、请勿将此产品放置于热源附近或直接暴露在火源附近。
6、请勿将本产品放置在有强大电磁力的环境中，否则会导致产品故障。

4

耳机灯光

模式	描述	语音提示
开机	耳机蓝色指示灯亮一秒	"Power on"
关机	——	"Power off"
配对	耳机蓝色指示灯闪烁	"Pairing"
连接	耳机指示灯熄灭	"Connected"
断开	耳机蓝色指示灯闪烁	"Disconnected"
耳机低电	蓝灯每5秒闪烁一次	"Battery Low"
充电仓给耳机充电	RGB指示灯长亮12秒	——
充电仓低电	红色指示灯快闪	——
充电仓充电	红色指示灯慢闪	——
充电仓充满	红色指示灯长亮	——

恢复出厂设置

耳机开机后未与蓝牙设备连接状态下，连续单击左/右耳机功能键5次清除配对信息后关机

5

产品操作说明

①开机:
方法1. 从充电仓取出耳机，蓝灯长亮1秒耳机开机。(语音提示音："Power on")

②关机:
方法1.与蓝牙设备断开连接3分钟后，自动关机。方法2.耳机放入充电仓后，自动关机(语音提示音："power off")

③蓝牙配对:
步骤一：耳机开机，左右耳机自动互连后进入配对状态。(语音提示音："pairing")
步骤二：打开智能设备的蓝牙列表，搜索"Airmars-ABW07"并连接。
(语音提示音："connected")

6

功能键操作

■ 常规模式

■ 音乐播放模式

■ 通话模式

■ 游戏/音乐模式切换

7

产品中有害物质名称及含量

部件名称	有害物质					
	铅 (Pb)	汞(Hg)	镉(Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T11364的规定编制
○:表示该有害物质在该部件所有均质材料中的含量均在GB/T26572规定限量要求以下。
X:表示该有害物质至少在该部件的某一均质材料中的含量超出GB/26572规定的限量要求。
表单标记"X"的部件，皆因全球技术发展水平限制而无法实现有害物质的替代。

本表格依据SJ/T11364的规定编制
印刷电路板组件*:包括印刷电路板及其零部件,电子元器件等。
根据产品型号不同,您所购买的产品可能不会含有以上所有部件

按不含有6种有害有害物质或含有低小于限量值。字母 "e" 代表英文字母电子(electronic),电子(electrical)和环境(environment)的首字母；环境的最低要头表示可回收利用。

8

保修声明

免责声明
本使用手册没有任何形式的担保，立场表达其他暗示。本使用手册所提到的产品，规格及结果仅作参考，内容仍会随时更新予调整，恕不另行通知。

保修声明:
因本文件所提的产品提如下保证，如产品在您购买日起十二（12）个月"保修期"内，在正常使用情况下因质量瑕疵发生损坏，损修理费，负责修理，段厂家确认无法修理的，免费更换，修理或更换后的产品，在剩余保修期（量短不少于30天）内维续享有保修。购买日以销售发票日期为准，如无法确定购买日，则保修期自产品生产日期起每个月1(1)个月计算。
如申请保修，请先联系产品服务热线，并按照们指示的方式执行。申请保修时，您需要提供发票、完整和清晰填写的有效销售发票，以上仅属不适用于下列情况:
1.超过三包有效期的;
2.涂改保修卡、产品编码与产品本体不符;
3.因误用、滥用或不当的维修、使用，或使用或保管而导致的故障或损坏;
4.因不可抗力（如地震、战争、大灾等）或意外导致的故障或损坏;
5.拉链、拼扣或者刀口无故损坏。
6.因承载过重造成的脱线或撕裂。
7.任何因安装软件造成的损坏。
8.有拥抓或水渍进来的产品。
9.因擅自拆改导致的损坏。
10.产品正常使用过程中发生的老化、脱色、磨损、破裂和其他损耗。
11.配产品原有标识标签更改或损毁，本保证将失效。
产品及随附物料的齐备和外观完好不属于保证范围，但应在接收产品时当场检验并对任何不符提出异议。

以上保证是我们就产品做出的全部保证，且仅在中国大陆地区销售适用。本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权利。

服务电话：400 155 2521

9

Airmars-ABW07
FCC ID: 2BL52-ABW07
True wireless earphones
instruction manual



Packing List

Product diagram



10

Product Parameters

BT version：V5.4
Transmission distance：≥10m
Horn diameter：Φ13mm
Horn impedance：32 Ω ± 15%
Sensitivity：108± 3dB@1kHz
Operating frequency：2.402~2.480GHz
Frequency response：20Hz-20KHz
Playing time：About 4.5 hours
Charging time(earphone)：About 1.5 hours
Battery capacity(earphone)：30mAh/3.7V
Rated input(earphone)：5V ⎓ 30mA
Charging time(Charging Case)：About 1.5 hours
Battery capacity(Charging Case)：280mAh/3.7V
Rated input(Charging Case)：5V ⎓ 280mA

Restore factory settings

If the earphone is not connected to the Bt device after the earphone is turned on, click the left/right earphone function key five times to clear the pairing information and shut it down

11

Charging guide

1, If the earphones are placed in the charging case, charging the charging case can also charge the earphones.

Rated Input：5V ⎓ 30mA (earphone)　　Rated Input：5V ⎓ 280mA (Charging Case)

Tips

1、Except for the operation methods specifically marked in the manual,please do not try to disassemble or replace any parts in the earbuds.
2、Don't put the earbuds in the water or any others liquid, The earbuds are not waterproof.
3、If any liquid enters the product by accidentally,please disconnect and remove the connection immediately.
4、Please make sure that there is no water on your hands when Installing or uninstalling the product to avoid electroshock.
5、Do not put the product near by the heat source or expose it to the fire source directly.
6、Do not put the product in the environment with strong electromagnetic force, otherwise it will cause product malfunction.

12

Earphone lighting

Mode	Describe	Sound prompt
Power On	Earphone blue indicator is on for one second	"Power on"
Power Off	——	"Power off"
Pairing	The earphone blue indicator blinks	"Pairing"
Connected	Earphone indicator off	"Connected"
Disconnected	The earphone blue indicator blinks	"Disconnected"
Low Battery	The blue light flashes every five seconds	"Battery Low"
Earphone placed in charging case	The RGB indicator is on for 12 seconds	——
Charging case low power	Red light flashes quickly	——
Charging case charged	The red indicator light flashes slowly	——
Charging case fully charged	Red indicator lights up	——

13

Product Instructions

① Boot:
Method 1. Remove the earphone from the charging compartment, and keep the blue light on for 1 second to turn on the earphone.
(Voice prompt tone: "Power on")

② Shutdown:
Method 1. Automatically shut down after disconnecting from BT device for 3 minutes
Method 2. After the earphone is put into the charging bin, it automatically shuts down.(Voice prompt tone: "Power off")

③ BT pairing:
Step 1: The earphone is turned on, and the left and right earphone are automatically connected to enter the pairing state.
(Voice prompt tone: "pairing")
Step 2: Open the BT list of smart devices, search for "Airmars-ABW07" and connect. (Voice prompt tone: "connected")

14

Function key operation

■ General mode

■ Music playback mode

■ Call mode

■ Game/ Music mode switch

15

Names And Contents Of Hazardous Substances In Products

Port Nones	Harmful Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364
○Indicates that the content of the hazardous substance in all homogeneous materials of the part is in below the limit required by GB/T 26572.
XIndicates that the hazardous substance at least in a certain homogeneous material of the part exceeds The limit requirements specified in GB/T 26572.
The parts marked with "X" on the form are all harmful due to the limitations of global technological development. Substitution of substances.

Printed circuit board components:
Including printed circuit boards and their parts,electronic components, etc and depending on the product model,the earbuds you purchased may not contain all the above components

Refers to not containing 6 toxic and harmful substances or containing but less than the limit value, with the letter "e" representing the English letter "electronic"; The first letters of electronic and environmental;
The curved arrows surrounding indicate recyclability.

16

Warranty Statement

Disclaimer
This user manual does not have any form of guarantee,position expression or other implication.The mentioned products,specifications and information are for reference only,and the content will also be updated on the web at any time without additional separate notice

Warranty statement:
The product attached to this document is guaranteed as follows:If the product is twelve (12) months from the date of purchase("Warranty Period"),under normal conditions of use due to quality defects damaged,can be repaired,free repair,free replacement if the manufacturer confirms that it cannot be repaired; during the remaining warranty period (the shortest is not less than 30 days) The remaining warranty period (the shortest not less than 30 days)Purchased by sale the ticket date shall prevail;if the purchase date cannot be determined,the warranty period shall be 15 (15) months.
If you apply for a warranty,please call the product service hotline first and execute it in the manner instructed by us.When applying for warranty,you need to provide an accurate,complete and clearly filled-out valid sales invoice.

The above guarantee does not apply to the following situations:
1.Exceeding the validity period of the three packs;
2.Altering the warranty card and product code does not match the product body;
3.Causes caused by misuse,abuse or improper transportation,use,maintenance or storage by the customer;
4.Failure or damage caused by force majeure (such as earthquake,war,disaster,etc) or accident bag;
5.The zipper and towel buckle are damaged due to excessive force;
6.Disconnection or tearing caused by excessive load;
7.Any damage caused by sharing software;
8.Products with signs of burning of moisture;
9.Products damaged by unauthorized disassembly;
10.Aging,discoloration,abrasion,rupture and other losses that occur during the normal use of the product.
11.If the original identification label of the product is changed or damaged,this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee.You should check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products,and are only applicable in mainland China.Nothing in this document affects consumer rights that cannot be excluded or restricted under the law.profit.

E-mail：wanlin_tech@wanlintech.com

16