

The statements should be displayed in the user manual:
changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

MUSIC BOXING TARGET

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Operation instruction



Please read the instructions carefully before use

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



1. Installation Instructions

Cut the Velcro to size and peel off the backing. Stick one side to the punching target and the other to the wall at the desired height. Align and press firmly to attach.

Tip:
For painted walls, press firmly to ensure a strong bond. Leaving it overnight improves adhesion. Note: Removing the Velcro may cause slight paint peeling.

2. Operating Instructions

Key	Short Press	Long Press	
Button Instructions			
(SPEED) ⏪	Adjust Speed/Level	Lower Volume	
(ON/OFF) ⏻	Switch Music/Bluetooth Mode	On (Music Mode, Vol3) / Off	
(MODE) ⏩	Cycle Modes (C1:Box / C2:Rhythm / C3:VS)	Increase Volume	
Game Mode Guide			
Mode	玩法说明	Game Level	Special Rules
Box	Hit when lights flash	Music: L1-L5 Bluetooth: L1-L6	Bluetooth: Lights sync with music
Rhythm	Hit when light reaches 5th/6th LED	Music: 6 Stages Bluetooth: 1 Stages	Pass with $\geq 70\%$ score
VS	2P VS Mode: First to 10 points wins	Tempo ramps up	Music Mode Only
Auto Shutdown: Enters sleep mode after 20 minutes of inactivity Low Battery Alert: Sounds warning and powers off when voltage <3.2V Volume Control: 5 adjustable levels (default: Level 3 at startup) Bluetooth name: quanji3			

3. Charging Instructions

Charge via USB (Do not use during charging).

Precautions

1. Rest for 30 minutes after meals before use.
2. Avoid use if feeling unwell.
3. Do not wash – clean only with a dry cloth.
4. Recharge when battery is low to prevent damage.
5. Stop use immediately if you feel unwell during operation.
6. Wear boxing gloves for optimal use.
7. Do not disassemble.

Item NO: CD8820

Product Name: Music powered boxing target