

43 mm

43 mm

43 mm

主动式电容笔 Active Stylus

产品概述

Product Overview



使用说明

Operation Instruction

1. 开机

按压开关键3秒，指示灯亮蓝灯开始使用

1. Power on

Press the power button for 3 seconds, used when blue LED indicator lights up.

2. 关机

手动关机模式：按压开关键3秒，立即关机

自动关机模式：静放五分钟，自动关机

2. Power off

Manual mode: Press the power button for 3 seconds to turn off immediately

Automatic mode: Leave the stylus without using for 5 minutes.



3. 充电

连接USB Type-C充电线充电

3. Charging

Connect the USB Type-C cable to charge the stylus



4. 蓝牙连接

打开设备蓝牙，搜索配对名为OCM Pen OPI21的电容笔，点连接

4. Bluetooth Connection

Click Bluetooth on the device side, search for the stylus named

5. 切换功能

单击笔尖按钮在“橡皮擦”和“圆珠笔”或“钢笔”或“铅笔”之间重复切换

5. Accessibility features


单击笔尖按钮在蓝牙快捷命令“Erase”和“Brush”或“Pen / Pencil”之间重复切换

6. 蓝牙快捷命令功能

单击笔尖按钮在蓝牙快捷命令“Erase”和“Brush”或“Pen / Pencil”之间重复切换

7. 磁性吸附

7. Magnetic Adsorption



6. 笔尖更换

抓住笔尖并轻轻转动，将笔尖取下后，用同样的方式装入新的笔尖

6. Tip Replacement

Grab the tip of the pen and gently turn out the replace tip.



7. 磁性吸附

7. Magnetic Adsorption



iPad Pro 11"/12.9"

产品参数

产品名称	主动式蓝牙电容笔
型号	OPI21A
输入	5V=1A
电池容量	130mAh
额定电压	3.7V
工作温度	0℃~35℃
充电时间	<50分钟
工作时间	>=8小时
适用型号	iPad Air 10.5寸（第三代） iPad mini 7.9寸（第五代） iPad 9.7寸（第6代） iPad 10.2寸（第7代） iPad Pro 11"/12.9寸（第3代） 备注：兼容2018款或2019及以上iPad版本 &系统更新到12.2版本以上或最新才可以 使用
包装清单	电容笔x1 充电线x1 替换笔尖x1 说明书x1

以上参数均来源于公司实验室，实际参数会因产品或者其它因素而有差异；图片仅供参考，请以实物为准

指示灯说明

使用状态	指示灯显示
工作中	蓝色灯
电量<10%	红色+蓝色混合色灯
充电中	红色灯
充满电	绿色灯

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Product Parameter

Product Name	Active Bluetooth Stylus
Model Number	OPI21A
Input	5V=1A
Battery Capacity	130mAh
Nominal Voltage	3.7V
Working Temperature	0℃~35℃
Charging Time	<50 Minutes
Working Time	>=8Hours
Compatible With	iPad Air 10.5 inch (Gen 3) iPad mini 7.9 inch (Gen 5) iPad 9.7 inch (Gen 6) iPad 10.2 inch (Gen 7) iPad Pro 11"/12.9 inch (Gen 3) Notes: Compatible with iPad Launched in 2018 & 2019 or latest, together with iOS updated to higher than Rev 12.2
Packing List	Stylus x 1pcs Charging Cable x1pcs Replacement Tip x1pcs User Manual x1pcs

All the above data and information comes from lab. They might vary with environment or other factors. Photos only for reference.

About Indicator

Working State	LED indicator
Power on	Blue light
Battery Capacity < 10%	Mixed Red+Blue light
Charging	Red light
Charging Completion	Green Light

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general R F exposure requirement.

The device can be used in portable exposure condition, compliance with exposure requirements.

185 mm

注意事项

- 切勿在屏幕以外的其他表面使用笔, 以免笔尖过度磨损导致损坏屏幕。
- 使用时请保持笔尖干净, 因为灰尘或微粒可能会影响触控效果。
- 使用过程中笔尖会逐渐磨损, 请及时更换替换笔尖以免损坏屏幕。
- 请将笔放置在儿童或宠物接触不到的地方, 避免儿童或宠物吞食或导致其他伤害。
- 笔内包含敏感电子元器件 (含电池), 使用时请小心, 若不慎跌落、焚烧、弯曲、破坏性挤压或接触到液体, 可能会对制造或损坏或导致人身伤害。切勿使用已被损坏的笔。
- 请勿使用任何溶剂或液体清洁产品, 以免清洁时溶剂或液体流入产品内部导致产品受潮或损坏内部件。
- 部分屏幕贴膜可能会影响书写体验。

电池警告

- 请勿尝试自行更换电池, 因您可能会损坏电池, 或者由于不正当的操作导致过热或造成人身伤害。
- 充电时, 请勿用身体任何部位压住笔, 或者将笔放在枕头、被子下, 避免皮肤与笔长时间接触, 以免由于笔过热引起身体不适或受伤。
- 禁止拆解、撞击、挤压或投入火中。若出现严重肿胀, 请勿继续使用。请勿置于高温环境中。
- 如果电池更换不当会有爆炸风险, 只能用同样类型或等效类型的电池更换。
- 电池 (电池包或组合电池) 不得暴露在诸如日照、火烤或类似过热环境中。
- 本产品内含锂电池, 请与家庭垃圾分类处理。

产品中有毒物质的名称及含量

为满足中国电子电气产品有害物质限制相关的法律法规和其他要求, 对本产品中有毒物质, 按部件分类, 声明如下。

部件名称	有毒物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBBs)	多溴二苯醚 (PBDEs)
金属件	○	○	○	○	○	○
其他	○	○	○	○	○	○

本表格依据 **GB/T 11364** 的规定编制, 某些型号的产品可能不包含表中的部分部件。

0 表示该有害物质在该部件所有均质材料中的含量均在 **GB/T 26572** 规定的限量要求以下。

X 表示该有害物质至少在该部件的某一均质材料中的含量超出 **GB/T 26572** 规定的限量要求。标记“X”的部件, 皆因全球技术发展水平限制而无法实现有害物质的替代。

在中华人民共和国境内销售的电子信息产品必须标识此标志。圆圈内的数字表示正常使用状态下产品的环保使用期限。

Attention

- Never use pen for writing on the other surface than tablet touch screen, to protect the tip, which might potentially damage touch screen
- Keep stylus tip clean when you use it, because dust can affect the touch effect.
- The pen tip will wear away in the process of use. Please change the pen tip in time to avoid damaging the screen.
- Place the pen in a place where children or pets could not reach it.
- The pen contains sensitive electronic elements (including batteries). Please be careful when using them. If you accidentally drop, overheat, be squeezed or touched with liquid, you may cause damage to the body. Do not use damaged pen.
- Do not let the solvent or liquid flow into the product, which might cause product damage.
- Touch screen protective film may affect the writing experience.

Battery warning

- Do not try to replace the battery by yourself, because you may damage the battery due to improper operation resulting in overheating or causing injury to the collar.
- When charging, do not press stylus with any part of the body, or place the pen under the pillow / quilt, which may cause injury or product damage due to overheating of the pen.
- It is forbidden to fold, squeeze or put the pen into the fire. Please do not put the pen in high temperature.
- If the battery is not properly replaced, it will risk the explosion. It can only be replaced by the same type or equivalent type.
- Batteries (battery packs or combination batteries) should not be exposed to sunlight or fire.
- This product contains battery. Please separate it from the garbage.

Declaration of hazardous substances in products

In order to meet regulation & law requirements in China for hazardous substances control, we declare the substances as shown in the table:

Parts	Hazardous Substances					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBBs)	多溴二苯醚 (PBDEs)
Metal	○	○	○	○	○	○
Others	○	○	○	○	○	○

This table is filled according to the regulations of SJ/T 11364 in China. Some model may not contain the parts in the table.

0 indicates that the substance meets the requirement of GB/T 26572.

X means the substance exceeds the requirement of GB/T 26572, because this hazardous substances can't be replaced due to limited global technology.

All the electronic products sold in China must identify the sign. The number in the circle indicates the duration of the product is environmentally friendly for usage.

执行标准:

Executive standard
GB 4943.1-2011 ; GB 31241-2014



保修卡 Warranty card

客户姓名:
Customer name _____

联系电话:
Contact telephone _____

产品名称:
Product name _____

购买日期:
purchase date _____

地址:
Address _____

备注:
Remarks _____

深圳市智诚立创技术有限公司
Shenzhen OCM Technology Ltd., Co

制造商: 深圳市智诚立创技术有限公司
Manufacturer: Shenzhen OCM Technology Ltd., Co

地址: 深圳市宝安区宝华路卓越时代广场A座1703
Address: Baoan, Shenzhen, China

Web: <http://www.ocm-tech.com/>

Email: service@ocm-tech.com

深圳市智诚立创技术有限公司版权所有并保留一切权利
All Copyright owned by Shenzhen OCM Technology Co., Ltd.

中国制造
Made in China