

- 刀模线
- 折线
- 出血线

型号: JLOK02
尺寸: 180x95mm

⚠ WARNINGS

- Only use the charging cable provided and a good quality USB power source.
- Charge the product in a well-ventilated area and avoid charging under pillows, blankets, or on flammable surfaces. Do not leave unattended while charging.
- To avoid damaging the headphones, please keep it away from direct streams of splashes and do not submerge into water.
- Do not expose this product to sources of heat. Do not expose to temperatures above 40°C, such as in a car on a hot day, or in direct sunlight.
- Prevent objects and debris from entering the device ports.
- To protect your hearing, keep the volume at a safe level and take regular breaks.
- Refer all servicing to qualified service personnel, which is required if this product is damaged in any way / is exposed to liquid, or does not operate normally.
- Children under age of 5 year must be supervised when using or handling this product.
- The battery is unreplaceable. If the battery is expanded, stop using and keep it away from children.

SPECIFICATIONS

Wireless version:	V5.3
Connection distance:	8-10 meters (barrier-free)
Output power:	8W
Built-in Battery:	Speaker - 1200mAh, Microphone - 300mAh
Input USB-C:	DC 5V 1A Max
Play time:	About 3hrs at 50% volume.
Charge time:	About 2hrs
Function:	Wireless mode/TF mode/AUX mode
Product Net:	517g
Frequency:	2.402-2.48 GHz
Max EIRP:	
Working Temperature:	0-40°C

JellieMons
JELLIE O-K
Karaoke Speaker
JLOK02

SING ALONG

QUICK START GUIDE

WHAT'S INCLUDED:

1. CHARGE YOUR JELLIE O-K SPEAKER

Before first use, fully charge the speaker and microphone using the supplied cable. While charging, the LED indicator on both the speaker and microphone will turn red. Once fully charged, the LED indicator will switch off.

前面

2. CONNECT YOUR JELLIE O-K SPEAKER

Once the speaker is fully charged, press the power ON button for 2 seconds. You will hear a sound saying, "It's JellieMons" followed by "This is wireless mode," and the RGB light will turn on to indicate the speaker is powered on and ready to pair.

For the microphone, press the power ON button for 2 seconds once it's fully charged. No sound will play, but the white light indicator will flash show it's on. After pairing with the speaker, the indicator will turn solid white to confirm the connection.

To connect, turn on Wireless in your phone settings and select JELLIE-O-K from the list of available devices. Once paired, you will hear a sound, "You are connected" to confirm a successful connection.

3. USE YOUR JELLIE O-K SPEAKER

Speaker

Turn ON/OFF	Press for 2 seconds
Play/pause song	Press
Disconnect phone	Press twice
Previous track	Press for 2 seconds
Next track	Press for 2 seconds
Volume down	Press
Volume up	Press
Light ON/OFF	Press for 2 seconds
Light mode	Press
Change Wireless/TF/Aux-in mode	Press twice

Tip: The RGB light will keep the same lighting effect from the last time it was turned off. This is the memory light effect mode.

Microphone

Turn ON/OFF	Press for 2 seconds
Mute/Unmute	Press
Volume down	Press
Volume up	Press
Echo volume down	Press for 2 seconds
Echo volume up	Press for 2 seconds
Voice/Tone Changer	Press for 2 seconds
Back to original voice	Press for 3 seconds after emit a short and long sound

Tip: If only speaker is used, please set Microphone to mute to reduce static noise and get a louder volume.

4. PRODUCT SUPPORT

For the latest assistance, simply scan this QR code to access product support.

CHECK OUT OUR WHOLE RANGE AT
JELLIEMONS.COM

JellieMons

背面