

材质:80g双胶纸 **黑白印刷**

展开尺寸为:450x270mm

折叠尺寸为:90x90mm

绿色实线为切线, 绿色虚线为折痕不打印

两面打印方向一致

折叠方式:先向**右风琴横折**,再**竖折**



## Quick instructions

1. Turn on the device  
Press and hold the button for 5 seconds, the device will beep and turn on.

2. Pair the device  
· Open the Find My app.  
· Hold the device close to your iPhone, tap the Items tab, tap + and then Add Other Item.  
· Tap Connect.  
· Type a name for your device, select an emoji.  
· Tap Agree to acknowledge that this item will be linked to your Apple ID.  
· Tap Finish.

3. Enable Lost Mode  
· Open the Find My app, tap the Items tab, then tap your item.  
· Under Lost Mode, tap Enable.  
· Read the instructions, tap Continue and enter a phone number or email address.  
· Confirm the information, customize the lost message, and tap Activate to complete the setup.

4. Remove the device  
· Open the Find My app, tap the Items tab, then tap your item.  
· Tap Remove Item and then tap Remove to complete the operation.  
Note: After removing the device in the app, the device will beep and the light will flash six times, it will not shut down and will be in the pairing mode. If there is no re-pairing within 10 minutes, the device will leave the pairing state, and the device and app cannot be paired at this time. If you need to pair the device, you need to click the device button once, the device will ring and the light will flash once. At this point, the device enters the pairing state and can be re-paired with the app.

## 使用说明

1、设备开机  
长按设备按键5秒，设备响开机。  
2、绑定设备  
· 打开苹果自带的“查找”app。  
· 将设备靠近您的 iPhone，轻点“物品”标签，选择“添加新物品”，点击“其他支持的物品”。  
· 带有Blackshark Tag字样的设备，轻点“连接”。  
· 填写“自定义称”以命名您的设备并选取一个表情符号。  
· 同意将设备注册到您的 Apple ID。  
· 轻点“完成”绑定成功。

3、启用“丢失模式”  
· 打开苹果自带的“查找”app，点击屏幕底部的“物品”，然后点击物品的名称。  
· 在“丢失模式”下方，点击“启用”。  
· 按照屏幕指示操作，点击“继续”输入联系电话或者邮箱。  
· 点击“下一步”核对信息后，请再次点击“启用”完成设置。

4、删除设备  
· 打开苹果自带的“查找”app，点击屏幕底部的“物品”，然后点击物品的名称。  
· 在列表的最下方找到“移除物品”，轻点“移除”完成操作。  
说明：删除设备后，设备会发出提示音、指示灯会闪烁6次，设备不会关机，处于配对模式。如果10分钟之内，没有重新配对，设备就会离开配对状态，此时设备与app无法配对，如果需要配对设备，需要点击设备按键一次，设备响，灯闪一次。此时设备进入配对状态，可以跟app重新配对。

## Main Functions

1. Locate your item  
If your missing item isn’t nearby, the Find My app can still help you track it down using the Find My network — hundreds of millions of iPhone, iPad, and Mac devices around the world. Nearby devices securely send the location of your missing device to iCloud, then you can see where it is in the Find My app. It’s all anonymous and encrypted to protect everyone’s privacy.  
2. Play Sound  
· Open the Find My app, tap the Items tab, then tap your item.  
· Click Play Sound, and the device will beep, so you can find the item easily.

### Instructions for device button

1. Power on  
Long press the button for five seconds, the device will beep, the light will flash three times, and the device will be turned on.  
2. Device status confirmation  
Double-click the device button, the device will beep, and the light will flash three times, indicating that the device is working. If the device does not ring, the device is off. Long press the button for five seconds to turn it on.  
3. The device enters the pairing state again  
After removing the device in the app, the device will beep and the light will flash six times, it will not shut down and will be in the pairing mode. If there is no re-pairing within 10 minutes, the device will leave the pairing state. If you want to pair a device at this time, you need to click the device button once, the device will beep, and the light will flash once. At this time, the device enters the pairing state and can be paired with the app again.

## 产品主要功能

1、“查找”网络定位  
当设备与手机超出蓝牙距离，在查找app中链接不上设备，可以选择：丢失模式，选择：启用。输入您的联系电话等。如果设备与您的手机断开超过一段时间，同时设备附近有别的苹果手机，您的查找app中即可收到通知以及最新的位置。  
2、播放声音  
手机与设备在蓝牙范围内（一般是20米左右），在查找app中，点击，播放声音，设备会发出音乐，帮助您快速找到附近的物品。

## 设备按键使用说明

1、设备开机  
长按按键五秒，设备响，灯闪三次，设备开机。  
2、设备状态确认  
双击设备按键两下，设备响，灯闪三次，说明设备在工作。如果设备不响，说明设备处于关机状态。长按按键五秒，开机。  
3、设备重新进入配对状态  
删除设备后，设备会发出提示音、指示灯会闪烁6次，设备不会关机，处于配对模式。如果10分钟，没有重新配对，设备就会离开配对状态，此时设备与app无法配对。如果需要配对设备，需要点击设备按键一次，设备响，灯闪一次。此时设备进入配对状态，可以跟app重新配对。

4. Factory Reset  
First, remove the item from Find My app then, after the device is powered on, double-click the device button. The device will beep. Long press the device button for eight seconds until the device beeps and the light flashes three times. Release the button to complete factory reset. The device can now be paired.  
5. Power off  
When the device is on, press the device button 5 times in 2 seconds. The device will beep, the light will flash three times, the device will be powered off.

### FAQ:

1. When can the device be located?  
When an item is separated from its owner for a period of time, it can be found by other Apple devices that are part of the Find My network, and the owner can start to get the location of the device.  
2. How to confirm whether the device has been turned on?  
Double-click the device button, the device will beep, and the light will flash three times, indicating that the device is working. If the device does not ring, the device is off. Long press the button for five seconds to turn it on.  
3.How is the device designed to discourage unwanted tracking?  
If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways:  
1. If you have an iPhone, iPad, or iPod touch, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later.  
2. If you don't have an iOS device or a smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved. These features were created specially to discourage people from trying to track you without your knowledge.

4.How is my privacy protected?  
Only you can see where your item is. Your location data and history are never stored on the item itself. Devices that relay the location of your item also stay anonymous, and that location data is encrypted every step of the way. So not even Apple or Nutale knows the location of your device or the identity of the device that helps find it.

5. What is the Find My network? And how does it work?  
The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, iPod touch, Mac, or the Find Items app on Apple Watch. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or Nutale , can view its location.



European Union-Disposal Information  
The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities.

The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

## Regulatory Safety Information



**WARNING:** KEEP BATTERIES OUT OF REACH OF CHILDREN  
Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the oesophagus.

If you suspect your child has swallowed or inserted a button battery immediately call the 24-hour Poison Information Centre for fast expert advice.

**KEEP BATTERIES OUT OF REACH OF CHILDREN**  
•Keep in original package until ready to use  
•Call a local poison control center for treatment information.  
Australia: 13 11 26  
Canada: 1-800-268-9011 (Ontario), 1-800-567-4911 (BC), 1-800-463-5060 (Quebec) US: 800-458-8666 (verify suitable, emergency call numbers for your country).  
•Do not use if the compartment is not secure.  
•Dispose of used button batteries promptly and safely. Flat batteries can still be dangerous.  
•Risk of fire and burns.  
•Do not recharge, disassemble, heat (-20°C +70°C)or incinerate.  
Rated voltage 3V  
Fixed Voltage 3V  
Rated current -175 mAh  
Fixed Current -175 mAh  
• Immediately dispose of used batteries and keep away from children. Do NOT dispose of batteries in household trash.  
• Even used batteries may cause severe injury or death.  
• Call a local poison control center for treatment information.

Article 12  
Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the certified lower power frequency electric machinery.  
Article 14  
The application of low power frequency electric machines shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists. The foregoing legal communication refers to the wireless telecommunication operated according to the telecommunications laws and regulations.

- Increase the separation between the equipment and receiver.  
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help.  
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

The low power frequency electric machinery should be able to tolerate the interference of the electric wave radiation electric machineries and equipment for legal communications or industrial and scientific applications.

## FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Reorient or relocate the receiving antenna.  
- Increase the separation between the equipment and receiver.  
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

4、恢复出厂设置  
首先，在Find My app中，移除设备，然后在设备开机后，双击设备按键，设备响，马上按住设备按键约八秒，直到设备发出提示音，指示灯闪烁三下，松开按钮，恢复出厂设置完成。设备就可以最新的账户配对。  
5、关机  
设备在开机状态下，2秒内连续按压设备按键5次，设备发出提示音、指示灯闪烁三次，设备进入关机状态。

## 常见问题

1、设备什么时候可以被别的苹果手机定位？  
当设备与主人的苹果手机断开一段时间后，设备可以开始被别的苹果手机定位，主人就可以开始获得设备的位置。  
2、如何确认设备是否已开机？  
请双击设备按键两下，设备响，灯闪三次，说明设备在工作。如果设备不响，说明设备处于关机状态。请长按按键五秒，开机。  
3、如何防止设备被用于恶意跟踪？  
当别人的设备混入您的随身物品时，并跟踪超过一段时间，您会通过以下两种方式被提醒：  
1. 如果您有iPhone, iPad, 或者iPod touch等苹果设备，您会在苹果设备上获得提醒；此功能在iOS or iPadOS 14.5 及以后版本的苹果设备上有。  
2. 如果您没有苹果设备，如果别人的Nutale Air离开了自己的主人，并跟踪了您一段时间，当它移动时，它会发出音乐，以提醒您；当然，如果碰巧您身边的朋友正带着设备，或者您搭乘的地铁上很多人都有这个设备，也不必担心。因为只要设备没离开主人身边，就不会触发这样的提醒。

2. Воспроизвести звук  
Телефон и устройство находятся в зоне действия Bluetooth (обычно около 20 метров). В приложении поиска нажмите "Воспроизвести звук", и устройство издает музыку, помогая вам быстро найти ближайший предмет.

## кнопки устройства

1. включение устройства  
Нажмите и удерживайте кнопку в течение пяти секунд, затем устройство издает звук, и свет мигнет три раза, после чего устройство включится.  
2. Подтверждение состояния устройства  
Дважды нажмите кнопку устройства, если устройство издает звук и светочувствительный диод мигнет три раза, это означает, что устройство работает. Если устройство не издает звука, это значит, что оно выключено. Нажмите и удерживайте кнопку в течение пяти секунд, чтобы включить устройство.

3. Устройство снова входит в режим сопряжения  
После удаления устройства, оно издает звуковой сигнал, индикаторный свет мигнет шесть раз, устройство не выключится и перейдет в режим сопряжения. Если через 10 минут устройство не будет сопряжено, оно выйдет из режима сопряжения, и его уже не будет возможно сопряжить с приложением. Если вам нужно сопряжить устройство, нажмите кнопку устройства один раз, устройство издает звук, свет мигнет один раз. В этот момент устройство переходит в режим сопряжения и может быть сопряжено с приложением заново.

## 使用说明

1. включение устройства  
Удерживайте кнопку устройства в течение 5 секунд, устройство зазвучит и включится.  
2. привязать устройство  
· Откройте встроенное приложение «Find» от Apple.  
· Подведите устройство к вашему iPhone, нажмите на вкладку «Вещи», выберите «Добавить новую вещь», затем нажмите на «Другие поддерживаемые вещи».  
· Устройство с надписью "Blackshark Tag", нажмите "Подключить".  
· Введите «Пользовательское имя» для назначения имени вашему устройству и выберите эмодзи.  
· Согласитесь с регистрацией устройства под вашим Apple ID.  
· Нажмите «Готово», чтобы завершить привязку.  
3. включить режим потерянного устройства  
· Откройте встроенное приложение Apple «Find», нажмите на «Вещи» в нижней части экрана, а затем нажмите на имя предмета.  
· Под "Режимом потерянного устройства" нажмите "Включить".  
· Следуйте указаниям на экране, нажмите "Продолжить" и введите контактный телефон или электронную почту.  
· Нажмите "Далее", чтобы проверить информацию, а затем снова нажмите "Включить", чтобы завершить настройку.

4. Удалить устройство  
· Откройте встроенное приложение "Find" («Найти») Apple, нажмите на "Вещи" в нижней части экрана, а затем нажмите на название вещи.  
· Внизу списка найдите "Удалить предмет", нажмите "Удалить", чтобы завершить операцию.  
Примечание: После удаления устройства оно издает звуковой сигнал, светодиодный индикатор мигнет 6 раз, устройство не выключится и перейдет в режим сопряжения. Если в течение 10 минут устройство не будет сопряжено заново, оно выйдет из режима сопряжения, и его больше не будет возможно сопряжить с приложением. Если вам нужно сопряжить устройство, нажмите кнопку устройства один раз, устройство издает звук, и светодиодный индикатор мигнет один раз. После этого устройство перейдет в режим сопряжения и можно будет его сопряжить с приложением заново.

## Основные функции продукта

1、Поиск сетевой локализации  
Когда устройство находится за пределами диапазона Bluetooth и не может быть подключено через приложение "Find", вы можете выбрать режим "Потерянное устройство" и выбрать "Включить". Введите ваш контактный телефонный номер и другую информацию. Если устройство отсоединится от вашего телефона более определенного периода времени, и рядом с устройством находится другой iPhone, в вашем приложении "Find" появится уведомление, а также будет отображаться последняя известная позиция устройства.

начнет мигать. После этого отпустите кнопку. (Примечание: Если вы удерживаете кнопку в течение 2 секунд после включения, устройство издает звук "бип-бип-бип", и светодиод рядом с кнопкой начнет мигать. Не отпускайте кнопку, продолжайте удерживать ее, пока устройство не издает второй музыкальный сигнал, и светодиод рядом с кнопкой начнет мигать. После этого отпустите кнопку.)  
3. Попробуйте сопряжение с приложением "Find My" снова.

4. Восстановление заводских настроек  
Сначала удалите устройство из приложения Find My. Затем, после включения устройства, дважды нажмите на кнопку устройства, устройство издает звук, и немедленно удерживайте кнопку устройства примерно восемь секунд, пока устройство не издает звуковой сигнал, и светодиод мигнет три раза. Отпустите кнопку, и сброс на заводские настройки будет завершен. Теперь устройство можно будет сопряжить с новой учетной записью.

5. выключить  
Устройство в состоянии включения, нажимайте кнопку устройства 5 раз в течение 2 секунд, устройство издает звуковой сигнал, светодиод мигнет три раза, и устройство перейдет в состояние выключения.

## Часто задаваемые вопросы

1. Когда устройство может быть локализовано другим iPhone?  
Когда устройство отсоединится от iPhone владельца на определенное время, другие iPhone могут начать определять местоположение устройства, и владелец сможет начать получать информацию о местоположении устройства.

2. Как проверить, включено ли оборудование?  
Дважды нажмите кнопку устройства. Если устройство издает звук и светочувствительный диод мигнет три раза, это означает, что устройство работает. Если устройство не издает звука, значит, оно выключено. Нажмите и удерживайте кнопку в течение пяти секунд, чтобы включить устройство.

## Важное уведомление

При сопряжении устройства с приложением "Find My" необходимо подключиться к серверам Apple. Если возникает ситуация, когда устройство не сопрягается, это обычно означает, что используемая сеть временно не может подключиться к серверам Apple. Рекомендуемые действия:

1. Попробуйте изменить сеть на своем телефоне, например, переключитесь между Wi-Fi и мобильной сетью.  
2. Восстановите настройки устройства до заводских: После включения устройства дважды нажмите на кнопку устройства, дождитесь звукового сигнала, затем нажмите и удерживайте кнопку на протяжении примерно 8 секунд, пока устройство не издает второй звуковой сигнал, и светодиод