Luminous Robot

User Manual



Made in China

Dear users:

Shalom!

Welcome to use our digital products!

The company will enter your work and life with high-tech quality and excellent service, once you have it, you will really feel its excellent performance and excellent quality, so that you can always enjoy the relaxed and happy life. In order to make you better experience the Seiko quality of the company, please read this manual carefully before using this product. If you have any confusion, you can consult the customer service of our company.

Unsecured Statement:

The contents in this manual, unless required by applicable law, provide no warranty, express or implied, for all contents in this manual. To the extent permitted by law, we shall not compensate for any special, incidental, indirect, secondary damage arising from the use of this manual, or for any loss of profit, data, goodwill or expectation.

product features:

1. This product is a night light, Bluetooth speaker as one of the intelligent products.
2. Can be used for gifts, bedside alarm clock, children's toys, etc.
3. Power input:DC5V / 2A
4. Exquisite in appearance and elegant in appearance. Portable, multipurpose design.
5. Simple operation, high practical life.
6. Projection coverage: (15-30) square

How to connect to Bluetooth?

1. Turn on the projector and hear "Bluetooth mode".
2. Turn on the Bluetooth on your phone and connect to "JN117". If the connection is successful, a "Bluetooth connection" message will be displayed.
3. Click on the music play button.
4. If your Bluetooth-connected device feels that the speaker volume is low, it is recommended that you check that the "Headset Safety" feature in the device's Settings is enabled. By adjusting this setting, you may be able to increase the output volume of your Bluetooth device for a more satisfying listening experience.

Host key operation instructions



1. **Power Switch / LED :** Short press to switch to LED mode, and long press for 2 seconds to power off.

2. **Nebula / star toggle switch :** Short press once to turn off the nebula and turn on the stars,short press twice to turn off the stars and turn on the nebula, short press three times to turn off the stars and nebula, short press four times to turn on the stars and nebula.

3. **Previous / Volume+ :** Short press to switch to the previous song, long press to increase volume.

4. **Next / Volume- :** Short press to switch to the next song, long press to reduce the volume.