

Additional Resources




Additional Resources



Scent Diffuser 2 User Manual



Returns and Exchanges



Scentiment, LLC, Miami, FL 33122



3- You can now turn your diffuser back on.



Note: Note: If your diffuser was connected to the Scentiment App, after the reset you will need to pair the diffuser again.

Replacing the Nozzle

In case your Diffuser Scent Diffuser 2 nozzle gets damaged, you can replace it with the spare nozzle that comes with your Diffuser.

Follow these instructions to replace the nozzle:

- 1- Pull the Scent Diffuser 2 Diffusion Head. 2- Unscrew the oil bottle and set it aside.



3- Remove the black nozzle and oil tube from the diffuser with the metal hook.



4- Install the spare nozzle, making sure it's tight enough to ensure.



5- Screw the fragrance oil bottle in the Diffusion Head.



6- Install the Diffusion Head back on the diffuser.



7- You are ready to use your diffuser.



How to clean the diffuser

For best performance:

If the machine is unused for a while, clean the container with Scentiment's Diffuser Cleaner solution, filling it almost to the top of the oil bottle.

Clean the Scent Diffuser 2 every 1-2 months:

- Remove the Diffusion Head.
- Replace the oil bottle with either a 50 ml or 120 ml Scentiment Diffuser Cleaner Bottle or fill the provided glass bottle with Scentiment's Diffuser Cleaner and reinstall securely.



• Install the Diffusion Head back in the Scent Diffuser 2.



• Let the Diffuser run for two hours to ensure thorough cleaning.



Important Note: Place the diffuser in a very ventilated area when using the Diffuser Cleaner. For your safety, refrain from directly inhaling the mist emitted from the diffuser as it may pose risks to your respiratory system.

For general cleaning, use a damp cloth to remove stains and fingerprints.

Replacing The Pump

Your Scent Diffuser 2 pump can be easily replaced with a new one.

- 1- Remove the top of the diffuser along with the oil bottle to prevent any spillage. 2- Go to the bottom of the diffuser and locate the bottom gate.



3- Open the gate by pinching the two sliders.



4- Using your finger, pull the metallic handle and pull the Pump Cartridge out.



5- Insert your new Pump Cartridge and reinstall the bottom gate.



Safety

Is it safe for kids and animals?

Yes, our fragrance oils are safe to use around people, pets, plants, and furniture, 100% free of all Parabens, Formaldehyde, Color Additives, Synthetic Dyes, and Preservatives.

Warnings

For best results:

- Avoid turning over or tilting the product to prevent damage.
- Don't modify or disassemble it.
- Use within the recommended temperature range of 2°C to 35°C.
- When not in use for a while, remove the oil bottle and store it separately.
- Keep out of reach of children and pets.
- Normal shaking may cause sound due to the anti-dumping device.
- Atomization effect may vary based on the fragrance oil type.
- For optimal results, use fragrance oils.

Warranty

Your device comes with a 6-month limited warranty. Please ensure that you have proof of purchase in case a claim arises. Please note that the warranty is non-transferable. The following will not be covered under warranty:

- Damage caused by accidents or fire.
- Failure to use the device properly.
- If the device is repaired by a non-authorized dealer.
- Third-party parts are used in the machine.

Returns & Replacements

All returned items, whether for a refund, exchange, repair, or replacement, undergo inspection in our warehouse within a timeframe of 10 to 14 business days. If you haven't received an update from us within this period, feel free to reach out and inquire after the 14th business day mark.



Scent Diffuser 2
User Manual



What's included in the box

- Scent Diffuser 2
- Remote Control
- User Manual
- USB-A to USB-C charging cable
- Empty 120ml Oil Bottle and Cap
- Metal Hook
- Power Brick

Diffuser technical description

- Weight: 1050g
- Voltage: DC5V 2A
- Coverage: 1,000 sq ft
- Oil Bottle Capacity: 120ml
- Power: 5W
- Noise: <28 dba

Features



- **Expansive Reach.** Effortlessly scent large spaces up to 1,000 sq ft.
- **Safe & Clean.** Advanced technology ensures a residue-free experience that's safe for everyone and everything.
- **Personalized Aromas.** Adjust the intensity to create your perfect ambiance.

Power Connection

Connection Instructions

1- Take your cable out of the box.



2- Connect the Scent Diffuser 2 to the cable.



3- Plug the cable into a port, outlet, computer, or power brick.



• You will see the front Lightbar pulsing with a green light, indicating the device is charging.

• After the battery is fully charged, the green light will remain still.



Now you can plug your Scent Diffuser 2.



Battery Alert
When the diffuser battery reaches 20% or a lower level, the lightbar will pulse with a red light every five seconds until it's completely depleted or connected to a power source.



How to add oil to the diffuser

Pair your Scent Diffuser 2 with Scentific's 50 ml and 120 ml oil bottles

To replace the oil bottle

1- Pull up the Diffusion Head of the diffuser. It will reveal the 120ml plastic bottle that comes with the diffuser.



2- Replace it with either a 50 ml or 120 ml Scentific Oil Fragrance Bottle or fill the empty bottle with your preferred Scentific fragrance.




3- Securely reinstall the diffusion head, ensuring correct alignment.



How to Use the Diffuser

On/off the device: press and hold the rear power button for 2 seconds.



Misting Intensity Settings

The Intensity Level can be changed by pressing the rear button.

Low: It will mist for 1 second and then remain dormant for 90 seconds.



Medium: It will mist for 30 seconds and then remain dormant for 60 seconds.



• **High:** It will mist for 60 seconds and then remain dormant for 30 seconds.



Connect your diffuser to Scentific App

1- Scan the code to download the app.

2- Turn your diffuser on.

3- Open Scentific App



4- Create an account.



5- Select "Connect My Device" and follow the prompts.



Factory Reset

To perform a factory reset, follow these steps

1- Turn your diffuser off.



2- Press the rear button for five (05) seconds. The lightbar will blink with blue light, indicating that the factory reset was successful.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction