




品名:	T19 说明书 (英文版本)	材料 工艺:	成品尺寸: 70*70mm 18P, 风琴折, 四色印刷 128g哑粉纸
时间:	2024-07-11		
版本:	V1.0		
料号:			

<p>T19 Noise Elimination Wireless Earbud User Manual</p>  <p>Thank you for purchasing our product. This manual notes the operating instructions, safety guidelines and warranty. Please read carefully before using your earbud.</p>	<p>Content</p> <p>Package Contents 1 General Description 2 LED Indicators 3 How to Wear 4 How to Use 7 Cleaning 11 Questions & Answers 11 Specifications 13 Safety Instructions 14</p>	<p>Package Contents</p> <p>① T19 noise elimination wireless earbud x 1 ② USB-C charging cable x 1 ③ User manual x 1 ④ Ear tips of S / M / L sizes (the M size tip is pre-attached on the earbud)</p>  <p>- 1 -</p>	<p>General Description</p>  <p>- 2 -</p>	<p>LED Indicators</p> <table border="1"> <thead> <tr> <th>Earbud Status</th> <th>LED Indicator</th> </tr> </thead> <tbody> <tr> <td>Power on</td> <td>Stays blue for 2 seconds and goes off.</td> </tr> <tr> <td>Enter the pairing mode</td> <td>Flashes red and blue alternately.</td> </tr> <tr> <td>Connection successful</td> <td>Flashes blue 2 times and goes off.</td> </tr> <tr> <td>Incoming call</td> <td>Flashes blue once every 2 seconds.</td> </tr> <tr> <td>Power off</td> <td>Stays red for 2 seconds and goes off.</td> </tr> <tr> <td>Low battery</td> <td>Flashes red every 5 seconds.</td> </tr> <tr> <td>Out of battery</td> <td>Stays red and goes off.</td> </tr> <tr> <td>Charging</td> <td>Stays red.</td> </tr> <tr> <td>Fully charged</td> <td>Goes off.</td> </tr> </tbody> </table> <p>- 3 -</p>	Earbud Status	LED Indicator	Power on	Stays blue for 2 seconds and goes off.	Enter the pairing mode	Flashes red and blue alternately.	Connection successful	Flashes blue 2 times and goes off.	Incoming call	Flashes blue once every 2 seconds.	Power off	Stays red for 2 seconds and goes off.	Low battery	Flashes red every 5 seconds.	Out of battery	Stays red and goes off.	Charging	Stays red.	Fully charged	Goes off.	<p>How to Wear</p> <p>The T19 earbud is suitable for wearing on either ear, and it is factory set for your left ear. To wear the earbud on another ear, adjust the direction of the microphone, ear hook and earbud nozzle.</p> <p>To wear the earbud on your left ear:</p> <ol style="list-style-type: none"> 1. Insert the earbud into your ear, and twist it to fit snugly into the ear canal. 2. Hang the ear hook on your left ear. The 'L' symbol on the ear hook should face outward. 3. Adjust the microphone's position until it can clearly receive your voice.  <p>- 4 -</p>	<p>To wear the earbud on your right ear:</p> <ol style="list-style-type: none"> 1. Rotate the microphone about 180° clockwise. 2. Rotate the ear hook about 180° counterclockwise. 3. Rotate the earbud nozzle about 45° counterclockwise. 4. Insert the earbud into your ear, and twist it to fit snugly into the ear canal. 5. Hang the ear hook on your right ear. The 'R' symbol on the ear hook should face outward. 6. Adjust the microphone's position until it can clearly receive your voice. <p>- 5 -</p>	 <p>To convert the earbud the left-ear mode, rotate the related components in the opposite direction as described above.</p> <p>- 6 -</p>	<p>How to Use</p> <p>Pairing</p> <ol style="list-style-type: none"> 1. Hold the power button for 5 seconds. The LED indicator will stay blue for 2 seconds and go off. The earbud will then enter the pairing mode and the LED indicator flashes red and blue alternately. 2. Enable Bluetooth on your device. Make sure the earbud and your Bluetooth device are next to each other within 3 feet and there are no obstacles between. 3. Find 'T19' on your Bluetooth device. Choose it and pair. The LED indicator will go off if the pairing succeeds. 4. To turn off the earbud, hold the power button for 5 seconds. The LED indicator will stay red for 2 seconds and go off. <p>Notes:</p> <p>When the earbud is on, it will automatically connect to the device that they paired successfully last time if the Bluetooth address of this device is available.</p> <p>If the earbud is on but fail to connect to any device, it will be automatically off after 2 minutes. The LED indicator will stay red for 2 seconds and go off.</p> <p>- 7 -</p>
Earbud Status	LED Indicator																											
Power on	Stays blue for 2 seconds and goes off.																											
Enter the pairing mode	Flashes red and blue alternately.																											
Connection successful	Flashes blue 2 times and goes off.																											
Incoming call	Flashes blue once every 2 seconds.																											
Power off	Stays red for 2 seconds and goes off.																											
Low battery	Flashes red every 5 seconds.																											
Out of battery	Stays red and goes off.																											
Charging	Stays red.																											
Fully charged	Goes off.																											

<p>Dual-Device Connection</p> <ol style="list-style-type: none"> 1. The T19 earbud allows connection with 2 Bluetooth devices at a same time. 2. After the earbud is connected to a device, you can pair it with another Bluetooth device by selecting the device name 'T19' on the device. The LED indicator will flash blue 2 times and go off if the pairing succeeds. 3. You can hear the voice prompt if any of the 2 devices are unconnected with the earbud. If both 2 devices are unconnected with the earbud, it will enter the pairing mode automatically. The LED indicator flashes red and blue alternately. <p>Notes:</p> <p>When the earbud is connected to 2 devices, playing a video or audio on one device will cause the video or audio playing on another device to pause.</p> <p>When there is an incoming call on either of the devices, click the multi-function button to answer it. When answering a phone call on either of the devices, the earbud won't respond if another device receives a phone.</p> <p>- 8 -</p>	<p>Power/Volume Button</p> <ol style="list-style-type: none"> 1. To power on the earbud, hold the power button for 5 seconds. The LED indicator will stay blue for 2 seconds and go off. The earbud will then enter the pairing mode automatically. 2. Click the power/volume button once to increase the volume. You can hear the voice prompt when the earbud reaches its maximum volume. Click once again to go back to the minimum. 3. To turn off the earbud, hold the power button for 5 seconds. The LED indicator will stay red for 2 seconds and go off. <p>Multi-Function Button</p> <ol style="list-style-type: none"> 1. When connecting, click the multi-function button once to play or pause the audio or video. Click twice to play the next track. Click three times to play the last track. 2. When there is an incoming call, click the multi-function button once to answer it. Hold the button for 3 seconds to reject it. <p>- 9 -</p>	<p>Charge the Earbud</p> <ol style="list-style-type: none"> 1. Plug the charging cable into the USB-C charging port. Connect the power supply. The LED indicator will stay red during charging. 2. After the earbud is fully charged, the LED indicator will go off. <p>Note:</p> <p>When the battery level is low, the LED indicator will flash red every 5 seconds, and the voice prompt will warn you once every 1 minute.</p> <p>When the earbud is out of power, the LED indicator will flash red every 2 seconds, and the earbud will automatically shut down.</p> <p>When the earbud is off, it will not automatically turn on if being charged.</p> <p>- 10 -</p>	<p>Cleaning</p> <p>The earbud may require regular cleaning. To prevent the dust to block charging port which will lead to charging problems as well as to keep microphones clean to guarantee the noise cancelling functions, please clean them regularly and only with a dry, soft cotton swab or equivalent. Note that never insert any cleaning tool into the earbud nozzle.</p> <p>Questions & Answers</p> <p>Q: Pairing failed. A: 1) Turn on the Bluetooth on your phone. 2) Delete all your Bluetooth addresses which have been connected to your phone. 3) Discover Bluetooth devices again and select 'T19' in the list. If the pairing still fails, please try again.</p> <p>Q: Connection is not stable. A: Bluetooth signals can be affected when transmitting. Then it will lead to the sound intermittent. In this case, check if the following conditions occur: 1) The distance between the earbud and your Bluetooth device is at the edge of the Bluetooth transmission distance. 2) Signals encounter obstacles or human body blockage.</p> <p>a) Make sure the earbud and your Bluetooth device are next to each other within 3 feet and have no obstacles between them. b) Make sure there is no signal interference nearby. (If there is, please refer to the 'Connections is not stable' below).</p> <p>- 11 -</p>	<p>Q: I paired the earbud with my Bluetooth device before, but failed to pair them again. A: 1) Turn on the Bluetooth on your phone. 2) Delete all your Bluetooth addresses which have been connected to your phone. 3) Discover Bluetooth devices again and select 'T19' in the list. If the pairing still fails, please try again.</p> <p>Q: Connection is not stable. A: Bluetooth signals can be affected when transmitting. Then it will lead to the sound intermittent. In this case, check if the following conditions occur: 1) The distance between the earbud and your Bluetooth device is at the edge of the Bluetooth transmission distance. 2) Signals encounter obstacles or human body blockage.</p> <p>- 12 -</p>	<p>Specifications</p> <table border="1"> <tbody> <tr> <td>Model</td> <td>T19</td> </tr> <tr> <td>Bluetooth Version</td> <td>V5.3</td> </tr> <tr> <td>Battery Capacity</td> <td>110mAh</td> </tr> <tr> <td>Charging Time</td> <td>2 hours</td> </tr> <tr> <td>Waterproof Rate</td> <td>IPX4</td> </tr> <tr> <td>Input Voltage/Current</td> <td>5V/1A</td> </tr> <tr> <td>Playtime</td> <td>10-12 hours</td> </tr> <tr> <td>Bluetooth Range</td> <td>10m</td> </tr> <tr> <td>Supporting Protocols</td> <td>A2DP/HEP/HSP/AVRCP</td> </tr> <tr> <td>Supporting Codecs</td> <td>AAC/SBC</td> </tr> <tr> <td>Working Temperature</td> <td>-10℃ -40℃</td> </tr> </tbody> </table> <p>*Playtime of the earbud may vary by the volume and content you play.</p> <p>- 13 -</p>	Model	T19	Bluetooth Version	V5.3	Battery Capacity	110mAh	Charging Time	2 hours	Waterproof Rate	IPX4	Input Voltage/Current	5V/1A	Playtime	10-12 hours	Bluetooth Range	10m	Supporting Protocols	A2DP/HEP/HSP/AVRCP	Supporting Codecs	AAC/SBC	Working Temperature	-10℃ -40℃	<p>Safety Instructions</p> <p>Use of the earbud will impair your ability to hear other sounds. Use cautiously while using your earbud when you are engaging in any activity that requires your full attention.</p> <p>If you have a pacemaker or other electrical medical devices, consult your physician before using this product.</p> <p>This product is not a toy - never allow children to play with this product. The bags themselves or the small parts they contain may cause choking if ingested.</p> <p>Never try to disassembly the product by yourself, or push objects of any kind into the products, as this may cause short circuits which could result in a fire or electric shock.</p> <p>None of the components can be replaced or repaired by users. Only authorized dealers or service centers can open the product.</p> <p>Avoid exposing your product to heat and humidity to protect against damage to the product or injury to you.</p> <p>If the product is overheated, dropped or damaged, has a damaged cord or plug, or has been dropped in a liquid, please shut it down and don't use it immediately.</p> <p>- 14 -</p>	<p>Do NOT use in areas where there are explosive hazards. Do NOT submerge the product in water. Do NOT expose the product under moving water (e.g., from a faucet, etc.) Do NOT wear the earbud while showering or bathing, or when participating in water sports, e.g. swimming, waterskiing, surfing, etc.</p> <p>Leaving the product in hot or cold places, such as a closed car in the summer and winter conditions, will reduce the capacity and lifetime of the earbud.</p> <p>Do NOT use a charging case that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury. Dispose of the product according to local standards and regulations.</p> <p>Remember: Always drive safely, avoid distractions and follow local laws!</p> <p>Using the earbud while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions, just as use of the earbud with both ears covered while driving is not permitted in certain jurisdictions. Check your local laws.</p> <p>Be cautious while using your earbud when you are engaging in any activity that requires your full attention. While engaging in any such activity, removing the earbud from your ear or turning off your earbud will keep you from being distracted, so as to avoid accident or injury. Do not take notes or read documents while driving.</p> <p>- 15 -</p>
Model	T19																												
Bluetooth Version	V5.3																												
Battery Capacity	110mAh																												
Charging Time	2 hours																												
Waterproof Rate	IPX4																												
Input Voltage/Current	5V/1A																												
Playtime	10-12 hours																												
Bluetooth Range	10m																												
Supporting Protocols	A2DP/HEP/HSP/AVRCP																												
Supporting Codecs	AAC/SBC																												
Working Temperature	-10℃ -40℃																												

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.