



Content

Speaker * 1/Charging cable * 1/User Manual * 1

Product diagram

Top view panel diagram of speaker



Rear view panel diagram of speaker

Specifications

Model	E-3583
Function	Wireless/USB/TF/AUX/RGB lights
Wireless connection distance	≥10m
Output power	3w*2
Output voltage	DC 5V
Speaker Specifications	2in*2
Frequency range	60Hz-16KHz
SNR	≥75db

Function Instructions

1. Power on/off

Turn "⑤" to ON to turn on the device, and turn "⑤" to OFF to turn off the device.

2. Play/Pause/Previous/Next

Short press "①" to pause or play music, long press "③" to play the previous song, long press "②" to play the next song.

3. Volume adjustment

Short press "③" to decrease the volume, and short press "②" to increase the volume.

4. Wireless connection playback

By default, the device enters wireless mode when turned on, with the indicator light flashing blue and the Bluetooth connection function enabled. Search for the wireless name "E-3583" to connect to the Bluetooth of the device.

5. USB flash drive playback

Insert the USB drive containing MP3 format audio files into "⑧" and it will automatically enter the USB drive playback mode.

6. TF card playback

Inserting the TF card containing MP3 format audio files into "⑦" will automatically enter TF card playback mode.

7. AUX audio connection playback

Insert one end of the audio cable into a device that supports AUX audio output, and insert the other end into "⑥". It will automatically enter AUX audio playback mode for playback.

8. Play mode switching

When the speaker has multiple audio input states, you can short press "④" to switch playback modes.

9. Light switch and light transformation

Long press "④" to turn on and off the lights and change the light mode.

10. Speaker Charging

Insert the charging cable into the other end of "⑨". Plug in the power adapter and turn on the power. The red indicator light is on to activate the speaker charge.

certificate

It is hereby certified that the product is qualified after inspection

examination clerk: _____

Inspection date: _____

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.


This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

E-3583 多功能桌面音箱 使用说明书

包装清单

音箱*1/充电线*1/使用说明书*1

产品示意图



产品参数

产品型号	E-3583
产品功能	无线连接/USB/AUX/TF/RGB灯
无线连接距离	≥10m
输出功率	3W*2
输入电压	DC 5V
喇叭规格	2in*2
频率范围	60Hz-16KHz
音频信噪比	≥75db

功能使用说明

1. 开机/关机

拨动“⑤”到ON开机,拨动“⑤”到OFF关机。

2. 播放/暂停/上一曲/下一曲

短按“①”暂停或播放音乐, 长按“③”上一曲, 长按“②”下一曲。

3. 音量调节

短按“③”调小音量, 短按“②”调大音量。

4. 无线连接播放

开机默认进入无线模式, 指示灯闪烁蓝灯, 打开带蓝牙连接功能的设备的蓝牙, 搜索无线名为“E-3583”进行连接。

5. U盘播放

将存储有MP3格式的音频文件的U盘插入“⑧”, 会自动进入U盘模式读取U盘进行播放。

6. TF卡播放

将存储有MP3格式的音频文件的TF卡插入“⑦”, 会自动进入TF卡模式读取TF卡进行播放。

7. AUX音频连接播放

将音频线一端插入支持AUX音频输出的设备, 另一端插入“⑥”会自动进入AUX音频播放模式进行播放。

8. 播放模式切换

当音箱有多种音频输入状态时, 可短按“④”进行播放模式切换。

9. 灯光开关和灯光变换

长按“④”可开关灯光和变换灯光模式。

10. 音箱充电

将充电线插入“⑨”另一端插入电源适配器上接通电源红色指示灯亮起对音箱进行充电。

合格证

经检验为合格产品, 特此证明

检验员: _____

检验日期: _____