


9.5cm



## MICROPHONE PRODUCT FUNCTION DESCRIPTION



- 2. Light/Bluetooth
- 3. Previous/Song
- 4. Next song/Children's song
- 5. Volume+/Learning
- 6. Volume -/Story
- 7. Microphone volume+/-
- 8. Role play

7 buttons

1 mic

1 charging port

Bluetooth device name: MONKEY

1 three color light (with a notch but not connected)

### Power on: Enter the startup mode.

- ① Power on: Play a startup sound (button invalid) and enter standby mode.
- ② Standby: No operation for 15 minutes, enter shutdown mode.
- ③ Shutdown: Play a shutdown sound and enter sleep mode.
- ④ Sleep: The button cannot wake up (power needs to be turned off before powering on).
- ⑤ Low battery: When the voltage is below 3.5V, a low battery warning sound will be played every 55s. After playing a shutdown sound below 3.3V (other buttons are invalid), the device will shut down and enter sleep mode.
- ⑥ Charging: The charging hardware loses power.

### Local mode:

#### 1. volume

5 levels of volume, default to level 5, mic volume changes with the master volume.

#### 2. mic

By default, it is turned on when turned on, and the mic volume changes with the master volume.

#### 3. light

By default, it is turned on when turned on.

#### 4. Bluetooth

Bluetooth on, off, connected, and disconnected all play prompt sounds.

正面

背面

### Local mode:

#### 1. Function key 1: Light/Bluetooth

Short press: Turn on/off the light Long press: Turn on Bluetooth (enter Bluetooth mode)

#### 2. Function key 2: Children's songs (6 songs)

001 Children's Song - A Tisket A Tasket

002 Children's Song - Bago

003 Children's Song - I Love the Mountains

004 Children's Song - Old MacDonald

005 Children's Song - Skidamarink

006 Children's Song - The Wheels on the Bus

#### 3. Function key 3: Songs (6 songs)

001 English Song\_Saby

002 English Song - Dream It Possible

003 English Songs\_Monsters

004 English Song\_Stupid Heart

005 English Song - Rough Is a Friend

006 English song - Jar Of Love

#### 4. Function key 4: Learning (3 songs)

001 Good study habits

002 Good Health Habits

003 Good Habits of Civilization

#### 5. Function key 5: Story (5 songs)

001 English Story 01 Donkey and Wolf

002 English Story 02 Hungry Dog

003 English Story 03 Thirsty Crow

004 English Story 04 Wolves and Herds

005 English Story 05 Rabbit and Frog


Short press: triggers 1 playback of 1 song, without continuous playback

#### 6. Function 6: Volume adjustment:

5->4->3->2->1->2->3->4->5

#### 7. Function 7: Magic Sound:

Short press: Switch between 5 magic sound effects Long press: Close mic



### Bluetooth mode:

Function key 1: Light/Bluetooth Short press: Turn on/off the light

Long press: Turn on Bluetooth (enter Bluetooth mode) Function key 2: Children's songs (6 songs)

Function key 3: Songs (6 songs) Function key 4: Learning (3 songs) Function key 5: Story (5 songs)

Short press: triggers 1 playback of 1 song, without continuous playback

Function 6: Volume adjustment: 5->4->3->2->1->2->3->4->5

Function 7: Magic Sound: Short press: Switch between 5 magic sound effects Long press: Close mic

### CAUTION:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### CAUTION:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.