

## 4. DESCRIPTION OF TEST MODES AND CONFIGURATIONS

### 4.1. DESCRIPTION OF ANTENNA LOCATION



## 4.2. DESCRIPTION OF ASSESSMENT POSITION

The following test configurations have been applied in this test report:




**A**

The bottom of the EUT faces to the phantom with 0mm-separation distance.



**B**

The edge of the EUT faces to the phantom with 0mm-separation distance.



**SETUP PHOTO**