

MEX-BT2700


Disassembly Picture



SCREW(For Cover)


MAIN ASSY

Panel Front ASSY




Screw (2 portion For Mecha deck Bracket)

Screw (2 portion For Mecha deck )




Panel Sub ASSY



Screw (3 portion For For MAIN PWB)



Screw (2 portion For For Heatsink)



Antenna position

