


Index of the schematic diagram for SF-F1

Schematic diagram	Name of P.W.Board
S - 411 - 01 - 11	P.W.BOARD A (401RRC-217-01R) (system/mode control)
S - 411 - 02 - 11	P.W.BOARD B (401RRC-218-01R) (transmitter and receiver)
S - 411 - 03 - 11	P.W.BOARD C (401RRC-219-01R) (antenna)


87001-87002-87003-R6 TYPE DRV CELL BATTERIES.



ALL resistors are in ohms. W  
unless otherwise noted.

ALL capacitors are in uF(p:pF)  
unless otherwise noted.


SF-F1  
S-411-01-11  
P.W. BOARD A (401RRC-217-010)



ALL resistors are in ohms. W unless otherwise noted.

ALL capacitors are in uF(p:pF) unless otherwise noted.

SF-F1  
 S-411-02-11  
 P.W. BOARD B (401RRC-218-01R)  
 (transmitter and receiver)



ALL resistors are in ohms.1/10W  
unless otherwise noted.

ALL capacitors are in uF(p:pF)  
unless otherwise noted.

NF-F1

S-411-03-11

P.W. BOARD C (401RRC-219-01R)  
(ANTENNA)