



Model: WRT-805A(64)



Model: WRT-805A(64)

UHF SYNTHESIZED
TRANSMITTER WRT-805



Model: WRT-805A(64)

Switch Function

Mode	20000	10000	5000	2500
①	ON	ON	ON	ON
②	OFF	OFF	OFF	OFF
③	ON	OFF	ON	OFF
④	OFF	ON	OFF	ON

Settings

1. With the power switch on, press the [SET] button. The display shows "00000".

2. Press the [2] button to set the mode. The display shows "20000".

3. Press the [3] button to set the mode. The display shows "10000".

4. Press the [4] button to set the mode. The display shows "5000".

5. Press the [5] button to set the mode. The display shows "2500".

6. Press the [6] button to set the mode. The display shows "00000".


7. Press the [7] button to set the mode. The display shows "00000".

8. Press the [8] button to set the mode. The display shows "00000".

9. Press the [9] button to set the mode. The display shows "00000".

10. Press the [0] button to set the mode. The display shows "00000".

Model: WRT-805A(64)



Switch function

-60dBV	ECM-122MP
	GC-07MP
	ECM-122MP
	ECM-310MP
	ECM-448MP

Settings

- 1 While holding SET button down, set POWER switch to ON.
- 2 Press SET button again to select the item (CH, AIT or TIME) to be set.
- 3 Press (M) buttons to set CH or AIT.
- 4 To reset the running time, press (M) button.
- 5 Set POWER switch to OFF to store the settings.

WRT-805A (64)

IMP SYNTHESIZED TRANSMITTER

770 00-791325A41


NO.

PCO ID :

Make to Japan

Imp Corporation

Model: WRT-805A(64)



Model: WRT-805A(64)